

PART TWO

SYSTEM AND COMPONENT MAINTENANCE

SECTION 1 - OVERALL SYSTEM MAINTENANCE

2-1

INTRODUCTION	2-1
SERVICING PROCEDURES	2-1
MAIN POWER SUPPLY	2-5
SEQUENCE OF OPERATION	2-5
SCHEMATIC DIAGRAM, MODEL R-83	2-22
SCHEMATIC DIAGRAM, MAIN POWER SUPPLY	2-25
WIRING DIAGRAM, PHONO HARNESS	2-26
SCHEMATIC DIAGRAM, SELECTION COMPUTER	2-27

SECTION 2 - CREDIT AND SELECTION SYSTEM MAINTENANCE

2-28

MAJOR COMPONENTS	2-30
INTRODUCTION	2-29
PRICING	2-29
PRICE OF PLAY PROGRAMMING	2-29
PREMIUM PRICING	2-35
CREDIT COMPUTER TROUBLESHOOTING	2-36
160, 120, 100 SELECTION PROGRAMMING	2-37
SELECTION SYSTEM OPERATION	2-37
COIN SWITCH ADJUSTMENT	2-37
CREDIT SYSTEM OPERATION	2-38

SECTION 3 - RECORD CHANGER MECHANISM MAINTENANCE

2-41

INTRODUCTION	2-39
PREVENTIVE MAINTENANCE	2-39
RECORD CHANGER MECHANISM OPERATION	2-39
RECORD CHANGER MECHANISM WIRING DIAGRAM	2-40
ADJUSTMENTS	2-41


SECTION 4 - SOUND SYSTEM MAINTENANCE

2-55

INTRODUCTION	2-54
EXTENSION SPEAKER OPERATION	2-54
REMOTE VOLUME AND CANCEL CONTROL	2-54
STEREO SOUND SYSTEM CHART	2-56
POWER LEVEL SETTINGS	2-57
SOUND SYSTEM QUIK CHEK	2-58
SOUND SYSTEM PRINCIPLES OF OPERATION	2-60
125 WATT AMPLIFIER SCHEMATIC DIAGRAM	2-65
PREAMPLIFIER SCHEMATIC DIAGRAM	2-64
125 WATT AMPLIFIER WIRING DIAGRAM	2-67
OUTPUT TRANSFORMER PACKAGE SCHEMATIC DIAGRAM	2-68
OUTPUT TRANSFORMER PACKAGE WIRING DIAGRAM	2-69



SYSTEM BLOCK DIAGRAM



SECTION 1 - OVERALL SYSTEM MAINTENANCE

INTRODUCTION

The information in Part II of this publication is intended for personnel with electronic service experience who prefer to service their own equipment instead of returning circuit modules to the factory. Keep in mind that modules can be damaged by improper maintenance procedures. Rowe will assume no responsibility for such damage. If you're not sure of what you are doing, don't even take the cover off; send the module back to the factory for repair.

SERVICING PROCEDURES

The module package consists of a printed circuit board sandwiched between a metal mounting plate and a protective plastic cover. A foam pad between the circuit board and mounting plate insulates and cushions the board. Always replace the pad after servicing the board to prevent the foil side of the board from shorting against the mounting plate.

Remove the plastic cover by squeezing the edges inward until they clear the metal tabs on the mounting plate.





FIGURE 2-1. TYPICAL MODULE PACKAGE ASSEMBLY

PRECAUTIONS


The MOS chips have an extremely high input resistance (typically on the order of 10^{10} [10,000,000,000] ohms.) Due to this high input impedance, they can be damaged by high static charges. Care should be taken when handling circuit boards removed from the protective module package to avoid conditions where the board may be exposed to static discharges.

IC PIN LOCATIONS


When looking at IC from top, with indexing mark to your left, pin no. 1 is at lower left. Indexing mark may be notch or dimple.



CREDIT CHIP AND SELECTOR DISPLAY CHIP



MEMORY CHIP



14 PIN PACKAGE



16 PIN PACKAGE

FIGURE 2-2. INTEGRATED CIRCUIT PIN LOCATION

TESTING DISCRETE TRANSISTORS

Test transistors using a volt-ohm-milliammeter as follows:

1. Set the meter function switch to OHMS and the range switch to a medium scale (such as X10 on Simpson 260).
2. Connect ohmmeter to transistor leads to check NPN silicon transistors as follows:

NOTE

SOME METERS USE THE BLACK OR NEGATIVE LEAD AS THE POSITIVE LEAD FOR OHMS SCALE, TRIPLET BEING ONE OF THESE.

+ to emitter - to collector - no reading

+ to collector - to emitter - no reading

+ to base	- low reading (about 500 ohms)
- to collector	- no reading
+ to collector	- no reading
- to base	- no reading
+ to emitter	- no reading
- to base	- low reading (about 500 ohms)

3. With positive meter lead on collector and negative lead on emitter, touch base to collector. Check that the meter shows a low reading to indicate that the transistor is conducting.
4. All previous tests indicate a good transistor. Any deviation from these conditions indicates a defective transistor.
5. For PNP transistors, reverse the polarities and proceed as in the previous steps.

TESTING DARLINGTON POWER TRANSISTORS

Test Darlington transistors using a volt-ohm-milliammeter as follows:

1. Set the meter function switch to ohms, and the range switch to X1 (on Simpson 260) for scale.
2. Connect ohmmeter to transistor leads to check NPN silicon Darlington power transistors as follows:

NOTE

SOME METERS USE THE BLACK OR NEGATIVE LEAD AS THE POSITIVE LEAD FOR OHMS SCALE, TRIPLET BEING ONE OF THESE.

+ to emitter	- Low reading
- to collector	- No reading
+ to collector	- No reading
- to emitter	- No reading
+ to base	- Low reading
- to collector	- No reading
+ to collector	- No reading
- to base	- No reading
+ to emitter	- No reading
- to base	- Low reading
+ to base	- Low reading
- to emitter	- No reading

3. With positive meter lead on the collector and negative lead on emitter, touch the base to the collector. Check that the meter shows a low reading to indicate that the transistor is conducting.

4. For PNP transistors, reverse the polarities and proceed as in the previous steps.

TESTING SILICON DIODES

Test silicon diodes as follows:

1. Set the meter function switch to OHMS and the range switch to a medium scale.
2. Connect the diode as shown.

NOTE

CONNECTIONS MAY VARY WITH VARIOUS TYPES OF METERS. THE IMPORTANT THING TO REMEMBER IS THAT THE DIODE SHOULD INDICATE NO READING WITH THE LEADS CONNECTED ONE WAY AND A LOW RESISTANCE WHEN CONNECTED IN THE OPPOSITE POLARITY.





FIGURE 2-3. DIODE TEST HOOK-UP

REPLACING DARLINGTON POWER TRANSISTORS

Fuses mounted on driver boards on underside of amplifier serve a diagnostic function; an open fuse indicates a failed darlington power transistor, Q1 or Q2. Replace only the transistor adjacent to the open fuse. Use the following procedure:

125 Watt Amplifier

1. Replace open fuse and retest. If new fuse blows, continue as follows:
2. Remove guard covers from heat sink.
3. Remove transistor from socket on heat sink, being sure to retain mica insulator under transistor.
4. Apply Thermal Joint Compound (Rowe Spec 53) to BOTH sides of mica insulator and place insulator against heat sink.
5. Plug new transistor into socket and tighten mounting screws. One of the major causes of darlington failure is loose mounting screws. Be sure that screws are tight for proper heat transfer.

CAUTION

DIRECT CONTACT BETWEEN OUTPUT
TRANSISTOR AND HEAT SINK WILL DES-
TROY TRANSISTOR. INSULATE AS DIR-
ECTED.

6. Install new 5 amp fuse.

SOLDERING AND UNSOLDERING IC DEVICES

Integrated circuits, due to their fragile nature, require different soldering techniques than for discrete (individual) components. Improper soldering could also damage the circuit boards.

There are many devices on the market for soldering and unsoldering IC circuits. The following text describes some of the available devices. However, the technician will usually develop his own preferences.

Soldering irons for use with integrated circuits are available in many varieties. Simple versions are nothing more than a handle with a screw-in heating element and tip. Others include thermostatically controlled heating units. The selection of a soldering iron will be at the preference of the technician. However, the important thing to keep in mind is that the tip temperature should not exceed 750° (35W max.). Also the tip should be shaped to permit unsoldering of a single IC lead, if necessary, without heating adjacent components or pins. To prevent the introduction of leakage voltage into the circuit from the soldering iron, the tip should be grounded. This is accomplished by connecting a ground wire to the soldering iron holder or touching the tip of the iron to a grounded surface before using.

The simplest unsoldering tool is the wick or braid-type solder remover. Wound on a spool, it's a metal mesh that acts as a solder blotter. In use, a half-inch of the braid is placed on the joint and heat is applied for a period of one second per IC pin. Once the braid sucks up the solder, the iron and braid are removed together revealing a free joint. The wick is available in various widths.



FIGURE 2-4. USING BRAID TYPE SOLDER REMOVER

While braids work by capillary action, sippers and suckers draw solder with a vacuum. The simplest device in this category is a rubber bulb which inhales molten solder. The tip is made of Teflon, a plastic that won't combine with solder or suffer heat damage.




FIGURE 2-5. USING VACUUM BULB WITH TEFLON TIP

To use the bulb, squeeze it closed and then, when the solder melts, release it - vacuum does the rest. Since flowing solder cools and solidifies very quickly inside the bulb, it sometimes chokes the tip. Clear it with a wire. An advantage of the bulb is that it can be used in tight corners.

Soldering irons incorporating bulbs are also available. The major advantage of these devices is the convenience of one hand operation.

Be sure to discharge waste solder trapped inside the bulb after each joint is cleaned. Be careful on the discharge since it comes out of the tool as a fine spray of solder when the bulb is squeezed. Direct the spray into a metal container. Never press the bulb while applying the soldering iron to a solder joint or you'll spray the joint and nearby area with bits of solder that may cause short circuits. Finally, never reuse solder. Oxidation and loss of flux will almost certainly make a bad joint.




FIGURE 2-6. COMPONENT REMOVAL USING COMBINATION IRON AND SOLDER SUCKER




FIGURE 2-7. SPECIAL IRON TIP HEATS ALL IC PINS AT ONCE WHILE SPRING-LOADED REMOVAL TOOL LIFTS IC FROM BOARD

When isolating one part of an IC package, the recommended procedure is to cut the lead as close as possible to the board. Miniature cutters are recommended for this purpose. Bend the lead up, away from the board.




FIGURE 2-8. ISOLATING SINGLE PIN OF IC

To place the isolated section back in operation, bend the lead back down and solder in place. Use a thin 0.22-gauge 60/40 tin-lead solder. The thin gauge solder will melt and flow more freely thus requiring less application of heat.




FIGURE 2-9. MAIN POWER SUPPLY

MAIN POWER SUPPLY (See figures 2-9, 2-11)

The main power supply distributes unregulated +28 VDC and 28 VAC, and regulated -27 VDC and -7 VDC power to phonograph components. Power is controlled by a toggle switch located on the access door at the rear of the cabinet. 120-volt AC receptacles are provided for the amplifier, lights, accessories and service equipment. The AC receptacles and transformer primary are protected by 10 amp circuit breaker CB1, while circuit breaker CB2 protects the transformer primary only. Both the circuit breakers can be reset from the front panel.

The step-down transformer incorporates four secondary windings, each corresponding to one of the four output voltages (+28 VDC, 28 VAC, -27 VDC and -7 VDC). Each secondary passes directly to the phonograph harness. Three identical full wave bridge rectifiers convert the AC secondary voltage to DC charging filter capacitors C1004, C1005 and C1006.

Integrated circuit Z1001 provides voltage regulation for the -27 VDC circuit (top of schematic). The regulator drives transistor Q1006 which, in turn, drives Q1002 to supply the necessary current. If output current draw should become excessive, Q1007 is turned on. This removes the drive to Q1006, cutting current flow to protect the circuit.

The -7 VDC and +28 VDC supplies are unregulated, otherwise operation is similar to the -27 VDC circuit described previously. Transistors Q1005 and Q1009 provide overload protection. LED's indicate the presence of voltage.

SEQUENCE OF OPERATION


The sequence of operation diagrams which follow illustrate the circuits which are active during each point in the phonograph operational cycle.

Since the circuit chips are digital devices, the pins are at one of two states in each sequence diagram:

Q = Quiescent
A = Active

The voltage for each chip pin in both the Q and A states is listed on the schematic diagram and referenced in the text.


Most of the voltages indicated can be measured with an inexpensive VOM.



**FOR THIS SECTION, SELECT VIEW(TOP TOOL
BAR), THEN CLICK ON PAGE LAYOUT, THEN
FACING**

1 QUARTER INSERTED. STANDARD CREDIT ESTABLISHED.

THESE TWO LAMPS ARE ON ALL THE TIME TO LIGHT KEYBOARD.




1. QUARTER INSERTED. STANDARD CREDIT ESTABLISHED.

Credit computer pricing is set to one play for a quarter coin, standard price.

1. The quarter passes through the slug rejector operating the 25¢ coin switch lever to close the 25¢ coin switch.
2. The 25¢ coin switch connects pin 16 of the credit computer chip to COMMON through C612, R616 and R614.

3. Money pulses (-17vdc to 0vdc) are sent out chip to Q603 which drives the optional mo-


4. A standard credit signal (-27 vdc to 0 vdc) chip drives Q602 which lights the MAKE S. This signal also appears at pin 18 of the se-



EQUIVALENT ENGINEERING DRAWING 6-08600-01-Q-2 A

pin 39 of the credit computer
meter assembly; five pulses=25¢.


pin 2 of the credit computer
STANDARD SELECTION LED.
or ship.



2. HALF-DOLLAR INPUT

- If a half-dollar coin is detected, the credit computer chip to Q1-Q10.
- The MAKE STANDARD SELECTION sequence will repeat the previous sequence.

(2) HALF-DOLLAR INSERTED. PREMIUM CREDIT ESTABLISHED.




RTED. PREMIUM CREDIT ESTABLISHED.

sited, the 50¢ coin switch connects pin 17 of the IMON through R615, R616, and C612.

LECTION LED is lit in the same manner as the


3. A premium credit signal (-17 vdc to 0 vdc) at pin 4 of the credit computer chip drives Q601 which lights the MAKE ANY SELECTION LED. This pulse also appears at pin 22 of the selector chip.

3. CREDIT BUTTON PUSHED. CREDIT ESTABLISHED.




3. CREDIT BUTTON PUSHED. CREDIT ESTABLISHED.

1. Pressing manual credit pushbutton S601 on the credit computer simulates a 25¢ credit by connecting pin 16 of the credit computer chip to COMMON through diode CR604.
2. Money pulses (-17vdc to 0vdc) are tied to COMMON through R609, Q604 and R618 to prevent credit from registering on the optional money meter.
3. A standard credit signal (-17 vdc to 0 vdc) at pin 18 of the selector chip drives Q602 which lights the MAKE STANDARD SELECTION VIO. This signal also appears at pin 18 of the selector chip.



EQUIVALENT ENGINEERING DRAWING 6-08500-01-Q-2 A


the credit computer
SELECTED LED.



4. FIRST DIGIT SELECTED AND DISPLAYED.

Only the numbers 1 and 2 corresponding to the selection group right and left side can be chosen for the first digit. If another digit such as 0 or 3 through 9 is chosen, the RESET AND RESELECT LED will blink. In this instance, the RESET pushbutton must be pressed before making an alternate selection for the first digit.


Each of the three light emitting diodes are connected together electrically. Each pulse is synchronized with the third display to cause it to appear to be lit by the observer.



Number display units consist of seven segments illuminated by LEDs. The equivalent segments of the three display units are tied together and scanned left to right by pulses from the selector chip. This causes the appropriate segment in the first, second, and third display units to light the appropriate segment in the first, second, and third display units to produce the composite number image. The segments do this due to the high scan speed and the persistence of vision.

- The number 1 is chosen for the first digit by pressing the 1 pushbutton on the selector keyboard. This closes a circuit to pin 28 of the selector chip.
- A signal at pin 24 of the selector (-7 vdc to -1 vdc) chip drives Q516 which lights the YOUR SELECTION LED.
- The signal at selector chip pin 1 (-7vdc to -1vdc) drives Q504 and Q501 which codes the signal for the first display unit.
- Signals (-7vdc to -1vdc) at pins 6 and 7 of the selector chip drive Q512 and Q513 respectively, lighting the B and C segments of the first display unit during the scan to produce the number 1.

5) SECOND DIGIT SELECTED AND DISPLAYED.




5. SECOND DIGIT SELECTED AND DISPLAYED.

The second digit chosen can be any number, 0 through 9 corresponding to the second number of the available record selections.

1. The number 2 is chosen for the second digit by pressing the corresponding pushbutton of the selector keyboard.
2. The signal (-7vdc to -1vdc) at selector chip pin 2 drives Q505 and Q502 which codes the signal for the second digit.

3. Signals (-7vdc to -1vdc) at pins 5, 6, 11, 9 and Q511, Q512, Q510, Q508 and Q507 respectively D segments of the second display unit during the


NOTE: If one or more of the premium price switches the second digit represented by those switches will minimum selection is attempted, premium credit may not be available, the RESET AND RESELECT further selection digits will be accepted. In this it must be pressed and the entire selection must be repeated.



EQUIVALENT ENGINEERING DRAWING 6-08500-01-Q-2 A

of the selector chip drive
igniting the A, B, G, E and
to produce the number 2.

S501-1 to S501-4) is closed
premium priced. If a pre-
be available. If premium
lamps will flash and no
nce, RESET button must




As was the case with selecting the second digit in the previous sequence, the third digit chosen can also be 0 through 9.

1. The number 3 is chosen for the third digit by pressing the corresponding push-button on the selector keyboard.
2. The signal (-7vdc to 0vdc) at selector chip pin 3 drives Q506 and Q503 which codes the signal for the third digit.

3. Signals (-7vdc to 0vdc) from Q512, Q513, and Q514 are transmitted to the memory unit.
4. After the transmission, the selector chip pin 3 goes high (+1vdc).

6 THIRD DIGIT SELECTED AND DISPLAYED. CREDIT CANCELLED, SELECTION TRANSMITTED TO MEMORY




6. THIRD DIGIT SELECTED AND DISPLAYED. CREDIT CANCELLED, SELECTION TRANSMITTED TO MEMORY UNIT

5. Clock pulses (-17vdc to 0vdc) transmitted from pin 25 of the selector chip synchronize the selection data on pin 26.
6. The selection computer, connected across the clock and data lines, detects the data pulse train. It recognizes a selection sequence and enters the selection in its memory.
7. When the selection cycle is completed, a credit cancel signal (-17vdc to 0vdc) is sent to the credit computer from pin 20 of the selector chip and credit is erased.

0 -1vdc) at pins 5, 6, 11, 7 and 8 of the selector chip drive Q511, Q512 and Q507 respectively, lighting the A, B, G, C and D segment display unit during the scan to produce the number 3.

digit has been selected, the coded selection information (data) from pin 26 of the selector chip (-17vdc to 0vdc) to the memory is stored.

7) SELECTION DATA STORED IN MEMORY UNIT. SCAN SIGNAL ENERGIZES DETENT COIL AND MAGAZINE



7. SELECTION DATA STORED IN MEMORY UNIT, SCAN SIGNAL ENERGIZES DETENT COIL AND AMPLIFIER MUTED.

1. The selection data and clock signals arrive at memory unit chip pins 4 and 22, lighting LED's CR716 (clock) and CR715 (data). These LED's will begin flashing when a selection is made and will continue to flash until the mechanism scans out.

2. The scan signal (-7 vdc to -1 vdc) on pin 12 of the memory chip drives Q713, Q808 and Q803 lighting SCAN LED CR814 and connecting 28 vdc to COMMON through the magazine detent coil.

2-12

3. The energized magazine detent coil operates the contacts of the magazine detent switch.


4. Triac Q801 connects 28vac to COMMON through the magazine motor. The magazine motor is energized.

5. The amplifier mute relay is energized by COMMON.

E MOTOR, AMPLIFIER MUTED.

CR813 ON FOR TOGGLE SHIFT COIL (RIGHT SIDE OF RECORD).
 CR814 ON DURING SCAN AND TRANSFER CYCLE.
 CR815 ON DURING FIRST HALF OF TRANSFER CYCLE.

MECH. CONTROL 401-06905




EQUIVALENT ENGINEERING DRAWING 6-08500-01-Q-2 A

MAGAZINE MOTOR.

mechanical linkage which transmits turning on triac Q801.

through the service switch and maga-


zine motor



8. MAGAZINE R

- The magazine motor is controlled by the record change switch. It rotates the magazine on one side to bring the correct record positions. The motor is controlled by the Z704 module.

ATES. ENCODER SIGNAL SCANS MEMORY. ENCODER SIGNALS SENT TO SELECTOR. AMPLIFIER MUTED.



EQUIVALENT ENGINEERING DRAWING 6-08500-DI-Q-2 A


ATES. ENCODER SIGNALS SCAN MEMORY, ENCODER SIGNALS SENT TO SELECTOR. AMPLIFIER MUTED.

drives an encoder commutator disc on the right side of mechanism. The disc has a binary coded printed circuit

The circuit segments correspond directly to the 100 disc is mechanically synchronized with the record maga-


2. Stationary wipers in the encoder assembly contact the circuits on the encoder disc.
3. Encoder signals are transmitted from the memory chip to the selector logic module on the data and clock lines.


9 RECORD PLAYING (OR SCAN) DISPLAYED.



9. RECORD PLAYING (OR SCAN) DISPLAYED.

1. A signal (-7 vdc to -1 vdc) at pin 14 of the selector chip drives Q518 which lights the RECORD PLAYING LED. The YOUR SELECTION LED goes out.
2. If the phonograph is playing a selection, the selection number will be shown on the display. If the mechanism is scanning when the RECORD PLAYING lamp comes on, the scan will be displayed.






10. SELECTION LOCATED.

- When the selection is located in the memory chip, the voltage at pin 10 changes from -7 vdc to 0 vdc. This transfer signal turns on Q710 which drives Q809, Q802 and Q804, lighting START TRANSFER LED CR815.
- Q804 turns on Q805 and drives an AC switch consisting of CR806 through CR809. The switch drives triac Q810 which completes a circuit to energize the transfer motor. TRANSFER MOTOR LED CR817 goes out.

3. Q8
det
ren
4. Th
sh
beg
gin
driv
shi




EQUIVALENT ENGINEERING DRAWING 6-08500 01-Q-2

simultaneously turns off Q803. This opens the circuit to the magazine coil. The magazine detent coil transfers the magazine detent switch power from the magazine motor.

Transfer signal at pin 10 also drives Q711 and Q807. This lights toggle LED CR813 and energizes the toggle shift coil if the selection number with the number 2 (right side selection). If the selection number beneath the number 1 (left side), a signal on pin 11 of the memory chip will Q712 which will short the drive to Q711 to -7 vdc to disable the toggle circuit.

5. The play counter is energized by Q809.
6. The selection is erased in the memory chip.

(11) TRANSFER BEGINS.




11 TRANSFER BEGINS

- A cam operated by the transfer motor operates cam switches CS1, CS2, CS4 and CS5.
- As the transfer motor and cam rotate, cam switch CS1 transfers, applying power to the turntable motor.
- Cam switch CS2 transfers locking the transfer

CR813 ON FOR TOGGLE SHIFT COIL (RIGHT SIDE OF RECORD I).
 CR814 ON DURING SCAN AND TRANSFER CYCLE.
 CR815 ON DURING FIRST HALF OF TRANSFER CYCLE.

MECH. CONTROL 401-06905



EQUIVALENT ENGINEERING DRAWING 6-06500-01-Q-2 A

uit on.

2704 PIN VOLTAGES

1. POWER DN, S702 OFF = -17 VDC
POWER ON, S702 OFF = -11 VDC
S702 ON = +1 VDC

2. -17 VDC
S702 ON = +1 VDC

3. Q1 = -17 VDC
A = PULSES TD 0 VDC

4. Q2 = 0 VDC
A = PULSES TD -17 VDC

5. Q3 = 0 VDC
A = 0 V

6. Q4 = 0 VDC
A = 0 V

7. Q5 = -17 VDC
A = 10 PULSES TD 0 VDC

8. 0 V

9. Q6 = -17 VDC
A = 0 TO -2 VDC

10, 11, 12. Q7 = -7 VDC
A = 0 TO -1 VDC

13-21. Q8 = -7 VDC
A = 0 TO -1 VDC

22. Q9 = 0 VDC
A = PULSES TD -17 VDC

23. POWER DN = -16 VDC
BATTERY ON = +11 VDC

24. -5 VDC

J704 P704
-7 VDC
-27 VDC
-17 VDC
Y
KEY
CLOCK
DATA
LOG. COM.
W704


99
1 1
2 2
3 3
4 4
5 5
6 6
7 7
8 8
9 9
KEY

MEMORY UNIT 301-07855

COLOR CODE:
IN ALL TWO COLOR WIRES THE FIRST COLOR IS THE BASIC COLOR OF THE WIRE AND THE SECOND COLOR IS THE STRIPE OR HASH MARK.
EXAMPLE: WTR IS WHITE WIRE WITH RED MARKING.

B BLACK	BL BLUE
BR BROWN	V VIOLET
R RED	S SLATE
O ORANGE	W WHITE
Y YELLOW	PK PINK
G GREEN	TAN TAN


VOLTAGES AND WAVE SHAPES ARE APPROXIMATE AND VARIATIONS ARE TO BE EXPECTED



12. RECORD PL

1. CS4 transfers, bre
2. CS5 transfers, ope dition CS5 connec transfer signal on

(12) RECORD PLACED ON TURNTABLE. TONE ARM SET DOWN.



CED ON TURNTABLE. TONE ARM SET DOWN.


ing the holding circuit to Q806.

g the circuit to the transfer motor and mute relay. In addition, pin 9 of the memory chip to COMMON which cancels the 10.

3. TRANSFER MOTOR LED CR817 lights and START TRANSFER LED CR815 goes out.

4. The record plays.

13 RECORD ENDS.




13. RECORD ENDS

- As the tone arm tracks into the cutoff groove of the record, a magnet on the underside of the tone arm operates the tone arm cutoff reed switch. The mute relay is energized.
- The tone arm cutoff switch also provides a circuit to COMMON through cam switch CS2 to switch on Q804. Q804 drives the transfer motor circuit.
- The record gripper arm picks up the record CS4 transfers back and locks the transfer circuit.
- Cam Switch CS5 transfers back, insuring

CR813 ON FOR TOGGLE SHIFT COIL (RIGHT SIDE OF RECORD).
 CR814 ON DURING SCAN AND TRANSFER CYCLE.
 CR815 ON DURING FIRST HALF OF TRANSFER CYCLE.

MECH. CONTROL 401-06905




EQUIVALENT ENGINEERING DRAWING 6-08500-01-Q-2 A

from the turntable. Cam switch
is on through Q806.

continuation of transfer function.

Z704 PIN VOLTAGES

1. POWER ON, Z702 OFF: -17 VDC
POWER OFF, Z702 ON: +11 VDC
Z702 ON: +1 VDC
2. -17 VDC
Z702 ON: +1 VDC
3. 0 + -17 VDC
A: PULSES TO 0 VDC
4. 0 + 0 VDC
A: PULSES TO -17 VDC
5. -0V
-5V
-12V
6. -0V
-12V
7. Q: -17 VDC
A: 10 PULSES TO 0 VDC
8. 0V
9. Q: -17 VDC
A: 0 TO -2 VDC
- 10, 11, 12. Q: -7 VDC
A: D TO -1 VDC
- 13-21. 0 + -17 VDC
A: 0 TO -1 VDC
22. 0 + 0 VDC
A: PULSES TO -17 VDC
23. POWER ON: -16 VDC
BATTERY ON: +11 VDC
24. -5 VDC



COLOR CODE:


In all two color wires, the first color is the basic color of the wire and the second color is the stripe or hash mark.
EXAMPLE: W/B is white wire with red marking.

B BLACK	BL BLUE
BR BROWN	V VIOLET
R RED	S SLATE
O ORANGE	W WHITE
Y YELLOW	P PINK
G GREEN	TAN TAN


AMPLIFIER MUTE PLUG

Q	QUIESCENT
A	ACTIVE
—	LOGIC COMMON
—	POWER COMMON
—	CHASSIS COMMON
%	OPTIONAL KIT
○	TERMINAL STRIPS

VOLTAGES AND WAVE SHAPES ARE APPROXIMATE AND VARIATIONS ARE TO BE EXPECTED




(14) RECORD RETURNED TO MAGAZINE. MECHANISM SCANS OUT.



14. RECORD RETURNED TO MAGAZINE. MECHANISM SCANS OUT.

1. Cam switch CS2 transfers, opening the transfer circuit and energizing the scan circuit.
2. The magazine rotates one to one-and-a-half turns and the memory is searched for additional selections.
3. If there are no selections stored in the memory chip, the voltage on pin 12 of the memory chip drops to -7vdc from 0vdc and the scan, data and clock circuits are deenergized.

15 AUTO PLAY.




15. AUTOPLAY

- Z701-1 and its associated resistors and capacitors form an oscillator which has a period of about 40 seconds (oscillator 1). Z701-2 similarly is an oscillator with a period of about 8 seconds (oscillator 2). The two oscillators are not related to each other in either phase or frequency.
- Oscillator 1 drives the clock input of seven stage counter Z703. The reset, R, holds the counter at zero. When the reset is released, each oscillator cycle increases the count by 1. Oscillator 2 drives the set input of a flip-flop formed by Z701-3, -4. The reset or the output of Z703 selected by switch S701 holds the flip flop off.
- When switch S701 is in the OFF position, both oscillators will run, but the switch has the output line of the autoplay circuit tied to -17 volts. This prevents the autoplay circuit from affecting phono operation.

- When switch S701 is in the OFF position, both oscillators will run, but the switch has the output line of the autoplay circuit tied to -17 volts. This prevents the autoplay circuit from affecting phono operation.
- After the Z701-3, -4 flip-flop. The output line of the flip-flop goes to the set input of a flip-flop formed by Z701-3, -4. The reset or the output of Z703 selected by switch S701 holds the flip flop off.
- With switch S701 in the OFF position, both oscillators will run, but the switch has the output line of the autoplay circuit tied to -17 volts. This prevents the autoplay circuit from affecting phono operation.
- Selections made during an auto play sequence are stored in the Z704 MOS MEMORY MODULE H-7407A.

CR815 ON FOR TOGGLE SHIFT COIL (RIGHT SIDE OF RECORD).
 CR814 ON DURING SCAN AND TRANSFER CYCLE.
 CR815 ON DURING FIRST HALF OF TRANSFER CYCLE.



In the CONT position, the reset is released from the autoplay circuit when CSS transfers as the record begins. At the next negative transition of oscillator signal, Pin 12 (Q1) of Z703 will switch from -17 volts to +17 volts. The timing of the oscillator is random, this signal may occur at any time from zero to about 40 seconds after CSS begins. The magazine may, or may not, scan out before the signal occurs. The signal pulses Pin 9 of Z704 through capacitor C712 so that it will continue as long as needed for autoplay.

Once the reset has occurred as described, the next negative pulse from oscillator 2 signal at Pin 2 of Z701 will set the flip flop. The flip flop drives both the transfer and toggle circuits through diode CR709. The record selected depends on the start of the scan and the start of the transfer. This time will vary from zero to the full period of oscillator 2 (1.2 seconds). If switch S701 is in the 20 position, counter Z703 must count 32 cycles of oscillator 1 before scan is begun.

If the 40 position, 64 cycles are required before the scan is started. In any case, if a record is played, which starts the transfer, the entire circuit is reset and the time required to start autoplay selection must begin from zero.

Customers from the selector keyboard will play normally without interference from autoplay. However, if in T mode, an autoplay selection may be played before the chosen selection.

REF. DESIGNATION	DESCRIPTION	ROWE PART NO.
	MODEL R-83 PHONOGRAPH	(Page 1 of 2)
	Selector Keyboard, Digital Display, Selection Lamps (See Parts Catalog for Parts List)	
	Coin Switches (See Parts Catalog)	
Credit Computer Assembly	601-07674	
	Credit Computer Cover with Lettering	301-07637
	Credit Computer Base	301-07624
	Insulation Pad	201-17710
	Insulated Base	201-17711
	Credit Computer Circuit Board Assembly	601-07670
	Consisting of:	
C601	35 MFD Electrolytic Capacitor, 50V (Motorola TT; Sprague 30D; G.E. 78F, 76F)	708-00235
C602	0.047 MFD Mylar Capacitor, 100V (Paktron FM720; Amperex C280; Electromotive P94731-1)	708-00240
or	0.1 MFD Mylar Capacitor, 100V (Paktron FM720; Sprague 225P; Electromotive P91041-1)	702-00240
or	0.068 MFD Mylar Capacitor, 100V (Paktron FM720; Sprague 225P; Electromotive P96831-1)	714-00240
or	0.022 MFD Mylar Capacitor, 100V	704-00240
or	0.033 MFD Mylar Capacitor, 100V	710-00240
or	0.01 MFD Mylar Capacitor	707-00240
	One of the above selected to meet oscillator frequency operation	
C603	0.01 MFD Ceramic Disc Capacitor, 100V	721-00224
C612	35 MFD Electrolytic Capacitor, 50V (Same as C601)	708-00235
C613,C614	001 MFD Ceramic Disc Capacitor, 100V	721-00224
CR601,CR602	Silicon Diode	707-00350
CR604,CR605	Silicon Diode (Same as CR601)	707-00350
Q601, Q602	Darlington Amp Transistor (Motorola 2N654B; Nat'l. Semi-Cond. NSD-U45)	708-00302
Q603, Q604	NPN Silicon Transistor (Motorola, Fairchild, National Semiconductors MPS-A06)	708-00300
R601,R602	1/4 W Carbon Resistor, 1K	7-9901-10
R603,R604	1/4 W Carbon Resistor, 27K	7-9901-27
R605	1/4 W Carbon Resistor, 2.2K	7-9901-22
R606	1/2 W Trimmer Potentiometer, 50K (Bourns 3389; CTS-362Y; Weston 840P)	202-15207
R608	1/4 W Carbon Resistor ,1K	7-9901-10
R609	1/4 W Carbon Resistor, 5.6K	7-9901-56
R610,R611	1/4 W Carbon Resistor, 220 Ohms	7-9901-22
R612toR615	1/4 W Carbon Resistor, 1K	7-9901-10
R616	1/4 W Carbon Resistor, 390K	7-9901-39
R617	1/4 W Carbon Resistor, 1K	7-9901-10
R618	1/4 W Carbon Resistor, 56K	7-9901-56
R619	1/4 W Carbon Resistor, 8.2K	7-9901-82
S601	SPST Pushbutton Switch (Oak Industries Series 415)	201-17733
S602,S603	9 Init DIP Switch (Amp 435166-6; Molex 01-07-0109; CTS 206-9)	701-00430
W601,W604	Wire Jumper	Spec 5039
Z601	MOS Credit Accumulator	302-0420
P601-18	2 Circuit Polarizing Wafer Assembly	702-00750
P601-1	14 Circuit Polarizing Wafer Assembly	714-00750
	Credit Computer Printed Wiring Board	601-07671
	DIGITAL DISPLAY AND HARNESS ASSEMBLY	401-07130
CR1toCR5	Light Emitting Diode(Nat'l.Semicond. NSL5056; Texas Instr. TIL220;Fairchild FLV117,FLV110)	703-000
R1 to R5	1/4W Carbon Resistor, 270 Ohms	7-9901-27
W1 to W7	Wire Jumper	Spec 5039
Z1 TO Z3	L.E.D. Display(Texas Instr. TIL312;Nat'l.Semicond. NSN71L;Monsanto MAN72)	201-17661
J501	12 Circuit Connector Housing (To Selector Logic)	712-00751
J505	6 Circuit Connector Housing (TO Selector Logic)	706-00751
	3 Circuit Universal Connector Plug Housing (To Selector Lights)	301-07491
	Incandescent Lamp Socket (2) (Display Lamps)	200-12781
	Wire Tie	701-0880
	Digital Display Printed Circuit Board	401-07130

REF. DESIGNATION	DESCRIPTION	ROWE PART NO.
Selector Logic Assembly	601-08060	
	Selector Cover with Lettering	301-07636
	Selector Logic Base	301-07625
	Insulation Pad	202-17710
	Insulated Base	202-17711
	Selector Logic Circuit Board Assembly	601-07655
	Consisting of:	
C501	Variable Capacitor, 5.1 to 50 pFD, 250V (JFD Electr. PVJ305A; Sprague-Goodman GKB50000; Johanson Mfg. 9305)	701-00260
C502 to C504	0.01 MFD Ceramic Disc Capacitor, 100V	721-00224
C505	35 MFD Electrolytic Capacitor, 50V (Motorola TT; Sprague 30D; G.E. 78F, 76F)	708-00235
C506 to C516	0.01 MFD Ceramic Capacitor, 100V	721-00224
CR501 to CR506	Silicon Diode (Selected 1N914; 1N4448; 1N4148)	707-00350
Q501 to Q503	PNP Silicon Transistor (Motorola, Fairchild, National Semiconductors MPS-A56)	704-00301
Q504 to Q515	NPN Silicon Transistor (Motorola, Fairchild, National Semiconductors MPS-A06)	708-00300
Q516 to Q518	Darlington Amplifier Transistor (National NSDU45; G.E. D40K2)	708-00302
R501	1/4 W Carbon Resistor, 220 Ohms	7-9901-221
R502	1/4 W Carbon Resistor, 1K	7-9901-102
R503	1/4 W Carbon Resistor, 220 Ohms	7-9901-221
R504	1/4 W Carbon Resistor, 1K	7-9901-102
R505	1/4 W Carbon Resistor, 220 Ohms	7-9901-221
R506	1/4 W Carbon Resistor, 1K	7-9901-102
R507 to R513	1/4 W Carbon Resistor, 100 Ohms	7-9901-101
R514 to R523	1/4 W Carbon Resistor, 1.5K	7-9901-152
R524 to R527	1/4 W Carbon Resistor, 5.6K	7-9901-562
R528	1/4 W Carbon Resistor, 1.5K	7-9901-153
R529	1/4 W Carbon Resistor, 1K	7-9901-102
R530	1/4 W Carbon Resistor, 15K	7-9901-153
R531	1/4 W Carbon Resistor, 1K	7-9901-102
R532	1/4 W Carbon Resistor, 15K	7-9901-153
R533	1/4 W Carbon Resistor, 1K	7-9901-102
R536	1/4 W Carbon Resistor, 15K	7-9901-153
R537, 538	1/4W Carbon Resistor, 5.6K	7-9901-562
R539 to R541	1/4W Carbon Resistor, 100 OHMS	7-9901-101
S501	4Unit DIP Switch (Molex 01-07-0104; Amp 435166-2; CTS 206-4) (Optional)	702-00430
S502	3PDT Slide Switch (U.I.D. Electronics SW-032PX)	304-07623
W502 to W504	Wire Jumper	Spec5039
Z501	MOS Selector-Display Module (L.S.I. Computer System LSI2002A)	302-07427
P501-12 P502-1 P506-1	2 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1021)(5 required)	702-00750
P503	3 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1031)	703-00750
P502	5 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1051)	705-00750
P501	8 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1081)	708-00750
P506	10 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1101)	710-00750
	Selector Logic Printed Wiring Board	601-07653






FIGURE 2-10. R-83 PHONOGRAPH SCHEMATIC DIAGRAM (Page 1 of 2)



Z704 PIN VOLTAGES

1. POWER ON, S702 OFF - -17 VDC
- POWER OFF, S702 OFF - -11 VDC
- S702 ON - -1 VDC
2. -17 VDC
S702 ON - -1 VDC
3. 0 - -17 VDC
A = PULSES TO 0 VDC
4. Q = 0 VDC
A = PULSES TO -17 VDC
5. -5V
-5V
6. -12V
-12V
7. Q = -17 VDC
A = 10 PULSES TO 0 VDC
8. 0V
9. Q = -17 VDC
A = 0 TO -2 VDC
- 10, 11, 12. Q = -7 VDC
A = 0 TO -1 VDC
- 13-21. Q = -17 VDC
A = 0 TO -1 VDC
22. Q = 0 VDC
A = PULSES TO -17 VDC
23. POWER ON - -16 VDC
BATTERY ON - -11 VDC
24. -5 VDC



COLOR CODE:


IN ALL TWO COLOR WIRES THE FIRST COLOR IS THE BASIC COLOR OF THE WIRE AND THE SECOND COLOR IS THE STRIPE OR HASH MARK.
EXAMPLE: W/R IS WHITE WIRE WITH RED MARKING.

B	BLACK	BL	BLUE
BR	BROWN	V	VIOLET
R	RED	S	SLATE
O	ORANGE	W	WHITE
Y	YELLOW	PK	PINK
G	GREEN	TAN	TAN

AMPLIFIER MUTE PLUG

- Q QUIESCENT
- A ACTIVE
- ↓ LOGIC COMMON
- ± POWER COMMON
- ↔ CHASSIS COMMON
- * OPTIONAL KIT
- TERMINAL STRIPS

VOLTAGES AND WAVE SHAPES ARE APPROXIMATE AND VARIATIONS ARE TO BE EXPECTED



MAIN POWER SUPPLY

401-06894




FIGURE 2-10. R-83 PHONOGRAPH SCHEMATIC DIAGRAM (Page 2 of 2)

MODEL R-83 PHONOGRAPH**601-088-30**

(Page 2 of 2)

ROWE

PART NO.

OR	Harness and Console Assembly (See Figure 1 of Parts Catalog for Parts)	601-08571
	Main Power Supply, 120V (See Parts Catalog and Schematic for Parts List)	401-06894
	OR Main Power Supply, 220V (See Schematic for Parts List)	402-65079
	Record Changer Mechanism Assembly (See Parts Catalog for Parts List)	604-03065
	Encoder Assembly (See Parts Catalog for Parts List)	601-07667
	Memory Unit Assembly 601-07666	
	Cover with Lettering	301-07858
	Mounting Plate	401-07143
	Insulation Pad	203-17711
	Insulation Base	206-17710
	Battery Retaining Plate	201-17960
	Battery Assembly consisting of:	201-17740
	Rechargeable NICAD Battery Pack (Burgess 475SC; G.E. 41B905CD19-G1)	301-07631
	Harness with Connector	201-17675
	Connector	703-00755
	Memory Unit Circuit Board Assembly consisting of:	601-08584
C701, C702	0.1 MFD Ceramic Disc Capacitor, 100V	721-00224
C703, C704	22 MFD Low Leakage Electrolytic Capacitor, 35V	710-00238
C705	5.1 to 50 pFD Trimmer Capacitor (JFD PVJ305A; Sprague GK850000)	701-00260
C706,C707	0.0047 MFD Mylar Capacitor, 100V	716-00240
C708 to C711	22 MFD Electrolytic Capacitor, 25V	703-00280
C712	270 pFD Ceramic Disc Capacitor, 100V	708-00224
C713	0.01 MFD Ceramic Disc Capacitor, 100V	721-00224
C714	2.2 MFD Tantalum Capacitor, 35V	712-00251
C715 to C717	270 pFD Ceramic Disc Capacitor, 100V	708-00224
C718	2.2 MFD Tantalum Capacitor, 35V	712-00251
C719 to C727	0.01 MFD Ceramic Disc Capacitor, 100V	721-00224
CR701	Silicon Diode	707-00350
CR702 to CR705	Germanium Diode	701-00351
CR706 to CR712	Silicon Diode	707-00350
CR713	Zener Diode (1N4746A)	716-00355
CR714	Silicon Diode	707-00350
CR715 to CR717	Light Emitting Diode (TI TIL220; National NSL5056; Fairchild FLV110, FLV117)	703-00353
Q701	NPN Silicon Transistor (Motorola, Fairchild, National MPSA06; TI SKA-3368)	708-00300
Q702	PNP Silicon Transistor (Motorola, Fairchild, National MPS-A56)	704-00301
Q703	NPN Silicon Transistor (Same as Q701)	708-00300
Q704 to Q706	PNP Silicon Transistor (Same as Q702)	704-00301
Q707	PNP Silicon Transistor (Motorola, T.I.TIP32B; R.C.A.RCA32B; Fairchild 2N6126)	702-00304
Q708 to Q713	NPN Silicon Transistor (Same as Q701)	708-00300
R701, R702	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R703	1/4W Carbon Resistor, 470K, 5%	7-9901-474
R704 to R706	1/4W Carbon Resistor, 15K, 5%	7-9901-153
R707	1/4W Carbon Resistor, 1.2 Meg, 5%	7-9901-125
R708, R709	1/4W Carbon Resistor, 15K, 5%	7-9901-153
R710, R711	1/4W Carbon Resistor, 47K, 5%	7-9901-473
R712	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R713, R714	1/4W Carbon Resistor, 15K, 5%	7-9901-153
R715	1/4W Carbon Resistor, 47K, 5%	7-9901-473
R716	1/4W Carbon Resistor, 3.9K, 5%	7-9901-392
R717, R718	1/4W Carbon Resistor, 82K, 5%	7-9901-823
R719	1/4W Carbon Resistor, 3.9K, 5%	7-9901-392
R720	1/4W Carbon Resistor, 82K, 5%	7-9901-823
R721	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R722	1/4W Carbon Resistor, 10K, 5%	7-9901-103
R723	1/4W Carbon Resistor, 1K, 5%	7-9901-102
R724	1/4W Carbon Resistor, 8.2K, 5%	7-9901-822
R725	1/4W Carbon Resistor, 1K, 5%	7-9901-102
R726, R727	1/4W Carbon Resistor, 10K, 5%	7-9901-103
R728	1/2W Carbon Resistor, 68 Ohms	719-00102
R729	1/4W Carbon Resistor, 1.5K, 5%	7-9901-152
R730	1/4W Carbon Resistor, 2.7K, 5%	7-9901-272
R731 to R733	1/4W Carbon Resistor, 1.5K, 5%	7-9901-152
R734	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R735	1/4W Carbon Resistor, 56K, 5%	7-9901-563
R736	1/4W Carbon Resistor, 10K, 5%	7-9901-103

(Continued in next column)

REF. DESIGNATION	DESCRIPTION	ROWE PART NO.
Memory Unit Assembly (Continued)		
R737	1/4W Carbon Resistor, 56K, 5%	7-9901-563
R738	1/4W Carbon Resistor, 10K, 5%	7-9901-103
R739	1/2W Carbon Resistor, 1K	719-00106
R740, R741	1/4W Carbon Resistor, 100 Ohms, 5%	7-9901-101
R742 to R744	1W Carbon Resistor, 2.2K	721-00108
R745 to R748	1/4W Carbon Resistor, 27K, 5%	7-9901-273
R749	1/4W Carbon Resistor, 1K, 5%	7-9901-102
R750 to R753	1/4W Carbon Resistor, 8.2K, 5%	7-9901-822
R754 to R762	1/4W Carbon Resistor, 1K, 5%	7-9901-102
R763, R764	1/2W Carbon Resistor, 1K	719-00106
R765	1/2W Carbon Resistor, 1.5K	705-00104
S701	"Auto Play" 4 Position Double Pole Slide Switch (CW Ind. G141-L-3)	301-07862
S702	"Clear Memory" Pushbutton Switch (Oak Series 415)	201-17733
Z701	Quad Comparator I.C. (Nat'l LM3302N, LM339N; Fairchild MA3302P; Motorola MC3302P)	701-00368
Z702	I.C. Transistor Array (Fairchild CA3046; Sprague ULN2046A, ULN2086A; RCA CA3146AE, CA3146E, CA3046, CA3086)	301-08002
Z703	CMOS 7 Stage Binary Counter I.C. (RCA CD4024BP)	724-00340
Z704	MOS Memory Module I.C. (L.S.I. LSI2001A)	301-07407
	Two Pin Receptacle (Molex 09-60-1021)	702-00750
	Three Pin Receptacle (Molex 09-60-1031)	703-00750
	Four Pin Receptacle (Molex 09-60-1041)	704-00750
	Eight Pin Receptacle (Molex 09-60-1081)	708-00750
	Printed Circuit Board	601-08583
Mechanism Control Unit Assembly 401-06905		
	Mechanism Control Cover with Lettering	301-07639
	Circuit Board Support (2 Required)	706-05000
	Bearing	703-01460
	P.C. Board Mounting Bracket	301-07723
	Mechanism Control Circuit Board Assembly consisting of:	401-06900
C801, C802	0.01 MFD Ceramic Disc Capacitor, 100V	721-00224
CR801 to CR812	Silicon Diode (1N4002)	702-00350
CR813 to CR815,		
CR817	Light Emitting Diode (Hewlett-Packard 5082-488S; Nat'l Semiconductors NSL-5056)	703-00353
CR818, CR819	Silicon Diode (Same as CR801)	702-00350
Q801	Triac Thyristor (RCA T2801B, T2800B, T2500B; Texas Instr. TIC226B)	703-00381
Q802	NPN Silicon Transistor (Motorola, Fairchild, National Semiconductor MPS-A06)	708-00300
Q803	PNP Darlington Power Silicon Transistor (Texas Instr. TIP136; Motorola 2N6041)	701-00308
Q804	PNP Silicon Transistor (Motorola, Fairchild, National Semiconductor MPS-A56)	704-00301
Q805, Q806	NPN Silicon Transistor (Same as Q802)	708-00300
Q807 to Q809	PNP Darlington Power Silicon Transistor (Same as Q803)	701-00308
Q810	Triac Thyristor (Same as Q801)	703-00381
R801	1/4W Carbon Resistor, 18 Ohms, 5%	7-9901-180
R802	1/4W Carbon Resistor, 1K, 5%	7-9901-102
R803	1/4W Carbon Resistor, 390 Ohms, 5%	7-9901-391
R804	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R805	1/4W Carbon Resistor, 560 Ohms, 5%	7-9901-561
R806	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R807	1/4W Carbon Resistor, 100 Ohms, 5%	7-9901-101
R808, R809	1/2W Carbon Resistor, 1.5K	705-00104
R810	1/4W Carbon Resistor, 560 Ohms, 5%	7-9901-561
R811	1/4W Carbon Resistor, 27K, 5%	7-9901-273
R812	1/4W Carbon Resistor, 2.7K, 5%	7-9901-272
R813	1/4W Carbon Resistor, 1K, 5%	7-9901-102
R814	1/4W Carbon Resistor, 5.6K, 5%	7-9901-562
R815 to R817	1/4W Carbon Resistor, 1.5K, 5%	7-9901-152
R819	1/2W Carbon Resistor, 1.8K,	706-00104
W802 to W804, W806 to W808	Wire Jumper	Spec. 5039
	Memory Interconnect Harness Assembly	301-07550
P802	2 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1021)	702-00750
P801	4 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1041)	704-00750
P801-1	12 Circuit Polarizing Wafer Assembly (Molex Products 09-60-1121)	712-00750
	Triac Heat Sink	201-17829
	Rectangular Washer (2 Required)	201-17761
	Mica Washer (2 Required)	201-15208
	Mechanism Control Printed Circuit Wiring Board	401-06899

MAIN POWER SUPPLY (120V) 401-06894 (See also Figure 6 – Parts Catalog)
 MAIN POWER SUPPLY (220V) 402-65079 (See also Figure 6 – Parts Catalog)

	POWER SUPPLY CIRCUIT BOARD ASSEMBLY	401-06850	
C1001	0.1 MFD Mylar Capacitor, 100V (Paktion FM1100; Amperex C280, Electromotive P91041-1)	702-00240	
C1002	0.01 MFD Ceramic Disc Capacitor, 100V	721-00224	
C1003	0.1 MFD Mylar Capacitor, 100V (Same as C1001)	702-00240	
C1004	1250 MFD Electrolytic Capacitor, 50V (Sprague 43D; Mallory TCW)	710-00233	
C1005	200 MFD Electrolytic Capacitor, 75V (Collins ARD; Motorola TCW; Cornell Dubilier WBR)	704-00235	
C1006	3000 MFD Electrolytic Capacitor, 15V (Motorola TCW; Sprague 39D; Collins ARD)	711-00235	
C1007	270 pFD Ceramic Disc Capacitor, 100V	708-00224	

CR1001 to CR1006 Silicon Diode (1N4004) 704-00350
 CR1007 to CR1014 Silicon Diode (Same as CR1001) 702-00350

F1001	3 Amp Cartridge Fuse (Buss MDL)	722-00721
F1002	1 Amp Cartridge Fuse (Buss MDL)	705-00721
F1003	2.5 Amp Cartridge Fuse (Buss MDL)	725-00721

P1001 P.C. Board Header (6 circuit Universal Mate-N-Lok no. 350431-1) 304-07635

Q1001	Silicon Transistor, NPN (Motorola MJE5191; RCA No. RCA31A; Fairchild 2N6122)	705-00330
Q1002	Silicon Transistor, PNP (Motorola MJE5195; RCA No. RCA32B; Fairchild 2N6126)	702-00304
Q1003	Silicon Transistor, PNP (Motorola MJE5194; RCA No. RCA32A; Fairchild 2N6125)	701-00304
Q1004, Q1005	Silicon Transistor, NPN (Motorola, Fairchild, Nat'l. Semiconductor MPSA06)	708-00300
Q1006 to Q1009	Silicon Transistor, PNP (Motorola, Fairchild, Nat'l. Semiconductor MPSA56)	704-00301

R1001	2W Wirewound Resistor, 0.82 Ohm (I.R.C. Type BWH)	716-00113
R1002	1/4W Carbon Resistor, 3.3K	7-9901-332
R1003	1/4W Film Resistor, 390 Ohms \pm 2%	7-9902-391
R1004	1/4W Carbon Resistor, 3.3K	7-9901-332
R1005	1/4W Film Resistor, 4.7K \pm 2%	7-9902-472
R1006	1/2W Carbon Resistor, 3.3K	720-00107
R1007	2W Wirewound Resistor, 10 Ohms	704-00113
R1008	1/4W Carbon Resistor, 1.2K	7-9901-122
R1009	1/4W Carbon Resistor, 2.2K	7-9901-473
R1010	1/4W Carbon Resistor, 47K	7-9901-153
R1011	1/4W Carbon Resistor, 15K	714-00113
R1012	2W Wirewound Resistor, 0.47 Ohm (I.R.C. Type BWH)	7-9901-332
R1013	1/4W Carbon Resistor, 3.3K	7-9902-680
R1014	1/4W Film Resistor, 68 Ohms \pm 2%	7-9901-332
R1015	1/4W Carbon Resistor, 3.3K	719-00107
R1016	1/2W Carbon Resistor, 330 Ohms	7-9902-561
R1017	1/4W Film Resistor, 560 Ohms \pm 2%	7-9902-273
R1018	1/4W Fixed Film Resistor, 27K \pm 2%	702-00122
R1019	1/4W Fixed Film Resistor, 4.22K \pm 2% (R-Ohm Corp.; TRW Electronics; Dale Electronics)	7-9902-153
R1020, R1021	1/4W Fixed Film Resistor, 15K \pm 2%	7-9901-102
R1022	1/4W Carbon Resistor, 1K	000-05039
W1001, W1002	Bare Wire	

Z1001 Linear I.C. Voltage Regulator (Teledyne 723CJ, 723CL; Fairchild u9A7723393; u6A7723393; National Semiconductor LM723CN, LM723CD; Signetics ua723CA, N5723A) 703-00365

Heat Sink Bracket	301-07630
Mica Washer (RCA DF103B; Thermalloy 43-77-8) (3 Required)	201-15208
Triangular Washer (ESNA 22-NM-62) (3 Required)	201-17761
Cable Tie (6 Required)	706-08001
Fuse Clip (6 Required)	200-50755
Power Supply Circuit Board	601-07686

VOLTAGE INDICATOR (L.E.D.) CIRCUIT BOARD ASSEMBLY 401-06960

CR1101 Silicon Diode (Selected 1N914B; 1N4448; 1N4148) 707-00350
 CR1102 to CR1105 Light Emitting Diode (Texas Instr.TIL-220; Nat'l. Semi-Cond. NSL-5056 Hewlett Packard 5082-488D) 703-00353

R1101 to R1103 1/4W Carbon Resistor, 2.7K 7-9900-272
 R1104 1/4W Carbon Resistor, 560 Ohms 7-9900-561

L.E.D. Circuit Board 401-06959






FIGURE 2-11.

MAIN POWER SUPPLY SCHEMATIC DIAGRAM



2-26 FIGURE 2-12. PHONOGRAPH HARNESS WIRING DIAGRAM






FIGURE 2-13. SELECTION COMPUTER "MEMOREC"
SCHEMATIC DIAGRAM

Selection Computer Assembly

401-07139

Cover with Lettering	301-07860
Display Window Light Filter	204-17819
Mounting Plate	301-07861
Insulation Pad	207-17710
Insulation Base	204-17711
Selection Computer Circuit Board consisting of:	601-07434
BT1401 Battery Assembly	201-17965
Rechargeable NICAD Battery Pack (Saft Storage Battery Div. 2VRO.5AA)	302-07631
3 Pin MATE-N-LOK Receptacle (Amphenol 1-480304-1)	201-12444
C1401 2.2 MFD Tantalum Capacitor, 20V	707-00251
C1402,C1403 470 pFD Ceramic Disc Capacitor, 100V	701-00224
C1404 2.2 MFD Tantalum Capacitor, 20V	707-00251
CR1401,CR1402 Silicon Diode	707-00350
CR1403 Zener Diode, 15V -1% (1N965B)	722-00355
CR1404 Zener Diode, 5.1V -5% (1N4733A)	701-00355
CR1405 Silicon Diode	707-00350
Q1401 NPN Silicon Transistor (National, Fairchild, Motorola MPS-A06; T.I. SKA-3368)	708-00300
R1401 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1402 1W Carbon Resistor, 100 Ohms	704-00103
R1403 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1404 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1405 Trimmer Potentiometer, 50K (Bourns 3389; Weston 840P; CTS 362Y)	202-15207
R1406 1/4W Carbon Resistor, 27K, 5%	7-9901-273
R1407 1/4W Carbon Resistor, 8.2K, 5%	7-9901-822
R1408 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1409 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1410 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1411 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1412 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1413 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1414 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1415 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1416 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1417 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1418 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1419 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1420 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1421 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1422 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1423 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1424 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1425 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1426 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1427 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1428 1/4W Carbon Resistor, 470K, 5%	7-9901-474
R1429 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1430 2 W Carbon Resistor, 200 Ohms	723-00105
R1431,R1432 1/4W Carbon Resistor, 8.2K, 5%	7-9901-822
R1433 2W Carbon Resistor, 390 Ohms	703-00126
R1434 1/4W Carbon Resistor, 8.2K, 5%	7-9901-822
R1435 1/4W Carbon Resistor, 680 Ohms, 5%	7-9901-681
R1436 1/4W Carbon Resistor, 220 Ohms, 5%	7-9901-221
R1437,R1438 1/4W Carbon Resistor, 100K, 5%	7-9901-104
R1440 1/4W Carbon Resistor, 220 Ohms, 5%	7-9901-221
S1401 "RESET" Pushbutton Switch (Oak Series 415)	201-17733
S1402 "MOST POPULAR/LEAST POPULAR" DPDT Slide Switch (U.I.D. Elect. SW622-P-8K-T6)	305-07623
S1403 "ADVANCE" Pushbutton Switch (Oak Series 415)	201-17733
Z1401 Vacuum Fluorescent Display (Futuba 4-BT-03; Nippon Electric LD8165)	201-15395
Z1402 Micro Computer (Rockwell MM75)	701-00364
Z1403 CMOS Memory, 256K X 4 RAM	701-00366
P1401 Two Pin Receptacle (Molex 09-60-1021)	702-00750
Three Pin Receptacle (Molex 09-60-1031)	703-00750
Battery Harness consisting of:	201-17964
Pin Housing (Amphenol 1-480319-0)	206-12445
Display Retainer	201-17954
Printed Circuit Board	601-07433

SELECTION COMPUTER ELECTRONIC PARTS LIST