



# Service & Parts Manual

Rock-Ola *Nostalgic* Jukeboxes

CD-4 *Gazelle*



CD-8 *Bubblers*



CD-6 *Peacock*



# Table of Contents

---

## Section A Jukebox Specifications

## Section B Set-up and Preparation

Major Component Location .....	B - 2
Unpacking the Phonograph .....	B - 3
Power Up .....	B - 3
Loading Program Pages .....	B - 4
Loading Compact Discs .....	B - 5
Repacking/Moving .....	B - 5

## Section C Connecting Speakers, Telephone Adaptor Kit, I.R. Remote Detector and Paging Microphone

External Speaker Connections .....	C - 2
Speaker Loading .....	C - 2
Connection Examples .....	C - 3
Installation of the Telephone Adaptor Kit for Removable Volume Control .....	C - 6
Installation of the I.R. Remote Detector and Harness Assembly .....	C - 7
Connecting A Paging Microphone .....	C - 8

## Section D Amplifier Description and Operation

Amplifier Description .....	D - 2
Indicator LED's .....	D - 3
Signal Inputs and Outputs .....	D - 3
Amplifier Feature Description .....	D - 4
Setting The Amplifier .....	D - 4

## Section E Operation and Programming Overview

Normal Operation .....	E - 2
Control Computer Buttons .....	E - 3
Programming, Service and Diagnostics Features Overview	
Suspend Mode .....	E - 4
Service Mode .....	E - 4
Setup Mode .....	E - 5
Diagnostic and Error Reporting Features .....	E - 6
Quick Find Reference Programming Chart .....	E - 7

### Quick Find Reference Programming Definitions

Disc Mapping .....	E - 8
Page Options .....	E - 8
Play Options .....	E - 9
Auto Play .....	E - 9
Free Play .....	E - 10
Pricing .....	E - 11
Set-up 1 .....	E - 12
Set-up 2 .....	E - 13
Set-up 3 .....	E - 14

Accounting .....	E - 14
Popularity .....	E - 15
Disc Errors .....	E - 15
Remote Control .....	E - 16
Test Mode .....	E - 16
Auto test .....	E - 18
TCM Setup .....	E - 18
Amp Setup .....	E - 21

#### Quick Find Reference Programming Flow Charts

Set up Mode Flow Chart .....	E - 23
Disc Mapping .....	E - 24
Page Options .....	E - 26
Play Options .....	E - 27
Auto Play .....	E - 28
Free Play .....	E - 33
Pricing .....	E - 36
Set-up 1 .....	E - 38
Set-up 2 .....	E - 41
Set-up 3 .....	E - 43
Accounting .....	E - 44
Popularity .....	E - 48
Disc Errors .....	E - 49
Remote Control .....	E - 51
Test Mode .....	E - 54
Auto test .....	E - 59
TCM Setup .....	E - 61
Amp Setup .....	E - 65

## Section F

### Routine Service

Accounting .....	F - 2
Popularity .....	F - 4
Disc Changing .....	F - 5
Appearance and Preventative Maintenance .....	F - 5
Checking For Errors .....	F - 6

## Section G

### Maintenance

Maintenance .....	G - 2
General Maintenance Considerations .....	G - 2
Preventative Maintenance .....	G - 2
Mechanical Adjustments	
Magazine Adjustments .....	G - 4
CD Player Adjustments .....	G - 5
Title Page Adjustments .....	G - 6
Coin Mechanism Cleaning .....	G - 6
Replacing Fluorescent Lamps .....	G - 6

## Section H

### Troubleshooting and Repair

Troubleshooting and Repair Overview .....	H - 2
Troubleshooting Charts	
Power and Start up Problems .....	H - 3
Credit Problems .....	H - 4

Play Problems.....	H - 4
Page Problems .....	H - 5
Fuse and LED Locations	
Power Supply Fuses.....	H - 6
Keyboard LEDs.....	H - 6
Digital Amplifier & Power Supply LEDs & Connections.....	H - 6
Block Diagrams	
Amplifier Block Diagram .....	H - 7
CPU Block Diagram.....	H - 8
CD Player Start-Up and Run Diagram .....	H - 9
Power Distribution Block Diagram .....	H - 10
Start up and Diagnostic Mode Operation.....	H - 11
Test Mode .....	H - 12
Viewing Error Codes .....	H - 12
Using Error Codes	
CPU (Input) Error Codes .....	H - 13
Keyboard Error Codes.....	H - 14
Mechanism Error Codes.....	H - 15
Page Unit Error Codes .....	H - 15
Running Tests	
CPU Tests .....	H - 16
Keyboard Test .....	H - 18
Display Test.....	H - 18
Pages Test.....	H - 19
Mechanism Tests.....	H - 19
Amplifier Troubleshooting .....	H - 21

## Section I

### Major Component Schematics

CPU .....	I - 2
Amplifier/Power Supply .....	I - 8
Audio Output Panel .....	I - 20
Keyboard/Display .....	I - 21
Removable Volume Control .....	I - 23
Crossover .....	I - 24
Transformer .....	I - 25
Lighting Wiring Diagram.....	I - 26
Primary Power Block Diagram .....	I - 27

## Section J

### Common Accessories (optional)

## Section K

### Parts Catalog