



No. 33319-A STEREO AMPLIFIER (Less Tubes)

ITEM	PART NO.	PART NAME	ITEM	PART NO.	PART NAME
1	33227	Output Transformer	18	32489	Hum Control
2	33227	Output Transformer	19	32824	Grounded Can Doubler Capacitor <i>200 uf/300V</i>
3	33217	180 Ohm 10 W. Resistor	20	ST-4332	1 Amp. Slo-Blo Fuse
4	33229	6973 Tube	21	33229	6973 Tube
5	33229	6973 Tube	22	11578	Pointer Knob
6	16810	4 Prong Miniature Socket	23	32853	6AN8 Tube
7	32853	6AN8 Tube	24	33229	6973 Tube
8	18634	6 Prong Miniature Socket	25	33232	Speaker Terminal Strip
9	32498	6CY7 Tube	26	33216	1820 Ohm 15 W. Resistor
10	33245	Balance Control	27	PH-3722	4 Prong Socket
11	32498	6CY7 Tube	28	33218	7800 Ohm 15 W. Resistor
12	33207	Tube Shield	29	33280	Output Plug (Red)
13	15155	12AU7 Tube	30	33278	Output Plug (Black)
14	33199	Dual Input Socket			
15	11578	Pointer Knob			
16	33246	17 Ohm Candohm Resistor			
17	30316	4 Section Filter Capacitor			

20-20-20-20/475