


CD-100C

LaserStar® II ***Compact Disc*** ***Phonograph***

Field Service Manual
And Parts Catalog

Volume 1



ROWE INTERNATIONAL, INC.

1500 UNION AVE, SE • GRAND RAPIDS, MI 49507-1884
(616) 243-3633

Printed in USA

Part No. 21822620
Second Edition
First Printing July 1992

This page intentionally left blank

Preface

To make installation easier, this manual describes a typical installation. This "typical" installation only includes loading the title rack and discs, setting up the sound system, and in some situations, modifying the pricing.

If you wish to make further programming changes, make them using the information that follows the basic installation.

This manual is split into two parts. The split is between Sections 3 and 4. The first half, Volume 1, contains routine installation and service information. The second half, Volume 2, contains troubleshooting charts, schematics, and other maintenance information. Please take time to read this page and review the *Table of Contents* in both volumes.

The *Troubleshooting* section has been expanded to include schematics, component lists, and board layouts for all serviceable modules.

This service manual is divided into eight sections:

Volume 1

- Section 1** **System Description** — Introduces you to the CD-100C, its features, and its major components, principles of operation, and step-by-step unpacking instructions. After unpacking the CD-100C, you should continue the installation process by following the title rack loading and programming instructions in *Section 2*.
- Section 2** **Installation And Programming** — Continues the installation process with disc and title rack loading instructions, programming references, and step-by-step programming and pricing instructions. Whether you are familiar with previous Rowe phonographs or not, pay special attention to the pricing and programming.
- Programming and pricing have been set at the factory, so you may not wish to change any of the CD-100C options. After you load the titles and the discs, the CD-100C is ready to play.
- Section 3** **Routine Service** — Provides routine service instructions for collecting money, doing cash and play audits, resetting phonograph totals, and doing preventive maintenance.

Volume 2

- Section 4** **CBA-2 Maintenance** — Contains all CBA-2 maintenance information, except for the CBA-2 replacement parts, which are in the *Parts Catalog*.
- Section 5** **Troubleshooting** — Provides troubleshooting charts, error code and disc condition descriptions, troubleshooting procedures, block diagrams, schematics, circuit board layouts, and component lists. This section also contains the sequence of operation.
- Section 6** **Mechanical Adjustments** — Details the mechanical checks and adjustment procedures for all of the CD-100C's modules, except for the CBA-2 modules, which are described in *Section 2*.
- Section 7** **Miscellaneous** — Contains specifications, fuse and circuit breaker locations, and a resistor color code chart.
- Section 8** **The Parts Catalog** — Lists and illustrates all replaceable modules in the CD-100C. The Accessory Equipment List is at the end of this section.

This manual is intended for owners, route operators, and technicians. This manual provides all field and shop related service and maintenance material. Accessories and their installation and service are discussed in the corresponding accessory instructions (or manuals).

Table of Contents

SECTION 1 — INSTALLATION AND SYSTEM DESCRIPTION

Introduction	1-1
Features	1-2
General Features:	1-2
Service Features:	1-2
Unpacking Instructions	1-3
Exterior	1-3
Doors	1-3
Shipping Bolts, Clips, And Tape	1-3
Title Rack	1-3
Mechanism	1-5
CD Unpacking	1-5
Visual Inspection	1-6
Phonograph Leveling	1-6
Handy Case	1-6
Warranty Registration Card	1-7
Major Components Of The CD-100C	1-7
CD Selection System	1-7
Keyboard	1-7
Central Control Computer	1-8
Memorec	1-8
Autoplay	1-8
Principles Of Operation	1-8
Audio System	1-8
CD Player	1-8
Stereo Amplifier	1-8
Preamp	1-8
Power Amplifier	1-8
Two-Wire Volume Control	1-9
Output Transformers	1-9
The Speaker System	1-10
CD Changer Mechanism	1-10
Magazine	1-10
Play Counter	1-10
Money Counter	1-10
Optical Switch	1-10
Cam Switch And Motor Assembly	1-11
Sprag Assembly	1-11
CD Modules	1-11
Mechanism Control Unit	1-11
Main Power Supply	1-11

SECTION 2 — INSTALLATION AND PROGRAMMING

Introduction	2-1
Power On	2-1
Lifting The Title Rack	2-1

Table of Contents

SECTION 2 — PROGRAMMING *(Continued)*

Loading CD'S And Titles	2-2
Preparing Titles For The Title Rack	2-2
Loading The Title Rack	2-3
Step-By-Step Instructions	2-4
Loading Discs	2-5
Setting Title Page Limits For The First Time	2-7
Pricing	2-7
To set Alternate Disc prices:	2-8
How CD-100C Pricing Works	2-8
Sample Price Changes	2-8
Checking The Pricing	2-10
Sound System Set Up	2-10
Extension Speaker Operation	2-10
70-Volt Speakers	2-11
Low Impedance Speakers	2-11
Selecting Speaker Power	2-11
General Instructions	2-11
Step-By-Step Instructions	2-11
4-Ohm Speakers	2-12
8-Ohm Speakers	2-13
70-Volt Speakers	2-13
Sound System	2-19
Acoustical Compensation (Equalizer Tone Controls)	2-19
What This Graphic Equalizer Does	2-19
Equalizer Settings	2-19
Step-By-Step Instructions	2-20
Soft And Highly Absorbent Rooms	2-20
Average Or Moderately-Absorbent Rooms	2-21
Hard And Non-Absorbent Rooms	2-21
Paging	2-22
Changing The Number Of Credits Remaining	2-22
Entering The Service Mode	2-23
Viewing Menus	2-23
If You "Get Lost" In The Menus	2-23
Using CD-100C Commands	2-23
Combining Menu And Command Modes	2-24
Service Mode Menu	2-26
Security Menu	2-26
Audits Menu	2-26
Attract Mode Menu	2-26
Initialize Menu	2-26
Autoplay	2-27
Pricing Menu	2-27
Options Menu	2-27
More Options 1 Menu	2-27
More Options 2 Menu	2-28
Reports Menu (Optional)	2-28
Status Menu	2-28

Table of Contents

SECTION 2 — PROGRAMMING *(Continued)*

How To Make Programming Changes	2-29
Keyboard Controls	2-29
Security Levels	2-30
Factory Security Level	2-30
Programming Autoplay, Premiums, Priorities, And Lockouts	2-50
Autoplay Programming Modes	2-51
Lockout And Timed Lockout Modes	2-51
Editing Autoplay, Premiums, Priorities, And Lockouts	2-51
Timed Free Play And Timed Lockout Scheduling Tutorial	2-52
What Multiple Lockout On/Off Times Do	2-52
What Multiple Freeplay On/Off Times Do	2-52
Enhanced Autoplay Tutorial	2-54
Autoplay	2-54
Differences Between Standard And Enhanced Autoplay	2-55
Setting Up Enhanced Autoplay	2-55
Using Reset+9 In The Category Menu	2-59
Disc Mode	2-59
Category Mode	2-59
Day Of The Week	2-60
Event	2-60
Time	2-60
Categories	2-60
Delay	2-60
Channel 1 And Channel 2 Volume (Optional)	2-60

SECTION 3 — ROUTINE SERVICE

Introduction	3-1
Lifting The Title Rack	3-1
Doing An Audit	3-2
Collecting Audit Figures	3-2
Entering The Service Mode	3-2
Cash Audits	3-3
Play Audits	3-3
Non-Resettable Audits	3-3
Most Popular Disc	3-3
Least Popular Disc	3-3
Most Popular Selection	3-4
Clearing The Audit Values	3-4
Clear Cash	3-4
Clear Plays	3-4
Clear Selection Popularity	3-4
Changing CD's And Titles	3-5
Preparing Titles For The Title Rack	3-5
Changing Title Page Limits On An Installed Phonograph	3-7
Changing Discs	3-8


Table of Contents

SECTION 3 — ROUTINE SERVICE *(Continued)*

Complete Audit Command List	3-9
Collecting Money	3-13
Preventive Maintenance	3-13
CD Player Laser Lens	3-14
Coin Acceptors (optional)	3-14
Coin Switch	3-14
Checks And Adjustments	3-16
Coin Lever	3-16
Contact Pressure And Gap	3-16
Door Spring Replacement	3-17
Glass Replacement	3-18

FREQUENTLY USED FIGURES AND TABLES for Volume 1

Audit Commands (Table 3-1)	3-9
Command Index (Table 2-5)	2-45
Extension Speaker Worksheet (Table 2-1)	2-12
Keyboard Controls (Table 2-3)	2-29
Menu And Command Descriptions (Table 2-4)	2-31
Service Mode Map (Figure 2-11)	2-25
Speaker	
Connections (Figure 2-8)	2-17
Overload Check (Table 2-2B)	2-15
Power (Table 2-2A)	2-15
Volume Control Diagrams (Figure 2-9)	2-18



DIGITAL DISPLAYS -
Show the SELECTION PLAYING, SELECTION BEING MADE, SELECTIONS REMAINING, and SERVICE MODE DISPLAY

SELECTOR KEYBOARD
Enters numbers and contains the POPULAR and RESET Keys

COIN ACCEPTOR - Accepts coins

BILL ACCEPTOR -
Accepts \$1 and \$5 bills

CENTRAL CONTROL COMPUTER -
Controls all functions of the Phonograph

OUTPUT TRANSFORMERS -
Provides connections to the speakers

CD MECHANISM -
Selects and Plays discs

AMPLIFIER COMPARTMENT -
Contains the Amplifier and Main Power Supply

SERVICE SWITCH -
Selects the mode of operation

FRONT DOOR LACHES -
Allow the front door to swing out

HANDY CASE -
Contains the Service Manual and spare parts

MECHANISM CONTROL UNIT -
Controls Disc Mechanism

SPEAKER SYSTEM -
Woffers and High/Midrange (not shown) Speakers




Figure 1-1. CD-100C Major Components