

CAUTION


DO NOT EXPOSE RECORDS ON THIS MACHINE TO DIRECT SUNLIGHT

INSTRUCTION FOR CONNECTING C.V. (500 Ω) SPEAKERS TO EACH STEREO CHANNEL


FADER SW. POSITION	WATTS PHONO	MAX. WATTS C.V. (500 Ω) SPKRS.	CONNECT TO
PHONO ONLY	15	—	C.V. & GND.
A	11	6	C.V. & GND.
B	6	12	C.V. & GND.
C	2	16	C.V. & GND.
D	½	17	C.V. & GND.

INSTRUCTIONS FOR CONNECTING PHONO & STEREO SPEAKERS


FOR PHONO & NO STEREO



FOR NO PHONO & TWO WALL, CORNER OR CONSOLE STEREO SPKRS.



FOR PHONO & ONE WALL, CORNER OR CONSOLE STEREO SPKR.



FOR PHONO, ONE WALL STEREO CORNER OR CONSOLE SPEAKER & TWO STEREO EXTENDER SPEAKERS

