


How to identify the software level

The naming of the Main Base EPROM (U5 & U6) indicates the software level (major version) and the jurisdiction.

You can view the naming of the Main Base software either on the EPROM label or in the *Service Menu/Machine Information* and *Audit Menu / Machine Information* of the gaming machine.



Main Base version

HBS-STD-3.x.x.xx
 HBS-STD-5.x.x.xx
 HBS-STD-7.x.x.xx
 HBS-STD-10.x.x.xx
 HBS-STD-11.0.x.xx
 HBS-STD-11.1.x.xx
 HBS-STD-11.3.x.xx
 HBS-STD-12.0.x.xx

Software Level

A-Level
 B-Level 1.2.1
 B-Level 1.2.3
 C-Level 1.x.x
 C-Level 4.0.x
 C-Level 4.1.x
 C-Level 4.2.x.x
 C-Level 5.1.x.x

[BACK](#)