् Search

**Parenting** 

**Living Well** Family & Relationships **Education & Activities** 

Login | Get Inspired | Explore Projects | Spark

More eHow

Featured: Life's Moments | Grocery Guide | Mother's Day

eHow » Toys & Games » Games of Chance & Dice » Slot Machines » How to Reset Japanese Slot Machines

# How to Reset Japanese Slot Machines

By Chris Deziel, eHow Contributor



Every Japanese city has amusement parlors featuring the vertical pinball machines called pachinko. These parlors also feature distinctive slot machines called pachislo. They differ form Vegas-style machines in that the player is able to stop each reel by pushing a button, creating the illusion of being able to win



jackpots by skill alone. In reality, the odds of hitting the jackpot are pre-programmed, and in a Japanese parlor attendants adjust them daily, both to attract customers and to cash in when there is a full house. In some parlors, attendants reset the machines after every payout.

### Other People Are Reading



How to Convert Tokens to Quarters for



How to Convert a Slot Machine From Γoken to Coin

# Things You'll Need

Pachislo machine

Key

### Instructions

1 Insert the key into the keyhole in the front of the machine. Turn it counterclockwise to disable the machine and pull the front of the machine towards you. It is hinged and will swing out. If it is an older machine, you may have to jiggle the

front to get the catch to release.

Look for the odds meter on the inside of the door. It will display a number from 1 to 6. The loosest odds are denoted by 6. Press the button next to the meter repeatedly to reset this number to the one you want. When you have chosen the number, press the play lever on the front of the machine to set it.

#### Sponsored Links

#### Download Video Editor

300+ Video Effects. 60+ Formats: MPEG VOB AVI WMV 3GP DVD RM www.avs4you.com/AVS-Video-Editor

Use a second key to reset the machine after a malfunction, usually denoted by the E1 code showing in the "credits" display on the front of the machine.

### Related Ads

Slot Machine Strategy

Slots Games

How to Win Cash

Manual Reset Switch

Japanese Door



Watch Video

Must-Know Tips for New Parents

### You May Like



Japanese Slot Machine Instructions



How to Fix a Slot Machine



How to Convert My Japanese Slot Machine to Take Quarters



How to Reset My Daito Skill Stop Slot Machine



How to Convert a Slot Machine to Quarter Play

5/2/2013 7:27 PM 1 of 4

- Turn off the main power button, usually located on the door or above the hopper, or unplug the machine. Insert the key into the reset keyhole located just under the hopper and turn it to the right. Leaving the key in this position, turn the power back on.
- Close the door and note that the credits display shows the number 1. Push the lever once, and it will read o.
- 6 Open the door again, turn the reset key back to its original position, and remove it.
- Push the door closed, and turn the door key clockwise to return the machine to operating mode. If the key doesn't turn, wiggle the door so that the latch lines up. Verify that the machine is working by inserting tokens and pushing the play lever.

Sponsored Links

NV

<u>Allied Electronics</u> Wide Selection of Parts and

Same Day Shipping. Order Now!

www.AlliedElec.com

The Hurry Cane™ - \$20 Free Shipping On All Orders

Off Trust The Best Folding Walking Cane

TheHurrycane.com/Promo

<u>Precision Garage Doors</u> Garage Door Repair & Replacement

New Doors Installed 1 Day, Call Now

www.garagedoor-lv.com

Silent Partner Machines \$300 Off most popular ball machines

Videos of ball machines: Info & fun

www.sptennis.com

# Tips & Warnings

It is common for a coin to jam the machine. When this happens, open the door and work the jammed coin out with a screwdriver before reseting the machine and closing the door.

Pachislo machines are designed to accept special tokens that players exchange for "prizes" (that are usually cash) because it is technically illegal to gamble in Japan. It is possible to retrofit a pachislo machine to accept quarters.

Pachinko parlors represent a multi-billion dollar industry in Japan, and older machines are constantly being replaced by newer ones. Out-of-date pachislo machines are readily available for export as curios.

#### Related Searches

Slot Machine Strategy

Slots Games

How to Win Cash

Manual Reset Switch

Japanese Door



How to Change a Pachislo Machine



How to Repair a Slot Machine



How to Reset a Slot Machine

2 of 4 5/2/2013 7:27 PM



Women: What Your Tongue Says About Your Thyroid Newsmax



**Government Lies** Distorting Economic Reality... Collapse Im... Classic Chevy Trucks ... Money Morning



Best Classic Ford Trucks for Sale & Consumer Car Reviews



Exercises You Can Stop Doing Daily Health Post

by Taboola

### References

Angelfire: Pachislo Slot Machine Operation Manual

Old Vegas Chips: Automatic Pachislo Skill Stop Japanese Slot Machine

YouTube: Fix Error Code E1 Pachislo Slot Machine

### Resources

Read this Article in Spanish

Read this Article in UK English

Photo Credit fÃate foraine 12 image by Nathalie P from Fotolia.com

### More Like This



Quarters for a Yamasa



How to Convert a Slot Machine From Token to Coin



Japanese Slot Machine Instructions

### Comments



Add a comment...

Comment



Elvis Arbogast 'Works at Carpentry

I bought one of these slot machines there was no reset key. where can I get a reset key? Reply Like March 30 at 6:40pm

Facebook social plugin

### You May Also Like

Japanese Slot Machine Instructions

A Japanese slot machine is called a pachislo. While similar to an American slot machine -like the ones you would find...

### **Featured**

3 of 4 5/2/2013 7:27 PM



Baby Gear 101: Buy, Borrow & Request



Meet Angry Chicken's Amy Karol



Oh, Baby! Build the Ultimate Nursery

How to Reset a Slot Machine
Types of Slot Machines

How to Find Las Vegas Slot Machines

How to Reset am IGT Bill Validator Slot Machine

What Are the 6 Simple Machines in the Pinball Machine?

About eHow eHow Blog How to by Topic How to Videos Sitemap

© 1999-2013 Demand Media, Inc.

Use of this web site constitutes acceptance of the eHow Terms of Use and Privacy Policy. Report Copyright. Ad Choices en-US

EHOW Lifestyle • Hobbies • Games • Toys

A Demand Media Property

4 of 4 5/2/2013 7:27 PM