

B & K MODEL 747 PARTS LIST

488-104-9-002

**SCHEMATIC
SYMBOL**

DESCRIPTION

**B & K
PART No.**

Case Name Plate Top	600-011-9-903
Case Name Plate Bottom	600-012-9-903
Nuvistor Socket, #22	749-015-9-001
7 Pin Min. Tube Socket, #1, 2, 3, 4, 5 & 30	749-064-9-001
Loctal Tube Socket, #27	749-014-9-001
Decal Socket, #28	749-033-9-001
Noval Tube Socket, #6, 7, 8, 9 & 10	749-066-9-001
10 Pin Min. Socket, #29	749-002-9-003
Octal Tube Socket, #14, 15, 17, 18 & 24	749-074-9-001
Novar Tube Socket, #11, 13, 20 & 25	749-068-9-001
Magnoval Tube Socket, #26	749-069-9-001
Compactron Socket, #12, 16, 19, 21 & 23	749-073-9-001
Lens Cap, Red (OFF-ON INDICATOR)	750-003-9-001
Knob (SENSITIVITY)	751-010-9-001
Knobs (HEATER)	751-081-9-001
Banana Jack, Black	774-001-9-002
Ferrite Core	870-002-9-001
Tube Chart	497-017-0-000
Instruction Manual	480-115-9-001
Lens Cap, Clear (SHORT INDICATOR)	750-003-9-002

NOTE: Standard value resistors and capacitors are not listed, values may be obtained from schematic diagram.

Minimum charge \$2.00 per invoice. Orders will be shipped C.O.D. unless previous open account arrangements have been made or remittance accompanies order. Advance remittance must cover postage or express charge.

Specify serial number when ordering replacement parts.