

EM 230

91802	STARTER TYPE S10	2
96045	FUSE 10 A 5X20 MM	10
985055	TRACE MM81 ROTOR OSCILL	2
985073	COMPRESSOR-PROTECTION	2
985074	STARTING RELAY COMPRESSOR	2
985075	CAPACITOR	1
985110	BLADE EMPTY FULL	4
985411	SPRING	2
985455	FRONT HALF-BUSH	4
985457	SPACER	2
985460	BLADE-SUPPORT	2
985528	THERMOSTAT K50-1127	2
985775	GREEN LIGHT	1
985776	ORANGE LIGHT 24V	1
985777	SELECTION-BUTTON	2
985822	POST. BUSH CARRIAGE ROTOR	1
985824	DISC FOR HALF-BUSH	2
985834	MICROSWITCH	4
985835	CAM (PET 0.5 CANS 2X0.25-2X0.33)	2
985846	CAM	2
985970	SCREW FOR MOTOR-FLANGE	2
985978	MOTOR-FLANGE	1
986058	DOOR-MICRO WITH RESETTING	2
986069	MOTOREDUCER	1
986613	SCREW M5X15	4
986614	NUT FLANGED	4
986849	BUSH FOR DOUBLE-DOOR	1