

Colibri Quick Reference Guide

Statistics

1. Press program button once located on the PCB mounted on the inside of the door.
2. Display will read Program then change to Statistics.
3. Press enter stat 1 is displayed then the display will change to Button 1 P=00000, you can scroll through to the required section using the top left button.
4. Abbreviations on display read as follows P = PAY G = GRATIS/FREE T = TEST

Reset Failures

1. Press program button twice (slowly) machine will display program then change to Present Failures.
2. To read failures press enter, Fault will appear on display.
3. To delete failure press delete button (bottom right button).

Price setting

1. Press program button twice display will read program then change to Present Failures.
2. Scroll to the right until display shows Set Prices,
3. Press enter display will read Price 1=0010,(if price 1 is set to 0000 the machine will be set to freevend).(8 prices to set.)
4. Press enter (3rd button down right hand side).
5. Display will now flash, enabling the price to be changed using the top two buttons.
6. Press enter to confirm change.
- 7.