

# Smart Food Machine.

## Pricing.

- 1/. Open door, machine will read M = Statistics.
- 2/. Press button 'C' once, machine will read Set Prices.
- 3/. Press button 'E' once, machine will read normal prices.
- 4/. Press button 'E' once, machine will read Set Global.
- 5/. Press button '0' once, machine will read Set Single.
- 6/. Press button 'E' once, the number '1' will be flashing.
- 7/. Press button 'E' once, now enter the new cost of the drum by using the keypad, you must use a three-digit number, i.e., *0.55* or *1.55*.
- 8/. If you wish to change any more prices just follow steps 6 & 7 again.