
Most - Often - Needed 1954 **VOLUME TV-8**







Compiled by M. N. BEITMAN

SUPREME PUBLICATIONS



Most - Often - Needed 1954 Volume TV-8

Television

Servicing Information

Compiled by

M. N. BEITMAN



Supreme Publications

FOREWORD

This new <u>1954 Television Servicing Information</u> manual is the eighth volume of the Supreme Publications TV series. As in previous volumes, we have tried to include in this new manual circuit diagrams and all essential service facts on every popular TV set made during the past year. Factory prepared and checked material was used in every case where it was available. We believe that each manufacturer knows its sets best and can prepare the most accurate and easiest to apply service material on the very sets they engineered, built, and distributed. The kind reception given by servicemen to previous volumes of this series encourages us to believe that our selection and editing of factory material incorporated in these manuals meets with your needs and approval.

The data on 1954 TV models included in this new SUPREME manual brings exciting news of recent technical developments that will prove of great interest to you and will be the help you need when these sets are in your shop for service.

The list of Contents is given on pages 3 and 4, while a complete Index by manufacturers and model (or chassis) numbers begins on page 191. Refer to this list and index to find the TV material you need.

Our sincere thanks and appreciation is extended to all manufacturers through whose cooperation it was possible to present technical information on the sets of their make.

M. N. Beitman

February 1954 Highland Park, Illinois

Copyright 1954, by Supreme Publications.

All rights reserved. This book, or parts thereof, must not be reproduced in any form without permission of the publisher.

2

TABLE OF CONTENTS

Admiral Corporation Chassis 22F2, 22G2, 22M2, 22N2, 22P2, and 22R2 Chassis 19J1, 19L1, 19P1, 19S1, 19A2, 19B2, 19D2, 19E2 (For list of models using these chassis see pages 5 and 15)	5 to 14 15 to 18
Arvin Industries, Inc. Chassis TE 358-1, TE 359, TE 363-1, TE 364, used in Models 9210, 9212, 9216, 9218, 9219, 9240 (with suffix letters)	19 to 22
Crosley Corp. Chassis 405, 405-1, 410, 410-1, and similar Chassis 402, 402-1 403, 403-1, 404, 404-1 (for list of models see page 23).	23 to 3 0
Allen B. Du Mont Laboratories, Inc. Chassis RA-306, RA-307	31 to 36
 Emerson Radio and Phonograph Corp. Chassis 120185B, 120190D, 120191D, 120192B, 120192D Chassis 120174B, 120180D, 120193B, 120198D are similar. (See page 37 for complete list of models using these chassis) Chassis 120182D, 120195D, 120196B, 120197B, 120197D, used in Models 741F, 757D, 781A, 781B, 784E, 784G, and 785K . 	37 to 44 45 to 46
General Electric Co.	
Models 21C225, 21C333, 21T7, 21T8, 21T20, 21T21, Chassis EE The Hallicrafters Co.	47 to 52
Chassis A1400D, B1400D, C1400D, D1400D (Models listed on 53)	53 to 58
Hoffman Radio Corp. Chassis 300-17, Models 7M140, 7B141, and Chassis 300-21, used in Models 21M143, 21B144, 21P145, 21M317, 21B318, 21M718, 21B719, 21P720	59 to 62
Motorola, Inc.	
Chassis TS-602, TS-602Y, (see page 63 for list of models) Chassis TS-292, VTS-292, WTS-292, with various suffix letters (For list of models using these chassis, see page 69)	63 to 68 69 to 71
Chassis TS-402, TS-502, (see page 72 for list of models) \ldots	72 to 76
Muntz TV, Inc. Chassis 17B1, 17B2, 17B3, 17B4, 17B5, 17B6, and 37A2 (Models using these chassis are listed on page 77)	77 to 82
Olympic Radio & Television, Inc. Chassis TM-17, TN-21, TNA-21 (see page 83 for list of models)	83 to 84
Packard-Bell Co. Chassis Type 2040 (See page 85 for complete list of models)	85 to 86
	87 to 97 98 to 104 05 to 110)

TABLE OF CONTENTS (Cont'd.)

 R. C. A. Victor Models 21T356U, 21T363, -U, 21T364, -U, 21T365, -U, 21T372, -¹ 21T373, -U, 21T374, -U, 21T375, -U, Chassis KCS-83, -B, - and similar Models 21S354, -U, 21S362, -U, KCS-83C, -D Models 17S349, 17S350, -U, 17S351, -U, 17T352U, 17S360, -U, 17T361, -U, using Chassis KCS-78F, -78H, -78J, and Models 17T301, -U, 17T302, -U, 17T310, -U, Chassis KCS-78, -78B, and Models 21T303, -U, 21T313, -U, 21T314, -U, 21T315, -U, 21T316, -U, 21T322, -U, 21T323, -U, 21T324, -U, using Chassis KCS-82 and KCS-82B Models 21D305, -U, 21D317, -U, 21D326, -U, 21D327, -U, 21D328, -U, 21D358, -U, 21D368, -U, 21D376, -U, 21D377, -U, 21D378, -U, 21D379, -U, 21D380, -U, Chassis KCS-81F, -81J, and Models 21D346, -U, -81D, -E 	-E, 111 to 114 115 to 120
Raytheon Manufacturing Co. 21T8 Chassis, Models UM-2133A, UM-2134A, UM-2135A, etc. 24T2 Chassis, Models UC-2403A to UC-2406A 1	27 to 134
Sentinel Radio Corporation Models 500, 510, 511, 512, 513, 515, 532, 542, 552, 554, etc. 1	35 to 138
Sparks-Withington Co. (Sparton) Chassis 21S173A, 21S214, 24U174, 24U213, 24U214 1 (See page 139 for a complete list of models)	39 to 142
Stewart-Warner Electric Models 21C-9300, 21T-9300, with various suffix letters 1	143 to 152
Stromberg-Carlson Company Series 621A, 622, 624, and 625	153 to 158
	159 to 163 164 to 168
Westinghouse Electric Corp. Chassis V-2240-1, V-2240-2, V-2243-1, V-2247-1, V-2249-1, and V-2250-1, (for list of models see page 169) 1 Chassis V-2227-1, V-2227-2, Models H-736T17, H-738T17, etc. 1	
Western Auto Supply Co. (Truetone) Models 2D1330A, 2D1331A, 2D1336A, 2D1345A, 2D2334A 1	178 to 180
Zenith Radio Corp. Chassis 19L25, 19L26, 19L27, 19L28, 21L21, 22L20 (See page 188 for a complete list of models) 1	l81 to 190
Index	191-192

4

Admiral

22F2, 22G2, 22M2, 22N2, 22P2 and 22R2 CHASSIS

MODEL IDENTIFICATION CHART

MODEL NUMBERS Model numbers may have suffix letter "N"	TV Chassis	Picture Tube	VHF Tuner	UHF Tuner	Record Changer	Radio	Tone Control
122DX12	22F2	21ZP4A	94D61-1				Yes
122UDX12	22G2	21ZP4A	94D61-1	A3969 or A4000			Yes
222DX15B, 222DX16B, 222DX17B	22M2	21EP4A	94D61-1			• • • • • • • • • • •	Yes
222UDX15, 222UDX16, 222UDX17	22N2	21EP4A	94D61-1	A3969 or A4000	•••••		Yes
222DX27B	22M2	21EP4A	94D61-1				Yes
322DX16A	22P2	21EP4A	94D61-1		RC600	Built-In AM	Yes
322UDX16	22R2	21EP4A	94D61-1	A3969 or A4000	RC600	Built-In AM	Yes

All these chassis have the same basic television circuitry and are similar to earlier Chassis 22C2, 22E2, covered in 1953 manual. For alignment information on all of these sets please refer to Supreme Publications Volume TV-7, Most-Often-Needed 1953 Television Servicing Information manual, pages 13 to 15, inclusive.

The circuit for 22G2 and 22N2 chassis is printed on pages 10-11. These are all channel VHF and UHF sets. Chassis 22R2 is used in a combination set and is similar to 22G2, 22N2, except for a built-in AM radio, record changer, and the necessary switching network. On pages 12-13 is the circuit for 22P2 combination which uses a similar radio and switching arrangement. Chassis 22F2 and 22M2 are straight television sets that correspond to the TV circuitry of 22P2 chassis.

BUILT-IN VHF AND UHF TELEVISION ANTENNAS


VHF-UHF receivers using the All-Channel UHF tuner are equipped with separate VHF and UHF built-in antennas which may eliminate the need for either indoor or outdoor antennas if the receiver is in-a "normal signal" area. The VHF built-in antenna is connected to the two lower terminals; the UHF built-in antenna is connected to the two upper terminals.

CONNECTING EXTERNAL ANTENNAS

A combination VHF-UHF antenna or a separate VHF and UHF antenna system can be used with these receivers. For best results in weak signal areas, we recommend the use of separate VHF and UHF antennas and transmission lines.

If separate VHF and UHF external antennas are used, connect the VHF antenna lead-in to the lower antenna terminals and the UHF antenna lead-in to the upper antenna terminals. If a combination VHF-UHF antenna is used, the following connections should be made:

1. Connect a 3¹/₄ inch stub of 300 ohm transmission line (shorted on one end) to the upper left terminal and the lower left terminal, as shown in the figure below.





- 2. Connect a similar stub to the other two terminals, upper right and lower right.
- 3. Connect the combination antenna lead-in wire to the upper two terminals.

ADMIRAL Chassis 22F2, 22G2, 22M2, 22N2, 22P2, and 22R2, continued.

SERVICE ADJUSTMENTS


For best results, all checks or adjustments should be made using a transmitted television test pattern. A mirror placed in front of the picture tube screen will be of help in observing the picture while making adjustments at the rear of the chassis. Removing the TV back disconnects the line cord; use a separate line cord (part number 89A22-1) when servicing.

1. ADJUSTING CHANNEL SLUGS

Individual channel slug adjustment of every receiver should be checked upon installation or servicing. If this adjustment is properly made, it is possible to tune from one station to another by merely turning the CHANNEL control. With correct slug channel adjustment, best picture and satisfactory sound will be located at the approximate center (half rotation) of the range of the Tuning control.

Channel slug adjustment can be made without removing the chassis from the cabinet. Adjust as follows:

- a. Turn the set on and allow 15 minutes to warm up.
- b. Set the CHANNEL knob for a station; set other controls for normal picture and sound.
- c. Set TUNING control at center of its range by rotating it approximately half-way.
- d. Remove the CHANNEL and TUNING knobs.
- e. Insert a 1/8" blade, NON-METALLIC tool in the hole adjacent to the channel tuning shaft (see illustration). Since some channel slugs may be "hollowed out" for hex drive, the screwdriver slot will exist on only the outer edge of the slug. A narrow, worn or excessively sharp blade will cause the adjustment tool to slip out of the drive slot in the slug. For each channel in operation, carefully adjust the channel slug for best picture with clear detail. (Note that this may not be the point at which the sound is loudest.) Be sure that the Tuning control is set at the center of its range before adjusting each channel slug. Generally, only slight rotation of the slug will be required; turning the slug in too far will cause it to fall into the coil. (If the slug falls into the coil, remove the chassis from the cabinet and remove the coil. Move the retaining spring aside, lightly tap the open end of the coil until the slug slips out. Replace slug and reset retaining spring.)



2. ADJUSTING THE ION TRAP

To prolong the life of the picture tube, it is important that this adjustment be made upon installation, after adjusting the picture positioning lever, or after repositioning the focus coil.

Set the BRIGHTNESS control (at front of set) for normal brightness.

Position the ion trap on the picture tube close to the base. Starting from this point, very carefully move the ion trap forward or backward and at the same time, rotate it slightly in either direction until maximum brightness is produced.

Reset the BRIGHTNESS control for normal brightness. Adjust the FOCUS control (at front of set) for good focus. Readjust the ion trap for maximum brightness.


Note that there may be two locations where the brightest picture can be produced. The second ion trap location, which is further away from the tube base, should not be used or tube damage will result.

Important: If the corners of the picture are shaded, be sure the ion trap has been properly adjusted. Do not sacrifice picture brightness when adjusting the ion trap to remove shaded corners. To eliminate shaded corners, see paragraph 5 "Picture Centering".

3. ADJUSTING DX RANGE FINDER

This control is at the rear of the set, near the right side.

This control is used to improve TV reception in fringe areas and in areas where there is interference.



ADMIRAL Chassis 22F2, 22G2, 22M2, 22N2, 22P2, and 22R2, continued.

The DX RANGE FINDER should be at the "0" position, if satisfactory pictures can be obtained by using the operating controls on the front of the set.

Where the TV signal strength is weak, the picture can often be improved by turning the DX RANGE FINDER part way to the right or, if necessary, all the way to "300".

White flashes across the picture can sometimes be minimized by careful adjustment of the DX RANGE FINDER.

Caution: If the DX RANGE FINDER is turned too far to the right for a strong signal, the picture may disappear completely.

If the signal strength changes, it may be desirable to change the setting of the DX RANGE FINDER; however, it is generally possible to set it at a single compromise position which gives reasonable reception for the different signal strengths.

It is important to keep the DX RANGE FINDER setting as low as possible consistent with satisfactory pictures.

4. ADJUSTING PICTURE TILT

If the picture is tilted, loosen the wing screw "H" on the deflection yoke coil "F" and slightly rotate the yoke until the picture is straight. Before tightening the wing screw, be sure that the voke is moved as far forward as possible, otherwise



Picture Tilted; Adjust Deflection Yoke Coil.

corners of the picture may become shaded.

5. PICTURE CENTERING

If the picture is off center, it can be centered by using the picture positioning lever, and when necessary, repositioning the focus coil around the picture tube neck. Follow the instructions given below. Note that the picture positioning lever can be moved sideways, or up and down.

Picture Not Centered; Adjust **Picture Positioning Lever.**

- a. Adjust ion trap as instructed on preceding page.
- b. Slightly loosen the screw "A" which locks the picture positioning lever to the focus coil, and adjust the lever (sideways, or up and down) for correct picture centering.

c. Readjust the ion trap.

Difficulty in Centering the Picture

- a. Adjust ion trap as instructed on preceding page.
- b. Slightly loosen the two screws "B" which hold the focus coil to the yoke bracket. Center focus coil around the tube neck; tighten screws.
- c. Loosen the screw "A" and center the picture with the picture positioning lever. If the picture cannot be centered with the lever, it may be necessary to locate the focus coil slightly off center and then center the picture with the picture positioning lever.
- d. Readjust the ion trap.

Difficulty in Eliminating Shaded Corners

- a. Loosen screws "G", then move the yoke support bracket forward until rubber grommet "E" is firmly against the flare of the picture tube.
- b. Move the deflection yoke coil "F" as far forward as possible. In some cases, it may be necessary to loosen the two screws "D", move the bracket up or down, and then move the deflection yoke coil as far forward as possible.
- c. Adjust ion trap as instructed on preceding page.

HEIGHT AND VERTICAL LINEARITY 6. ADJUSTMENT

If the picture is of incorrect height (vertical size), adjust the HEIGHT control. This adjustment may affect the vertical linearity of the picture. If necessary, alternately adjust the VERT. LIN. control and HEIGHT control. Note that the upper portion of the picture is



Incorrect Height; Alternately Adjust HEIGHT and VERT. LIN. Controls.

affected mostly by the Vertical Linearity control; the lower portion by the Height control.

If the large circle in the test pattern appears cramped or flattened at top or bottom (non-linear vertically), correct by alternately adjusting the VERT.



Top or Bottom of Picture Cramped or Flattened; Adjust VERT. LIN. and HEIGHT.

LIN. control and the HEIGHT control.


ADMIRAL Chassis 22F2, 22G2, 22M2, 22N2, 22P2, and 22R2, continued.

7. WIDTH ADJUSTMENT

If the picture is too wide or too narrow, slide the WIDTH adjustment to the left or to the right until the picture just fills the picture tube screen.

8. HORIZONTAL LINEARITY ADJUSTMENT

If the large circle in the center of the test pattern has a cramped appearance at either side (nonlinear horizontally), slide the HORIZ. LIN. adjustment to the left or right as required. Note that the Horizontal Drive and the Width adjustments also af-



Side of Picture Cramped or Flattened; Adjust HORIZ. LIN.

fect linearity. Be sure that these adjustments are set correctly when making the horizontal linearity adjustment.

9. HORIZONTAL OSCILLATOR AND HORIZONTAL DRIVE ADJUSTMENT


A receiver which requires horizontal oscillator or horizontal drive adjustment can be corrected only by following in exact detail the step-by-step procedure given here.

NOTE: If HORIZ. DRIVE adjustment is not properly made, it may be difficult to obtain sufficient picture width and brightness.

Check to see if the HORIZONTAL control (on front panel) keeps the picture in "horizontal sync" through half of its range so that the picture does not "break up" when switching channels. Note: Since there is some interaction between the HORIZ. LOCK adjustment and the HORIZ. DRIVE control, adjustment of these controls are combined in one procedure.

If the picture will not stay in "horizontal sync" through half of the range of the HORIZONTAL control (on front panel), it will be necessary to make HORIZ.


LOCK and HORIZ. DRIVE adjustments. However, before making these adjustments, be sure that the picture can be made to remain stationary up and down (sync vertically) as lack of both vertical and horizontal sync is an indication of trouble in the sync



trouble in the sync Picture Out of Horizontal Syne. circuits such as a detective tube or other component.

Make the HORIZ. LOCK and HORIZ. DRIVE adjustments exactly as follows:

- a. Allow the receiver to warm up for a few minutes. Tune in the station, set the BRIGHTNESS control at a lower than average setting. Turn PICTURE control fully to the left. Important: Before proceeding, be sure that the DX Range Finder control (AGC) is adjusted according to the instructions given in this manual.
- b. Turn the HORIZONTAL control (front panel) completely to the left. Turn the HORIZ. DRIVE control fully to the right.
- c. Turn the HORIZ. LOCK adjustment to the right until the picture falls out of sync. If the picture cannot be made to fall out of sync, momentarily interrupt the signal by switching the CHANNEL control off channel and then back on.
- d. With the picture out of sync, turn the HORIZ. LOCK adjustment slowly to the left until the picture just falls in sync.
- e. Turn the CHAN-NEL control to an unused channel. If a white vertical line(s) appears near the center of the screen, slowly turn the HORIZ. DRIVE control to the left until the line(s) just disappears.



Vertical Line; Adjust HORIZ. DRIVE.

- f. If, in step "e", the HORIZ. DRIVE control required readjustment, tune in a station and repeat steps "c" and "d" to be sure of proper Horizontal Oscillator adjustment.
- g. Adjustment should now be satisfactory. However, check adjustment by slowly rotating the HORIZON-TAL control in either direction while interrupting the television signal by switching the CHANNEL control off channel and then back on. The picture should automatically fall in sync through at least half of the range of the HORIZONTAL control. If necessary, repeat the above step.
- h. Do not use the HORIZ. DRIVE control to obtain correct width or linearity. If necessary, make Width and Horizontal Linearity adjustments.

ADJUSTING CURVATURE CORRECTING MAGNETS IN SETS USING 21EP4A (21") PICTURE TUBE

If either side of the picture has excessive curvature (pin cushion effect) or if corners of the picture are bent inwardly, this can be minimized by adjustment of the correcting magnets shown in the chassis illustration. Either side of the picture can be adjusted individually by using the magnet on that side of the picture tube. A picture or test pattern having straight vertical lines near the sides can be used for making adjustment.

ADMIRAL Chassis 22F2, 22G2, 22M2, 22N2, 22P2, and 22R2, continued.

Picture	Raster	Sound	Checks and Suggested Tube Changes
None.	None.	None.	ls set plugged in? Line cord loose. Change tube V501.
None, weak, or intermittent.	None, insufficient brightness, or intermittent.	ок.	Fuse (if it is necessary to replace fuse, also replace tube V408). Change tubes V406, V405, V407, V408, V305. Adjust ion trap per paragraph 2. Replace picture tube.
None, weak, or intermittent.	ОК.	None, distorted, weak, or intermittent.	Check antenna connections. Changes tubes V101, V102, V301, V302, V303, V304, V305, V307. See paragraphs 1 and 3.
None, weak, or intermittent.	ок.	OK.	Change tubes V305, V304, V303, V101, V102, V301, V302, and V307. See para- graph 3. Replace picture tube.
ок.	ок.	None, weak, distorted, or intermittent,	See paragraph 1 Changes tubes V202, V201, V203, V204 and V304. Check speaker connections.
Insufficient brightness.	Insufficient brightness.	ок.	See paragraph 2. Changes tubes V305 and V407. Replace picture tube.
Picture expands when pic- ture control is advanced.	May have insufficient brightness.	ок.	Change tube V407.
Insufficient width.	Insufficient width.	ок.	See paragraphs 7, 8, and 9. Change tubes V406, V405, V501 and V408.
Insufficient height.	Insufficient height.	ок.	See paragraph 6. Change tubes V402, V401, and V501.
Bright, horizontal line across center of screen.	Bright, horizontal line across center of screen.	OK.	Change tubes V402 and V401.
Horizontal lines move up- ward when volume con- trol is advanced.	OK.	OK.	See paragraph 1. Change tubes V102, V101, V301, V302, V303, and V304,
Will not hold sync ver- tically, or horizontally.	ок.	OK.	Change tubes V403, V401, and V101. After changing each tube, adjust the vertical-hold control, and make the adjustments in para- graph 9.
Holds sync vertically, but not horizontally.	OK.	ОК.	Change tubes V404, V405, V406, V305, V101, V301, V302, and V403. After chang- ing each tube, make the adjustments in para- graph 9.
Holds sync horizontally, but rolls vertically.	ок.	ок.	Change tubes V401 and V403.
Picture curves (bends).	OK.	ок.	See paragraph 9. Change tubes V404, V405, V406, V305, V101, V301, V302, and V403.
Poor horizontal linearity.	ок.	ок.	See paragraphs 7, 8, and 9, Change tubes V406, V405, and V408.
Poor vertical linearity.	ок.	ОК.	See paragraph 6. Change tubes V402 and V401.
Tilted.	Tilted.	ОК.	See paragraph 4.
Off center or shaded corners.	Off center or shaded corners.	OK.	See paragraph 5.
Vertical lines or jagged edges, poor horizontal linearity.	Jagged edges.	ок.	See paragraph 9. Change tubes V408, V406, and V405.
Wide, black horizontal bar across picture.	Wide, black horizontal bar across raster.	ок.	Change tube V305.


9

TROUBLE CHART

Admiral Corporation

Schematic for 22G2 and 22N2 Television Chassis.


Block Diagram of UHF Tuner Circuit: The block diagram of the circuit functions (figure 29) will aid in understanding the operation of the UHF tuner. The principle employed is that of a single conversion stage and can be compared to a simple superheterodyne radio receiver. The incoming signal is applied to a tuned preselector stage and then coupled to the input of a mixer stage. In the mixer, the signal is beat with signal from the local oscillator, thus producing a beat of the desired frequency. In this case, the oscillator operates below the frequency of the incoming UHF signal and produces a beat which is the difference between the two frequencies. The preselector bandwidth is such that the usable beat frequency extends from 76 to 88 MC, which is within the frequency range of Channel 5 or 6.



1/2 12 AT 7

Figure 29. Block Diagram of UHF Tuner Circuit.

UHF Preselector Circuit: The UHF signal is coupled to the first tuned line of the preselector circuit by a coupling loop CL1. The loop is center-tapped in order to provide a balanced 300 ohm input. The signal from Z1A is transferred to the second tuned line Z1B by means of



coupling loop CL2. Since maximum coupling is at the point of current maximum, a loop of constant size at this point will have a degree of coupling which will vary with frequency. To provide the most uniform coupling over the entire tunable range, the loop is placed as close as possible to the point of current maximum.

Coupling from the second tuned line Z1B to the cathode of the 6AM4 mixer tube, V1 is provided by coupling loop CL3. Tuning capacitors TC2 and TC3 are connected to the end of the line and add capacity to it. This effectively lengthens the line. The two lines are tracked from Channel 14 to Channel 83.

An equivalent circuit of the tuned line preselector is shown in figure 31. Note that parallel resonant circuits have been substituted for the tuned lines. Z1A can be considered as a tuned primary and Z1B a tuned secondary. CLI is the UHF antenna coupling and CL2 is the link coupling between the two tuned circuits.






Figure 31. Equivalent Circuit of Preselector.



Refer to notes on page 14.




PICTURE TUBE REPLACEMENT

Picture tube replacement for the 22 series receivers is similar to that of other chassis using a rectangular.glass picture tube. The 21ZP4A is not interchangeable with the 21EP4A because of cabinet differences. Instructions for adjusting curvature correcting magnets used with 21EP4A (21" cylindrical faced) picture tube is given.

White Flashes Across Picture (22F2, 22M2 and

22P2 chassis): In weak signal, high noise level areas, white flashes across the picture can sometimes be minimized by careful adjustment of the DX Range Finder control. Caution: turning the DX Range Finder control too far to the right for a strong signal may cause the picture to disappear completely.



Admiral Chassis 22F2, 22M2, 22P2, continued.

WAVEFORM DATA

(Waveforms given on schematic)

Waveforms taken with CONTRAST control set fully to the right, all other controls set for normal picture (in sync). Warning: Incorrect adjustment of the DX Range Finder control will cause waveform distortion.

Waveforms at video and sync stages obtained with transmitted signal input to receiver. The oscilloscope sweep is adjusted for 30 cycles (which is one-half of the vertical frequency), or for 7875 cycles (which is one-half of the horizontal frequency) so that two pulses appear on the screen.

The peak-to-peak voltage readings shown are subject to some variations due to response of the oscilloscope and parts tolerances.

CAUTION

Pulsed high voltage is present on the caps of V406, V407 and pin 3 of V408. Do not make direct connection to these points with ordinary test equipment. Waveform and peakto-peak voltage at pin 3 of V408 taken, using an oscilloscope with a capacitive voltage divider probe. Waveform at pin 3 of V408 can be taken by clipping or twisting the lead from the oscilloscope high side over the insulation on the cap lead. When taking the waveform this way, the shape of the waveform will be the same but the peak-to-peak voltage will be much lower, depending upon the degree of coupling.

VOLTAGE DATA (Voltages given on schematic)

- TV voltage taken with function switch on "TV" position. CONTRAST control turned fully clockwise. CHANNEL control set on an unused channel. Other front controls set at approximately half rotation. Vert. Lin. and Height set at approximately half rotation. DX Range Finder control set fully to the left (at "0" position). TV antenna disconnected from set with terminals shorted.
- Radio voltages V701 and V702 taken with function switch on "Rad" position; voltages measured from underside of tube sockets. When measured from top of tube sockets (with tube removed), B plus voltage at pins 5 and 6 of V701 and V702 will be approximately 275 volts.
- B plus voltages at V203 and V204, will be slightly higher when set is switched to "Rad" position. Voltages marked with an asterisk * will vary widely with control setting.
- Line voltage 117 volts AC.
- Voltages measured with a vacuum tube voltmeter between tube socket terminals and chassis, unless otherwise indicated.
- Voltages at V306 measured from top of socket with tube removed.
- Voltages at V101 and V102 (TV Tuner) are measured with tube in socket. Use an adapter or lift tube out of socket just high enough to allow a needle point probe to contact tube pins.


CAUTION


Pulsed high voltages are present on the cap of V406, pin 3 of V408 and on the filament terminals and cap of the 1B3GT tube. NO ATTEMPT SHOULD BE MADE TO TAKE MEASUREMENTS FROM THESE POINTS WITHOUT SUITABLE TEST EQUIPMENT.

Picture tube 2nd anode voltage can be measured from the 2nd anode connector and should be taken only with a high voltage instrument such as a kilovoltmeter or VTVM with a high voltage probe. 2nd anode voltage is approximately 17.5 KV. Proper filament voltage check of the 1B3GT tube may be made by observing filament brilliancy as compared with that obtained with a 1.5 volt dry cell battery.


POOR UHF RECEPTION DUE TO IMPROPER ANTENNA LEAD DRESS

Poor UHF reception in All-Channel VHF-UHF receivers, may be caused by the UHF antenna lead from





Top View of 22F2 and 22M2 Chassis.



Top View of 22P2 Chassis. (V701 and V702 are accessible from underside of chassis.)

the UHF antenna terminals to the UHF tuner being close to or touching the metal brackets of the rear picture tube mount. This lead is purposely long and acts to present a high shunt impedance at the mean frequencies of the lower and higher VHF channels.

Remove the back cover of the cabinet and check this lead to be sure it is not close to any metal and straighten it out if it is looped or doubled up. While the back is off the cabinet and after the antenna lead has been checked, check the lead from UHF antenna terminals at the point where it is soldered to the side of the UHF tuner; see illustration above. Remove the metal bracket (if used) that covers the UHF antenna connections. This bracket was used on the production line and is not required after the set is installed in the cabinet.

REPLACING FUSE M401

The horizontal output circuit of these receivers is protected by fuse M401 ($\frac{3}{8}$ amp., 250 volts). This fuse is located at the side of the high voltage compartment.

Admiral

19J1, 19L1, 19P1, 19S1, 19A2, 19B2, 19D2 and 19E2 CHASSIS

Used in Models 121UDX12, 221UDX16L, 221UDX17L, 321UDX15L, 321UDX16L, TU1811, TU1812, TU1822, TU2212, C2215, CU2215, T2215, TU2215, C2216, CU2216, H2216, HU2216, K2216, KU2216, T2216, TU2216, C2217, CU2217, H2217, HU2217, K2217, KU2217, T2217, TU2217, T2218, TU2228, TU2222, TU2226, C2236, CU2236, C2237, CU2237.


For alignment of these sets please refer to pages 6 to 9 in Supreme Publications Volume TV-7, 1953 Television Servicing Information manual. The circuit printed on pages 16-17 of this manual is exact for Chassis 19J1, 19L1. The other chassis are very similar and this material may be used for servicing these additional sets.

INDIVIDUAL VHF CHANNEL SLUG ADJUSTMENT


Individual VHF channel slug adjustment of every receiver should be checked upon installation or servicing. If this adjustment is properly made, it is possible to tune from one VHF station to an other by merely turning the LOW-CHANNEL selector. With correct channel slug adjustment, best picture and satisfactory sound will be located at the approximate center (half rotation) of the range of the Fine Tuning tab.

VHF channel slug adjustment can be made without removing the chassis from the cabinet. Adjust as follows:

- a. Turn the set on and allow 15 minutes to warm up.
- b. Turn HIGH-CHANNEL selector completely to the right until the pilot light goes out and the letters "VHF" are at the top of the knob.
- c. Set the LOW-CHANNEL selector for a station; set other controls for normal picture and sound.
- d. Set the FINE TUNING tab (low-channel) at center of its range by rotating it approximately half-way.



Control Panel in 19J1 and 19L1 Sets; Knobs Removed.



Control Panel in 19P1 Sets; Knobs Removed.

- e. Remove the CHANNEL knobs and FINE TUNING tab.
- f. Insert a 1/8" blade, non-metallic tool in the hole adjacent to the channel tuning shaft (see illustrations below). For each VHF channel in operation, carefully adjust the channel slug for best picture with clear detail. (Note that this may not be the point at which the sound is loudest.) Be sure that the Fine Tuning tab is set at the center of its range before adjusting each channel slug. Caution: Only slight rotation of the slug will be required.


UHF TUNER SLUG ADJUSTMENT

The UHF tuner slug (mixer output network) is set at the factory and should generally never require readjustment in the field. However, if UHF reception is weak (picture has excessive snow), reception can be improved by readjusting the UHF tuner slug. This adjustment is located below the VHF channel slug adjustment. It can be reached after removing the CHANNEL knobs and FINE TUNING tab (low-channel).

UHF tuner slug adjustment can be made without removing the chassis from the cabinet. Adjust as follows:


- a. Set the LOW-CHANNEL selector knob to either Channel 5 or 6 (whichever does not have a TV station).
- b. Set the FINE TUNING tab at the center of its range by rotating it approximately half-way.
- c. Tune in UHF station for best picture.
- d. Remove the CHANNEL knobs and FINE TUNING tab.
- e. Insert a 1/8 inch blade, **non-metallic** tool through the tuner shaft hole in the knob panel until the alignment tool engages the adjustment screw just below the VHF channel slug adjustment hole. Carefully adjust the slug for best picture with clear detail. Only slight adjustment in either direction will be required.

ADMIRAL 19J1, 19L1, 19P1, etc., continued



See page 18 for notes applicable to this schematic diagram.

Admiral



ADMIRAL 19J1, 19L1, 19P1, 19S1, 19A2, 19B2, 19D2, and 19E2, continued.

SCHEMATIC NOTES

Run numbers are rubber stamped at the rear of the chassis. Numerical symbols ①, ②, ③, etc. on schematic indicate a production change covered by a run number.

(Al), (A2),.....(Y), (1), etc. indicate alignment points and alignment connections.

IMPORTANT: Before making waveform and voltage measurements, see instructions below.

WAVEFORM DATA

(Waveforms and Voltages given on schematic)

Waveforms taken with CONTRAST control set fully to the right, all other controls set for normal picture (in sync). DX Range Finder control set fully to the left (at "0" position). Warning: Incorrect adjustment of the DX Range Finder control will cause waveform distortion.

Waveforms at video and sync stages obtained with transmitted signal input to receiver. Waveform at pins 1 and 4 of V403 and terminal "C" (2) of T404 taken with a 10 mmfd. condenser connected in series with the oscilloscope high side.

The oscilloscope sweep is adjusted for 30 cycles (which is one-half of the vertical frequency), or for 7875 cycles (which is one-half of the horizontal frequency) so that two pulses appear on the screen.

The peak-to-peak voltage readings shown are subject to some variations due to response of the oscilloscope and parts tolerances.

Caution: Pulsed high voltages are present on the caps of V404 and V405 and at pin 3 of V406. Do not make direct connection to these points with ordinary test equipment. Waveform and peak-to-peak voltage taken at pin 3 of V406, using an oscilloscope with a capacitive voltage divider probe. Waveform at V406 can also be taken by clipping or twisting the lead from the oscilloscope high side over the insulation on the lead connecting to pin 3. When taking the waveform this way, the shape of waveform will be the same but the peakto-peak voltage will be much lower, depending upon the degree of coupling.

TV VOLTAGE DATA

- CONTRAST control turned fully clockwise. LOW-CHANNEL SELECTOR set on an unused VHF channel. HIGH-CHANNEL SELECTOR in the "VHF" position. Other front controls set at approximately half rotation. Vert. Lin. and Height set at approximately half rotation. DX Range Finder control set fully to the left (at "0" position).
- VHF antenna disconnected from set with terminals shorted.
- Voltages marked with an asterisk (*) will vary widely with control setting.
- Line voltage 117 volts AC.
- Voltages measured with a vacuum-tube voltmeter between tube socket terminals and chassis, unless otherwise indicated.
- Voltages at V101 and V102 (VHF Tuner) are measured with tube in socket. Use an adapter or lift tube out of socket just high enough to allow a needle point probe to contact tube pins.


Voltages at pins 1 and 8 of V101 (6BZ7) must be taken as described above or no voltage reading will be obtained.


- Voltages at V306 measured from top of socket with tube removed.
- B+ voltage at terminal "a" of VHF-UHF switch S1 of UHF tuner A4000 taken with switch in UHF position.

CAUTION


Pulsed high voltages are present on the cap of V404, pin 3 of V406 and on the filament terminals and cap of the 1B3GT tube. NO ATTEMPT SHOULD BE MADE TO TAKE MEASUREMENTS FROM THESE POINTS WITHOUT SUITABLE TEST EQUIPMENT.

Picture tube 2nd anode voltage can be measured from the 2nd anode connector and should be taken only with a high voltage instrument such as a kilovoltmeter or a vacuum-tube voltmeter with a high voltage probe. 2nd anode voltage is approximately 15 KV. Proper filament voltage check of the 1B3GT tube may be made by observing filament brilliancy as compared with that obtained with a 1.5 volt dry cell battery.






Top View of Chassis.



Rear View of VHF-UHF Chassis Showing Antenna Terminals and Adjustment Locations.



Drive Cord Stringing for UHF Tuner A4000.


Arvin TE 358-1, TE 359, TE 363-1, TE 364

The chassis listed above are almost identical except for type of tuner and size of picture tube. The circuit diagram on the next two pages, over, is exact for TE 363-1. To the time of publication these chassis were used in television models listed below.


Models 9210, 9212, 9216, 9218, 9219, 9240 (with various suffix letters)

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
		CAPACITORS			RESISTORS	i	22381-561	R335, 336, Resistor 560 ohm 10%
C202	40355-1	Disc. 2.2 uuf, 5%, 500V. P-100	R426	41050	1100 ohm, 5%, 22W		22381-102 24123-560	R337, Resistor 1000 ohm, 10%, C315, Capacitor Disc. 56 uuf, 10%,
C204	41077-1	Disc. 2.7 uuf 0.5 uuf, P-100	R409	22381-122	1200 ohm, 10%, 1/2W	T202	41171	Transformer, 1st Pix I.F. Assy (M1)
C217	20290-390	Mica. 39 uuf, 10%	R217, 323,	22382-122	1200ohm, 5%, 1/2W	T203	41172	Transformer, 1st Pix I.F. Assy (M2)
C407	20290-101	Mica. 100 uuf, 10%	R429	25467-152	1500 ohm. 5%, 2W	T204,205	41173	Transformer, 2nd & 3rd I.F. Assy
C414	40538	Disc. 130 uuf, 5 KV. Mica. 270 uuf, 10%	R427	23970-18	2000 ohm, 10%, 5W	T206 T301	41174 22446-1	Transformer, 4th Pix I.F. Assy.
C410 C408	20290-271 20331-331	Mica. 270 uur, 1076 Mica. 330 uuf, 5%, 500V.	RZZI	22381-222	2200 ohm, 10%, 1/2W	T402	40926	Transformer, Vert. Osc. Assy Transformer, Power
C409	20290-331	Mica. 330 uuf, 10%	R218 R430	22382-272	2700 ohm, 5%, 1/2W	T401	41024	Transformer, Horiz. Output Assy.
C416	24994	Ei Volt 500 uuf, 20 KV.	R202, 321	20070-332 22381-472	3300 ohm, 10%, 1W 4700 ahm, 10%, 1/2W	T102	24776-5	Transformer, Audio Output
C205, 208	41052-1	Disc. 560 uuf	R219	41075-602	6000 ohm. 5%, 4W	L201	41176	Transformer, Sound Take Off
215,211		IN ANY C M N	R56	20070-472	4700 ohm, 10%, 1W	T101 T302	41177	Transformer, 1st Sound I.F.
C201,203, 206,207,	23078	Disc001 uf, G.M.V.	· R104	20070-682	6800 ohm, 10%, 1W	T201	41023-1 41175	Choke, Vertical Output Assy. Transformer, Converter
209,211			R211	22382-682	6800 ohm, 5%, 1/2W			transformer, converter
212,213,			R203	22382-822 22381-822	8200 ohm, 5%, 1/2W 8200 ohm, 10%, 1/2W		м	ISCELLANEOUS
214,216,			R408	20070-822	8200 ohm, 10%, 172 w 8200 ohm, 10%, 1W			
317		Disc. 001-07-30#	' R330	22382-822	8200 ohm, 5%, 1/2 W		41129-1	Door, Control & Escutcheon Assy
C111, 308 307, 105	40054-102	Disc001 uf, 20%	R431, 432	25467-103	10K, 5%, 2W		41129-3	(9210, 18, 19CM UEF) Door, Control & Escutcheon Assy
C405	40108-102	Disc. Heavy Duty001 uuf, 1000V.	R311	22381-103	10K, 10%, 1/2W		4112 70 5	(9210, 16, 18CB UHF)
C110	40054-332	Disc0033 uf, 20%	R310 R301	22381-123 22382-123	12K, 10%, 1/2W		41129-2	Door, Control & Escutcheon Assy
C406	20433-392	Mica. 3900 uuf, 5%, Class B.	R55	25467-133	12K, 5%, 1/2W 13K, 5%, 2W			(9212CFP UEF)
C301	40053-472	Disc0047 uf, G.M.V.	RZ24	22381-153	15 K, 10%, 1/2W		41129-4	Door, Control & Escutcheon Assy
C302,401.	40054-472	Disc 0047 uf, 20%	R214	22381-183	181., 10%, 1/2W		40935-3	(9212MEA UHF) Knob, Channel Indicator
CIIZ	40108-472	Disc. Heavy Duty .0047 uf, 1000V.	R417,418 R303	20302 - 183	18K, 10%, 2W		40755-5	(9210, 16, 18, 19CM CB UFF)
C3)	20324-472	.0047 uf, 5%, 600V. Min. Oil Imp.	R406	22382-223 20302-223	22K, 5%, 1/2W 22K, 10%, 2W		40935-2	Knob, Channel Indicator
		Molded Paper	R307, 316	22382-273	27K, 5%, 1/2W			(9212CFP UHF)
C101, 102, 103, 104,	40053-103	Disc01 uf, G.M.V,	R433	22383-303	30K, 5%, 1W		40935-4	Knob, Channel Indicator (9212MEA UFF)
106, 108,			R52, 53, 54	25467-363	36K, 5%, 2W		40934-3	Knob, Volume (9210, 16, 18, 19-
C417, 418	41135-103	Disc. Feavy Duty, .01 uf, 1500V.	R 106 R 305	22381-393 22382-393	39K, 10%, 1/2W 39K, 5%, 1/2W			CM CB UHF)
C404, 304	25455-103	.01 uf, 20%, 200V. P.T. .022 uf, 20%, 200V. P.T.	; R308, 313,	22381-473	47K, 10%, 1/2W		40934-2	Knob, Volume (9212CFP UHF)
C319 C412, 419,	25455-223 25462-104	1 uf, 20%, 400V.	1 319				40934-4 40933	Knob, Volume (9212MEA UHF) Knob, Fine Tuning
51			R304 R109	22382-473	47K, 5%, 1/2W		40932	Knob, Brightness
C413, 415	20457-473	.047 uf, 10%, 600V. P.T.	R302	20061-473 22382-563	47K, 20%, 1/2W 56K, 5%, 1/2W		24699-7	Knob, Behind Control Door
C311 C402,219	25461-473 25455-473	.047 uf, 20%, 600V. P.T. .047 uf, 20%, 200V. P.T.	R306	22382-823	82K, 5%, 1/2W		24973	Rail, Top Retainer
C312,	25461-104	1 uf, 20%, 600V P.T.	R110	22381-823	82K, 10%, 1/2W		24944-4 24947	Rail, Bottom Retainer Glass, Safety
C50	25455-104	.1 uf, 20%, 200V, P.T.	R410	22382-913	91K, 5%, 1/2W		40670-1	Mask, Plastic
C107, 313	25462-224	.22 uf, 20%, 400V.	R225	22381-104	100K, 10%, 1/2W		25519	Speaker
C306 C314	25455-474 25461-474	.47 uf. 20%, 200V. P.T. .47 uf. 20%, 600V. P.T.	R401;402 R412	22382-104 22381-124	100K, 5%, 1/2W 120K, 10%, 1/2W		23538	Plug, Speaker
C6	41534	Elect. 2 uf, 150V.	R317, 222	22381-154	150K, 10%, 1/2W		19579 25267-12	Socket, Speaker Tuner Assy. (Dual)
C7	25453	Elect. 4 uf, 150V.	R42 1	20061-224	220K, 20%, 1/2W		40663	Fuse, High Voltage
C5	40002	Elect. 5 uf, 250V.	R108	22381-334	330K, 10%, 1/2W		25471	Cap, Tube Top (6CD6G)
C4	41429	Elect. 10 uf, 350V. Elect. 30-400V, 60-20 350V, 100-50V.	R309 R318	22382-394 22381-394	390K, 5%, 1/2W 390K, 10%, 1/2W		40959	Plug, Interlock Assy,
C1 C3	22422-20 22422-22	Elect. 30 uf, 400V.	R334, 325,	22381-474	470K, 10%, 1/2W		40512	Socket & Corona Ring Assy. (1B3GT)
C2	22422-21	Elect. 60-40-350V, 50-400V, 20-25V.	414				25095 25265-1	UHF Indicator Panel Light Socket Assy
CP-1	24166	Couplate	R404, 314,	22382-135	1 meg 10%, 1/2W		19351	Dial Light Bulb.
C411	24528	Trimmer 40-370 uuf	32.8				24911-8	Socket, Kinescope Assy.
		RESISTORS	R326	22382-135	1.3 meg, 5%, 1/2W		25662-3	Trap, Ion
			R312	22381-155	1.5 meg, 10%, 1/2W		41123-2	Connector, Anode Assy.
R420	20209-39	3.9 ohm, 10%, 1/2W, W-W					25511-1	Cover, Hi Volt Top & Rear Assy.
R419 R50	20308-100 22381-220	10 ohm, 10%, 1/2 W, W-W 22 ohm, 10%, 1/2 W	R331 R403	22381-225	2.2 meg, 10%, 1/2W 4.7 meg, 10%, 1/2W	R111,223	41464 22464-50	41 Mc, Control, Volume, Brightness
R415	20061-470	47 ohm20%, 1/2W	R107	22381-475 20061-106	10 meg, 20%, 1/2W	SW-3	22404-30	Control, Volume, Drighthees
R208,204,	22382-470	47 ohm, 5%, 1/2W				R220	22464 - 52	Control, Contrast
212					OKES & TRANSFORMERS	R333	22464-41	Control, Vertical Linearity
R101 R113	22381-680	68 ohm, 10%, 1/2W	L403	41020	Coil, Width Control	R327	ZZ464-58	Control, Vertical Hold
R215	20070-181 22381-161	180 ohm, 10%, 1W 180 ohm, 10%, 1/2W	L101 L202	40937 25468-18	Coil, Quadrature Coil, Peaking 93 UH on 6800 ohm	R411	22464-53	Control, Horizontal Hold Control, Tone-Phono-TV Switch
R332	20103-471	470 ohm, 20%, 1W	L202	25468-16	Coil, Peaking 500 UH on 101.	R112, SW-1 R329	22464-56 22464-43	Control, Ione-Phone-IV Switch Control, Height
R416	23970-16	220 ohm, 10%, 5W	L203	25468-15	Coil, Peaking 500 UH on Dummy	R315	22464-57	Control, Elect. Stabilizer
R428 R105	23970-27	400 ohm, 10%, 5W	L204	25468-19	Coil, Peaking 185 UH on 8200 ohm	R103	41038	Control, Buzz
R105 R322	22382-681 22382-821	680 ohm, 5%, 1/2W 820 ohm, 5%, 1/2W	L207	25468-20	Coil, Peaking 215 UH on 8.2E		41072	Shaft, Control Contrast
R205, 206,	22381-102	820 ohm, 5%, 1/2W 1000 ohm, 10%, 1/2W	1,402 1,401	25468-10 23449	Coil, Peaking 93 UF Coil, Horizontal Osc.		41073	Coupling, Contrast Control
207, 210,			L205	25609	Coil, Video Trap	SW - 2	41039	Switch, Local Distance
213,216			L404	40533	Coil, Forizontal Linearity		40991-2	Control, Magnetic Focus
R434 R51	20070-102 20061-102	1000 ohm, 10%, 1W	L406	40925-1	Choke, Filter		24458-3	Antenna Loop Assy.
R320	22382-112	1000 ohm, 20%, 1/2W 1100 ohin, 5%, 1/2W	L405	23095 24807	Choke, Filament Coil, Deflection Yoke			10
_			I					13


PARTS LIST



Service data on Arvin Chassis TE 358-1, TE 359, TE 363-1, TE 364, continued.



Alignment information on the next page.



Alignment for Arvin Chassis TE 358-1, TE 359, TE 363-1, TE 364, continued. Å Set buss control in middle of its range before edjustin L101 Kasp laad between 15K resistor and pin 2 as short as possible completely out before Adjust L201 on inner peak Adjust sweep generator & tumer to channel 10. T205 positions 45.75 marker INSTRUCTIONS Outer peak-recheck steps 6 and 7 T206 adjusts tilt of curve

Recheck steps 8-9 and 10

Note: Turn bottom T201 making this adjustment.

Outer peak

Outer peak Outer peak

INSTRUCTIONS

MOST-OFTEN-NEEDED 1954 TELEVISION SERVICING INFORMATION

INSTRUCTIONS

Correct adjustment of bus control is approx. middle of its range

Buss control for minimum buss

L201-T101 (top and bottom) for max.

Connect VTVM to emport of Mg

Tune 4.5 mc trap (L205) for misimu

VTVM

ş

Ground

0001


14		34
	- E	

CHASSIS 405 Models: F-21TOMH F-21COMH F-21CDMH F-21TOBH F-21COBH F-21CDBH CHASSIS 405-1 Models: F-21TOMU F-21COMU F-21 CDMU F-21COBU F-21TOBU F-21CDBU

CHASSIS 410 Models: F-17TOMH F-17COMH F-17TOBH F-17COBH CHASSIS 410-1 Models: F-17TOMU F-17COMU F-17TOBU F-17COBU

A UHF Converter with a continuous tuner that covers the seventy (70) UHF television channels (14 to 83) is included in the 405-1 and 410-1 chassis.

The material on the next eight pages is exact for models listed above. The sets listed below use chassis which are very similar to the ones covered and, therefore, this material can be used as an aid in servicing these additional sets. The main differences are in AGC circuit, tubes used in sync clipper and amplifier, and type of VHF tuner.




CROSLEY (Continued)

I. F. ALIGNMENT

All lead connections from the signal generator and wobbulator must be shielded. Keep the exposed ends and ground leads as short as possible (about one inch). Always locate the ground lead connections as close as possible to their respective "hot" leads in the television receiver chassis. The wobbulator, signal generator output, and contrast control must be kept low enough to prevent overloading the television receiver circuits.

1. TO CHECK I. F. ALIGNMENT ON OSCILLOSCOPE.

- a. Lift the shield of the Oscillator-Mixer tube V2 sufficiently to clear the socket ground clips. Connect sweep signal generator "hot" lead to the ungrounded tube shield and generator ground lead to the tuner chassis.
- b. Connect high side of oscilloscope to high side of contrast control, and the low side to chassis.
- c. Apply -3.0 volts D. C. bias to I. F. Bias line(see sketch "Variable Bias Control"). Contrast control should be set in the maximum counter-clockwise position.



NOMINAL OVERALL I. F. RESPONSE CURVE NOTE: Response as Seen by Means of Sweep Generator.

- d. With the generator sweep set at zero, connect an electronic voltmeter between top of detector load and chassis. Adjust the output of the generator to obtain a reading of 2 volts D. C. on the meter.
- e. Set generator to sweep from 20 mc. to 32 mc.
- f. Connect marker generator to sweep generator output leads and adjust to provide markers that appear in the curve. See nominal response curve.
- g. Observe curve and position of markers (see nominal response curve). Slight deviation in shape from the nominal response curve is permissible, but if any great deviation is noted, it will be necessary to realign the I. F. Amplifier.
- 2. ALIGNMENT, I. F. & TUNER ASSEMBLY (with electronic voltmeter):
 - a. Connect -3.5 volts D. C. bias supply to I. F. Bias line.
 - b. Connect signal generator "hot" lead through a 1000 mmf. capacitor to TP-1 (wire protruding from tuner closest to the oscillator mixer tube V2) and the ground lead to the R. F. tuner case.
 - c. Connect high side of Electronic Voltmeter to top of detector load resistor, R116, and low side to chassis; zero the meter.
 - d. Set signal generator to 24.4 mc. and adjust top of T101 for maximum D. C. meter indication on voltmeter. Adjust the signal generator amplitude to make this peak indication 2 volts D. C., approximately.

- e. Set signal generator to 22.9 mc. and adjust top of L103 for maximum D. C. meter indication, limiting meter deflection to 2 volts D. C. by adjusting input of attenuator.
- f. Set the signal generator to 21.9 mc. and adjust bottom of L103 for minimum D. C. meter deflection. Input should be high enough to permit a definite null to be observed on meter.
- g. Repeat steps "e" and "f".
- h. Set signal generator to 25.5 mc. and adjust top of L102 for maximum meter deflection, limiting meter deflection to 2 volts D. C. by adjusting input attenuator.

I-F Bias Line	
To minus (-) of 4 1/2 v. Battery	
and plus (+) of 4 1/2 V.	
Battery	
5000 Ohm Control only, Part No. 144260	

VARIABLE BIAS CONTROL ASSEMBLY

- Connect a 100 ohm resistor in series with a 1000 mmf capacitor across L101. With signal generator at 25.5 mc., adjust converter output, L10 of R.F. Tuner, for maximum meter deflection, but limit output of generator so this reading does not exceed 2 volts D.C. Remove the 100 ohm resistor and the 1000 mmf., capacitor.
- j. Reset signal generator to 27.9 mc. and adjust the bottom of L101 for minimum D. C. meter deflection. Signal generator amplitude must be sufficiently high to produce a definite null.
- k. Set signal generator to 24.4 mc. Connect the 100 ohm resistor and the 1000 mmf. series capacitor from TP-2 (wire protruding from the tuner through the insulated eyelet closest to L10) on the R. F. Tuner to the tuner case and adjust L101 for maximum D. C. meter indication, adjusting amplitude of signal generator to make this maximum indication approximately 2 volts D.C. Remove the 100 ohm resistor and the 1000 mmf capacitor.
- 1. Repeat steps "j" and "k".
- m. Check sensitivity. The input, to obtain 2 volts D. C. output with zero bias, should not exceed 650 microvolts at 24.4 mc. with generator properly terminated and generator fed into grid of first I. F. Amplifier.
- n. Remove the signal generator and electronic voltmeter.
- o. Note: When aligning bottom of L103 and bottom of L101 the first null obtained when running the core into the trap winding from the Tinnerman Clip end of the trap winding is the proper alignment null.

CROSLEY Chassis 405, 410, etc.

Alignment Continued

SOUND ALIGNMENT

- 1. Connect crystal controlled 4.5 mc. 400 cycle amplitude modulated signal, modulated 30% or greater, between grid of video amplifier and chassis.
- 2. Connect high side of scope through detector probe to the junction of R132 & C121 (picture tube cathode). Connect low side of scope to chassis. Adjust 4.5 mc. trap, L111, for minimum 400 cycle deflection on scope.
- 3. Connect electronic voltmeter to lug 2 of ratio detector, V107, and adjust 4.5 mc. sound take-off (L115) and bottom of ratio transformer (T102) for peak reading on


voltmeter. Adjust input to make this peak reading 4 volts.

- 4. Adjust input to obtain 12 volts output. Transfer electronic voltmeter to junction of R135 and R136 (refer to Schematic Wiring Diagram). Adjust top of T102 for zero balance on electronic voltmeter.
- 5. Recheck steps 2, 3 and 4 above.
- 6. Remove input signal, scope and electronic voltmeter.


HORIZONTAL HOLD ADJUSTMENT

- 1. Tune in a local television signal and adjust contrast control for normal picture.
- 2. Connect electronic voltmeter between TP-3 (green lead) and chassis.
- 3. Short TP-5 (red lead) to chassis and adjust electronic voltmeter to zero.
- 4. Remove short from TP-5. Do not change zero on electronic voltmeter.
- 5. Connect a 0.1 mfd. 600 volt capacitor between TP-4 (orange lead) and chassis.

- 6. Adjust Horizontal Hold control for zero reading on the meter.
- 7. Remove the 0.1 mfd. capacitor from TP-4 and chassis. Do not disturb setting of horizontal hold control.
- 8. Adjust Horizontal Stabilizer coil (L117) for zero reading on the meter.
- 9. Remove electronic voltmeter from TP-3.
- 10. Check horizontal pull-in range. The pull-in range should be approximately 50° of the control's rotation.



VHF TUNER SCHEMATIC




CROSLEY Chassis 405, 410, etc. (Material continued)

NOISE GATE CONTROL:

This control makes it possible to obtain improved picture stability in the presence of electrical interference (noise). When the control is turned completely counter-clockwise, its effect is minimized. Adjust the control by turning it clockwise until the picture is stable. If the control is adjusted on a signal of one strength, it may require readjusting when a signal of a different strength is received.

VHF OSCILLATOR ADJUSTMENT:

A turret type VHF tuner is used on this receiver, and there is an oscillator adjustment for each channel. When the receiver is installed, the oscillator should be adjusted for each channel on which a station is operating in the area. Set the Channel Switch to the channel that is to be adjusted. Turn the Fine Tuning control to the center of its range. The oscillator trimmer screw is directly to the right of the tuner shaft, and is accessible through a hole in the front of the chassis after the two VHF tuning knobs have been removed. Use a non-metalic screw driver and adjust the oscillator trimmer screw until the proper tuning point is in the center of the fine tuning range.





CROSLEY Chassis 405, 405-1, 410, 410-1 Part of this circuit diagram is shown on the preceding page. This division is made for printing convenience only and is not present physically.

DEFLECTION YOKE AND BRACKET:

The DEFLECTION YOKE BRACKET should be positioned as far forward as possible so that the rubber cushion on the front of the bracket rests on the flare of the tube.

The DEFLECTION YOKE should be positioned as far forward as possible on the picture tube neck and rotated to the left or right as required to make the picture parallel with respect to the top and bottom of window frame.





CROSLEY, Continued.

CIRCUIT CHANGES

ON CHASSIS 405, 405-1, 410, & 410-1*


The circuit shown in Fig. 1 appears only on those chassis bearing code letter "A". The circuit change, as shown in the complete schematic, was made in later production sets (Code B, etc.) to improve the contrast ratio.

Fig. 2 shows two capacitors (.005 mfd) that appear in chassis coded with the letter "A". These capacitors were found unnecessary and are not used in with later code letters.

The circuits in Fig. 3 & 4 are found only in the chassis coded A and B. The changes to the circuits shown on the complete schematic were production changes only, not design improvements.

Chassis 405, 405-1, 410, & 410-1 (Code B or later) have a provision for greater heat dissipation in the screen circuit of the 6BQ6. This is accomplished in two ways: (1) Part No. 156911-1 resistor is used for R183, for under test, this resistor shows more than its rated 2 watt heat dissipation ability. (2) Two resistors are used in place of one and are wired in parallel; one is a 33,000 ohm, 10%, 1 w. resistor (Part No. 39374-131), and the other is a 15,000 ohm, 10%, 2 w. resistor (Part No. 39374-215).

NOTE: In early production sets, R125B (Contrast Control) had a resistance of 1500 ohms. To reduce the total resistance, a shunt was added by wiring a 3300 ohm, 10%, 1/2 w. resistor (Part Number 39374-31) from terminal 1 to terminal 3 of the control. In later sets, R125B has a resistance of 1000 ohms.



* In early production, when a change was made to one of the above chassis, it was made to all of them; similarly, the same code letter was assigned to all chassis incorporating the same changes.




ALLEN B. DU MONT LABORATORIES, INC

RA-306, 307 CHASSIS

Service material on these chassis is printed below and through page 36. For convenience in printing, the circuit diagram is divided and printed on page 33 and across pages 34-35. This separation is not present in the physical sense in the actual chassis.


UNDERCHASSIS VOLTAGE POINTS





Du Mont Chassis RA-306/307, continued

(See page 36 for Alignment Test Points location drawing)

VIDEO IF ALIGNMENT RA-306/307 Place STATION SELECTOR between channels to disable oscillator. Remove the Horizontal Deflection Amplifier, V214, and Damper, V215. Connect a short length of wire to pin 5 of V102 (see figure 1). Use the lowest VTVM range for all steps. Signal Generator Output Connect to Adjust Step Frequency | Connect to Indicator P206 Pin 5, Z203 for maximum reading. 44.0 MC **V102** (Pin 2, V204) Set signal generator output to maintain VTVM 1 No reading on lowest range of VTVM. Sweep IVTVM 42.35 MC As Above As Above 2 No VTVM Z202 for maximum reading. (2) 2VTVM Sweep 44.85 MC As Above As Above 3 VTVM Z201 for maximum reading. No (3) **3VTVM** Sweep C202 for 41.25 MC trap. 43.5 MC As Above Pin 5, V201 5.75 MC Mixer plate coil (L109) and Oscillo-Center Z204 (top) for 45.75 MC araph 4 Freq. marker. Z204 (bottom) for through 10 MC (4) 4XTAI 42.25 MC marker. L210 XTAL deviation for 47.25 MC trap. 41.25 MC P206 Junction of Oscillo-(Pin 2, R217, R220, 4.5 MC graph L207 for minimum reading. S V204) and C216. 400 CPS through AM 5 XTÄL 5XTAL SOUND IF ALIGNMENT P206 Oscillo-.5 MC Pin 5, V209 4.5 MC (Pin 2, graph L208 and Z205 (bottom) V204) 6 1 MC through for waveform. Sweep 6XTAL XTĂĹ 6 P205 As Above (Junction of Oscillo-Z205 (top) for C241 & C242) 7 As Above graph waveform. 7 DIRECT 7DIR ALTERNATE SOUND IF ALIGNMENT - USING TV SIGNAL TV Signal, Teleset Pin 5, V209 L208 and Z205 (bottom) 6 must be tuned for VTVM for maximum reading. best picture. 6VTVM P205 (Junction of Z205 (top) for null point. VTVM 7 As Above C241 & C242) 7VTVM








WITH VEIR REMOVED OSC. DISABLED


NOTES

- All waveforms and voltages were taken under operating conditions. The receiver was tuned to an average strength TV signal, the Contrast control rotated fully clockwise and the Dumonitor control (agc) was adjusted for -7 volts at P204 the agc test point.
- volts at P204 the age test point.
 Voltages ± 20% of those shown are normal.
 All resistors are 10%, one-half watt, unless otherwise indicated.
- 4. W.W. indicates wire wound resistor.
- 5. All capacitors are 20%, 500V, unless otherwise indicated.
- All capacitors are ceramic, unless indicated as follows:

M-mica, P-Paper, ±-electrolytic MP-Molded Paper

- GI Tuner 89 012 901 is used in RA-306 chassis stamped G. GI Tuner 89 012 911 and filter N202 are used with UHF tuner 89 013 291 in RA-307 chassis stamped G. Chassis using Standard Coll tuner 89 012 971 are stamped S.
- The Tone Control R292B and the Phono-TV Switch S202 were installed in chassis beginning with serial numbers 3069001 and 3072338.







Model Numbers	Model Numbers TV Chassis		TV Tuner	
760D, 762D	120191-D	17L P4		
760H	120190-D (GLASS-RECT.)		470696	
732G, 742E	120185-В	21MP4		
767A, 771A, 773A	120192-В	(METAL-RECT.)	470696	
771D	120192-D	21YP4 (GLASS-RECT.)	470696	

The service material on the next eight pages is exact for models using chassis as listed above. This material is also applicable to the following additional models:

Models 752A, 755A, 784A, use Chassis 120174B, and Models 768A, 772A, 774A, use Chassis 120193B, which are almost identical to Chassis 120185B, with the main differences in the use of individual VHF and UHF tuners, and placement of 5U4G rectifier tubes.

Models 753D, 761C, use Chassis 120180D, and Models 753F, 785C, 785E, use Chassis 120198D, which are almost identical to Chassis 120191D described in this manual; the main difference is in type of tuners used.

SYMPTOM	CHECK
Weak or no sound nor video (picture), raster normal	V-22, V-23, V-1, V-2, V-3, V-4, *
Weak or no sound video and raster normal	v 22, v=23, v=1, v=2, v=3, v=4, *
(a) Volume control setting effects strength of sound or hum	V-6, V-7, V-8, V-9
(b) Volume control setting does not effect strength of sound or hum	V-9, V-10
Weak or no video - Sound and raster normal	V-5, V-24
Sound and raster normal. Picture takes more than a couple of minutes	<u> </u>
to come to full contrast, starts out silvery. In time picture may always	
be negative in appearance	∨-24
Poor or no horizontal nor vertical sync - sound and video normal	
(contrast control makes video darker or lighter)	V-11, V-17
Poor or no horizontal nor vertical sync - Video weak or distorted, raster	<u> </u>
normal - sound may or may not be normal	
Poor or no horizontal sync – raster normal and sound normal	V-22, V-23, V-1, V-2, V-3, V-4
(picture locks in vertically)	V-11, V-12, V-13, V-17
Poor or no vertical sync - raster normal and sound normal	<u>v=11, v=12, v=13, v=17</u>
(picture locks in horizontally)	V-11, V-17, V-18
Horizontal line (no vertical sweep) – sound normal	V-18, V-19
Insufficient horizontal size, sound and video normal	
Insufficient vertical size, or white horizontal bar in picture,	V-14, V-16, V-20, V-21
horizontal size OK	V-19
No sound, no raster – tubes lit	Fuse, V-20, V-21
No sound, no raster – tubes not lit	Plug connection in wall socket,
	ON-OFF switch, line cord.

TUBE TROUBLE ANALYSIS CHART FOR CHASSIS 120185-B, 120190-D, 120191-D and 120192-B, D

By raster we mean the illuminated scanning lines.

*Another very common fault is a shorted or open circuit antenna connection to set.

EMERSON Chassis 120185B, 120190D, 120191D, 120192B, -D, continued


ALIGNMENT


ALIGNMENT

- Equipment Required A sweep generator, (10 MC. sweep with center frequency of 44 MC. plus all necessary R.F. sweep frequencies as listed in R.F. Table), accurate marker generator, oscilloscope and V.T.V.M. are required for alignment. The marker generator must supply frequencies of 4.5 MC., 40 to 48 MC. and 50 to 216 MC.
- Alignment Points The location of all I.F. transformers, Tuned Circuits, and trimmers shown in Figure 14.

TV R.F. & MIXER ALIGNMENT

Connect 3 volt bias battery to both I.F. and R.F. AGC. circuits, positive terminal to chassis, negative terminal to junction of R-19, C-19, C-18. Add a jumper wire from this junction to junction of R-10, R-16, C-8 so that the bias battery is also applied to I.F. AGC.





SWEEP & MARKER GENERATOR		MARKER GEN.	OSCILLOSCOPE	MISCELLANEOUS		
CONNECTIONS	FREQ. RANGE	FREQ.	CONNECTIONS	INSTRUCTIONS	OR SLUG	AND OUTPUT INDICATION
Connect as shown in Fig. 10 and adjust sweep controls	Channel #12	205,25 MC.	Vert, input of scope through 10K resistor to test point on	NOTE Keep output of R.F. Marker Generator at a level that	C-2 R.F. Amp. Input Trimmer	Adjust Trimmers C–2, C–5 and C–6 to obtain response shown in Fig.11 IMPORTANT: When adjusting trimmers C–2, C–5 and C–6 it will
for width so that complete channel re-	207 MC. Center Freq.	Pix Carrier	tuner Fig. 14 Low side to chassis		C-1 I.F. Trap	be noted that the band pass char- acteristic can be broadened by sacrificing amplitude. It is unde-
sponse may be observed as shown in Fig, 11				curve that is being observed on the scope.	C-5 R.F. Plate Trimmer	sirable to overly broaden the curve as that would result in a loss of sensitivity.
					C-6 Mixer Grid Trimmer	C-1 should normally be set at maxi mum capacity (screw all the way in unless interference is encountered. (See note below)
	#13 213 MC.	*215.75 MC. **211.25 MC.	Same as Above	Set Channel Selector to #13 (See Note Above)	The r-f band pass characteristic of the other television channels should now be checked without disturbing the settings of trimmers C-2, C-5 and C-6. Adjust the r-f sweep g erator and marker generator for operation the other television channels, observing po tion of both the sound carrier and picture of rier markers.	
	#11 201 MC.	*203.75 MC. **199.25 MC.		Set Channel Selector to #11 (See Note Above)		
	#10 195 MC.	*197.75 MC. **193.25 MC.		Set Channel Selector to #10 (See Note Above)		
	#9 189 MC.	*191.75 MC. **187.25 MC.		Set Channel Selector to #9 (See Note Above)		
	#8 183 MC.	*185.75 MC. **181-25 MC.		Set Channel Selector to #8 (See Note Above)		
Same	#7 177 MC.	*179,75 MC. **175,25 MC.		Set Channel Selector to #7 (See Note Above)		
Above	#6 85 MC.	* 87.75 MC. ** 83.25 MC.		Set Channel Selector to #6 (See Note Above)	RELATIVE	
	#5 79 MC.	* 81.75 MC. ** 77.25 MC.		Set Channel Selector to #5 (See Note Above)	NOT	E CHANNEL CARRIES BUST RESPONSES MUST NOT LIT HORE THAN 10% FALL WEDE SHADED BELOW THE PEAN. ANEL
	#4 69 MC.	* 71.75 MC. ** 67.25 MC.		Set Channel Selector to #4 (See Note Above)	1	I TUNER RESPONSE CURVE SHOWING BAND-PASS LIMITS.
	#3 63 MC.	* 65.75 MC. ** 61.25 MC.		Set Channel Selector to #3 (See Note Above)	the require	use for all channels should meet with ements of Fig.11. To do so it may be to compromise by slightly changing
	#2 57 MC.	* 59.75 MC. ** 55.25 MC.		Set Channel Selector to #2 (See Note Above)	the initial	channel #12 adjustments of C-2, C-6 while switched to channel which

*Sound Carrier Marker **Picture Carrier Marker NOTE: C-1 IS AN I.F. TRAP AND CAN BE ADJUSTED IN THE FIELD TO REDUCE ANY INTERFERENCE WHICH MAY AFFECT CHANNEL #2 FROM A NEARBY TRANSMITTER OPERATING IN THE 40 MC. BAND.

EMERSON Chassis 120185B, 120190D, 120191D, 120192B, -D, continued

I.F. ALIGNMENT

1) Tune receiver to unused Channel 10 or 12.

- Connect 3 volt bias battery with negative terminal to I.F. AGC. (Junction R-10, C-8, R-16) positive terminal to chassis.
- 3) Connect D.C. V.T.V.M. to video test point (see location in Fig. 13 and 14).
- 4) Connect terminated marker generator to floating shield of converter tube V-23 6J6. (Shield raised slightly so that it does not make contact with chassis). Use unmodulated marker. See Fig. 13.

MARKER GENERATOR	ADJUST	PROCEDURE
45.75 MC. Unmodulated	T-4	
43.2 MC. Unmodulated	T-3	Peak for maximum response. Adjust output of signal generator so that maximum response does not produce more than -2V. D.C. on V.T.V.M.
42.0 MC. Unmodulated	T-2	
45.0 MC. Unmodulated	L-3 T-1	
41.25 MC. Unmodulated	L-2	Adjust trap for minimum response. Increase output from signal generator so that a true minimum position can be found.

5) Connect vertical input of an oscilloscope instead of V.T.V.M. to video test point with vertical scope gain set at, or near, maximum. (Horizontal scope sweep set at 400 cycles).


MARKER GENERATOR	ADJUST	PROCEDURE
47.25 MC. 400 Cycles Amp. Mod.	L-1	With signal generator set at maximum output, adjust L-1 for minimum vertical re- sponse on scope.

6) Now that all the I.F. coils and transformers have been set, the overall response can be observed and adjusted if necessary.

SIGNAL GENERATOR INPUT						
	FREQU	IENCY	MEASURING INSTRUMENT ADJUST	PROCEDURE		
CONNECTION	SWEEP	MARKER				
Connect terminated sweep and marker as shown in Fig.13.	Center frequency 44 MC. 10 MC. Sweep	45.75 MC.	Scope connected to Video Test Point	T-4	If 45.75 MC. doesn't lie from 60 to 70% down adjust T-4 (see fig 12) for tolerances. *	

Providing overall curve is within tolerances as shown below, no further adjustments are needed. If band width or tilt is not as specified, repeat entire alignment procedure. If still out then a slight retouching is permissible. TRAPS L-1 and L-2 MUST BE ADJUSTED AS INDICATED ABOVE. DO NOT RE-ADJUST WHILE OBSERV-ING OVERALL 1.F. RESPONSE CURVE.

*KEEP OUTPUT SIGNAL GENERATOR AS LOW AS POSSIBLE WHEN OBSERVING THE OVERALL I.F. SHAPE SINCE TUBE OVERLOAD MIGHT RESULT AND THE RESPONSE WILL APPEAR INCORRECTLY FLAT AND WIDE.



NOTE: It may be impossible to observe the 47.25 MC. marker with the average service equipment due to the high attenuation of trap L-1 (adjacent sound).

EMERSON Chassis 120185B, 120190D, 120191D, 120192B, -D, continued





Figure 13. CONNECTIONS FOR I.F. ALIGNMENT.

All instrument leads should be dressed as directed and as short as possible to prevent interaction between input and output leads. Failure to do this may result in an un-stable response indication.

NOTE: It is important that the output cable of the sweep and marker generator be properly terminated in their characteristic impedance which is usually from 50 to 75 ohms. If this termination has not been built into the end of the cable by the instrument manufacturer then a resistor of the proper value (characteristic impedance) should be connected across the output of each generator cable as shown above.



EMERSON Chassis 120185B, 120190D, 120191D, 120192B, -D, continued

R.F. OSCILLATOR ALIGNMENT (V.H.F.)

- 1. Connect marker and sweep generator as shown in Figure 10, low side to chassis.
- 2. Connect scope to video test point (see location Fig. 13 and 14).
- 3. Connect 3 volt bias battery as described under R.F. Alignment
- 4. Before undertaking oscillator alignment be sure 1.F. circuits are correctly aligned for band pass characteristic and trap settings.
- 5. During oscillator alignment, it is necessary to set the fine tuning control so that the tooth on the fine turning cam points downward.

MARKER SIGNAL GENERATOR FREQUENCY	SWEEP GENERATOR FREQUENCY	MISCELLANEOUS IN STRUCTIONS	TRIMMER OR SLUG	TYPE OF ADJUSTMENT AND OUTPUT INDICATION	
*209.75 MC. **205.25 MC.	Channel #12 Center Frequency 207 MC. 10 MC. Sweep	Be sure that fine tuning control has been properly positioned (tooth on the cam pointing down) NOTE During this step and thru-out all suc- ceeding steps it is necessary to: 1. Keep output of sweep generator at a level that does not allow the reading on a VTVM to exceed minus 1 volt when connected across video detector load at minimum sweep width.	Adjust Slug A-12	NOTE: Before making the following adjustment, advance the vertical gain control on the scope in order to magnify the sound trap portion of the re- sponse curve. Then, use a non-metallic screwdriver to adjust channel #12 oscillator slug (accessible thru hole on front of r-f tuner unit) and shift response curve so that sound carrier marker is located at the position indicated below. Now reduce gain control setting of scope to re- store pattern to normal amplitude and observe position of picture carrier marker. This marker	
		 Keep output of standard signal gen- erator at a level that provides a readable marker but does not distort the curve that is being observed on the scope. 		should appear on the high frequency side of the characteristic curve. The amplitude of the pic- ture carrier should be between 60 and 70% down from peak response.	
*215.75 MC.	Channel #13 213 MC.	Set Channel Selector to #13 (See note above)	Adjust the eration on	r-f sweep generator and marker generator for op- other television channels; set marker generator to	
*203.75 MC.	Channel #11 201 MC .	Set Channel Selector to #11 (See note above)	sound carri responding	er frequency . After setting Channel Selector to cor- channel, adjust ascillator slug thru hole on front of hit. (A-2 to A-13)	
*197.75 MC. *193.25 MC.	Channel ≢10 195 MC .	Set Channel Selector to #10 (See note above)	This permit	is response curve to be shifted so that sound carrier l appear at the position indicated below.	
*191.75 MC. *187.25 MC.		Set Channel Selector to #9 (See note above)			
*185.75 MC. *181.25 MC.	Channel #8 183 MC.	Set Channel Selector to #8 (See note above)		то	
*179.75 MC. *175.25 MC.	Channel #7 177 MC.	Set Channel Selector to #7 (See note above)			
* 87.75 MC. * 83.25 MC.		Set Channel Selector to #6 (See note above)		45.75 MC. SOUND I.F.	
* 81.75 MC. * 77.25 MC.		Set Channel Selector to #5 (See note above)	-		
* 71.75 MC. * 67.25 MC.	Channel #4 69 MC.	Set Channel Selector to #4 (See note above)		41.25 MC.	
* 65.75 MC. * 61.25 MC.	Channel #3 63 MC.	Set Channel Selector to #3 (See note above)		TYPICAL OVERALL RESPONSE CURVE	
* 59.75 MC.	Channel #2 57 MC.	Set Channel Selector to #2 (See note above)		erly positioned during this step (tooth on the cam	

response curve for that channel (as described in R-F Amp. and Mixer Alignment Table). If characteristic curve does not conform reasonably well within the typical curve shown in Figure 11, then do the following things:

1. Check method of connecting scope, voltmeter and generator leads to eliminate possible distortion of observed response, or:

 Attempt to obtain a better compromise for R.F. response on all channels by realigning R-F Amp. and Mixer circuits, or:

3. Try replacing Antenna, R-F and Oscillator coils for the particular channel.

*Sound Carrier Marker

**Picture Carrier Marker

R.F. OSCILLATOR ALIGNMENT PROCEDURE

EMERSON Chassis 120185B, 120190D, 120191D, 120192B, -D, continued

SOUND ALIGNMENT

- (A) USING 4.5 mc UNMODULATED SIGNAL GENERATOR
 - Short pin #1 of V-3 to Chassis with short jumper wire.
 - Keep output of signal generator low so as to provide a sharp meter indication with adjustment of transformers.
- (B) USING TRANSMITTED TV AIR SIGNAL
 - Connect antenna and tune to a good on the air TV station.
 - 2) Adjust fine tuning control for best picture.
 - Adjust antenna coupling for moderate signal so as to provide a sharp meter indication with adjustment of transformers.
 - Meter reading may pulsate due to changes in signal strength; do not confuse with a peak adjustment.

STEP	SIGNAL GENERATOR INPUT		MEASURING	TULDA	PROCEDURE
	CONNECTION	FREQUENCY	INSTRUMENT	~~~~~	
1	Matker Gen. through .01 MF to Pin 7 of V-4 low side to chassis. - or - Connect antenna and tune in a good trans- mitted TV. signal (any channel)	4.5 MC (Unmodulated) - or - A good on the air TV, channel	Connect D.C. V.T.V.M. (negative scale) through 10K Resistor to Junction of C-30, R-35, R-36 – low side to chassis,	T-5 Top or Bottom T-6 Top ond Bottom	If T.V. signal is used adjust ant, coupling to receiver to produce
2	Same as above.	Same as ab ove.	Connect V.T.V.M. through 10K Resistor to Junction of R-44, C-34 – low side to chassis.	T-7 Top and Bottom (Dis- crimi- nator)	 A) Detune Discriminator secondary T-7 (Top Pt. #708018, 708151; Bottom Pt. #708017) for maxi- mum negative meter reading. B) Adjust primary T-7 for maximum negative meter reading. C) Readjust Discriminator secondary (towards original setting) for zero D.C. reading on V.T.V.M. D) Check Audio, if distorted repeat steps A - C.

* The noise voltage is measured under no signal conditions (antenna terminals shorted directly at tuner by means of a short jumper wire; or disconnect 4.5 MC. generator if procedure (A) above is followed.)

4.5 MC VIDEO TRAP ALIGNMENT (L-12)

- 1. Connect crystal controlled 4.5 mc. signal generator through a .01 mf. condenser to the grid of the video amplifier tube (Pin 1 of V-5, 6CB6) low side to chassis.
- 2. Set contrast control for maximum contrast (fully clockwise).
- 3. Connect a V.T.V.M. (D.C. scale) through an R.F. probe to the cathode of the picture tube (Pin 11, yellow lead) low side to chassis.
- 4. Adjust the 4.5 mc. trap L-12 for minimum reading on the V.T.V.M.

If a crystal controlled generator is not available the video trap can be adjusted in the field by setting the fine tuning control for maximum 4.5 mc. in picture and adjusting the 4.5 mc. trap (L-12) until this 4.5 mc. beat note is reduced. Be sure that video ringing is not introduced from this adjustment since this indicates the trap was aligned at too low a frequency.

REPAIR OF TUNER

The majority of tuner troubles which are not due to defective tubes can usually be detected by a physicol examinotion of the tuner (turret removed), such as burnt resistors, broken parts, bent or dirty contact fingers, cold solder joints, broken socket pins, etc.

It should always be borne in mind that a burnt resistor is usually the result of a shorted condenser or tube.

The part numbers of items which are not generally commercially available are given on the tuner schematic. When replacing parts, leads should be kept os short as possible and components replaced in the same positian as the original parts.



EMERSON Chassis 120185B, 120190D, 120191D, 120192B, -D, continued





Figure 17 - SCHEMATIC DIAGRAM OF TURRET TYPE TUNER USED ON CHASSIS 120185-B, 120190-D, 120191-D AND 120192-B, D





Model Numbers	TV Chassis	Tube Size	TV Tuner
741F, 757D	120182-D	17LP4 (GLASS - RECT.)	VHF - 470696
781A, 781B	120196-B	21MP4 (Metal - Rect.)	VNF = 470890
784 E	120197-B	21MP4 (Metal - Rect.)	
784G	120197-0	21YP4 (GLASS - RECT.)	VHF - 470712 UHF - 470729
785K	120195-D	17LP4 (GLASS - RECT.)	

For circuit diagram see the next page, over. Alignment procedure for these sets is the same as for earlier sets covered in the 1953 Television Manual, and you are referred to pages 50 to 54 of this volume (TV-7) for alignment information.

BRIEF CIRCUIT DESCRIPTION

The above chassis incorporate a 40 mc I.F. intercarrier system. The 4.5 mc intercarrier sound signal which is developed in the video detector is fed back to the grid of V-2 where it is amplified along with the regular video and audio I.F. signals are then fed to the sound limiter (V-6). This system is known as "sound reflex" and is accomplished by incorporating two resonant circuits in the plate and two resonant circuits in the grid of V-2. One set of plate and grid circuits resonates at the 40 mc video I.F. frequencies and the other set at the intercarrier sound frequency (4.5 mc). C-7 resonates with the secondary of T-5 to form the 4.5 mc grid resonant circuit of V-2.

To operate the R.F. amplifier at maximum gain at low signal levels delayed A.G.C. is applied to the tuner.


The output of the video amplifier (V-5, 6CB6) not only drives the cathode of the picture tube but also feeds the composite video signal to the grid circuit of the sync separator tube (1/2 V-8, 12AX7). Since the polarity of the video signal is such that the sync tips drive the grid of V-5 in a negative direction strong noise pulses of greater amplitude than the sync will drive the grid to cutoff and will, therefore, be clipped in the plate circuit of this tube. This effect greatly improves sync stability in electrically noisy weak signal areas.

ALIGNMENT OF MIRACLE PICTURE LOCK (Horizontal Oscillator and A.F.C.)

This can be accomplished without removing chassis from cabinet.

- 1- Tune set to a channel known to be good.
- 2- Short phasing coil by using a clip lead across phasing coil terminal strip located on top of chassis next to horizontal oscillator tube.
- 3- Rotate horizontal hold control fully clockwise.
- 4- Starting with horizontal frequency slug all the way out, rotate in until picture just locks into sync. (Turn slug in 1/2 turn more).
- 5- Adjust horizontal size if necessary; if picture falls out of sync. repeat Step 4.
- 6- Adjust centering so that right hand edge of picture is visible while facing front of set (see Figure #1).
- 7- Decrease contrast and turn up brightness while viewing a good picture so that the horizontal blanking porch is visible (see Figure #1) on right hand side of picture.
- 8- Remove the short across the phasing coil. If the picture falls out of horizontal sync. adjust the phasing coil to re-sync. the picture and then carefully continue to adjust the phasing coil so that the start of the horizontal sync. pulse is just visible at the end of the front blanking porch. (see Figure #2). It should be noticed that the sync. pulse is darker than the front blanking porch but not quite as dark as the unlit portion of the picture tube.

END OF PICTURE	END OF PICTURE	
END OF SCAN	BLANKING FRONT	
BLANKING FRONT	SYNC. PULSE JUST Starts to show	
SYNC. PULSE	UNLIT TUBE	AE
FIGURE 1	FIGURE 2	-





TELEVISION RECEIVERS MODELS 2117 & 2118

This material is exact for Models 21T7 and 21T8. Models 21C225 to 21C333, 21T20, and 21T21, are similar, but waveform voltages may differ somewhat.

TROUBLE SHOOTING

In many cases a circuit difficulty may be localized by observing the picture or test pattern and by noting the presence or absence of sound. In general, the tubes in defective circuits should be checked first since this check does not take much time and the probability of failure is higher in tubes than in components. When substituting tubes in r-f or video i-f circuits, the original tube should be replaced in the socket if it is found to be satisfactory.

General Service Information

I. CRITICAL LEAD DRESS

To prevent the effects of undesired 4.5 mc harmonic radiation, it is essential that all audio and video i-f components be replaced in exactly the same position they occupied when they were wired in at the factory. All r-f, video and sync carrying leads should be made as short as possible. Check lead dress of picture tube anode lead to prevent high-voltage arc-over.

2. NOISE INVERTER CHECK

C. No vertical deflection

A simple oscillographic check may be performed which will display the operation of the noise inverter. The procedure is based upon noise pulse inversion in the absence of signal. 1. Turn on receiver. Set channel selector switch to an unoccupied channel.

- 2. Connect oscilloscope to Junction of C303 and C304.
- 3. Bias off the noise inverter (V115B) by connecting a 100,000ohm resistor between its pin No. 3 and +250 volts.

4. Supply a moderate-amplitude noise signal to the antenna input terminals. A suitable noise source would be an electric shaver or similar "spark" type noise generator.

5. Observe positive polarity of noise pulses on oscilloscope. Removal of the temporarily added 100,000-ohm resistor should cause the noise signal to reverse itself and hence become negative in polarity.

3. KEYER TUBE CHECK

The proper operation of the AGC Keyer tube V108B may be checked by shorting pins 2 and 7 and observing the AGC voltage. This voltage should reach a value of 40 volts as measured at the AGC terminal of the R-F Tuner (see Fig. 19).

	SYMPTOM	CHECK FOR
		DEFECTS OF THE SYNC SECTION
Ā.	Weak or no horizontal sync; vertical sync, picture and sound satisfactory	 Sync amplitude at input to discriminator tube, V119A Bias and plate voltage on control tube, V119B Sine-wave oscillator components, L351, C361, C357, R358 and R359 Leaky or shorted capacitors, C354 and C355 Waveform feedback components, C364, R365, R366 and C365
B .	Weak or no composite sync, otherwise picture and sound normal	 Defective coupling capacitor C303 or C304 to clipper tube Incorrect value of plate resistor, R312 of clipper tube, V116A Insufficient amplitude of composite signal applied to sync amplifier from video detector; check video detector circuit
C.	No vertical sync, horizontal sync satis- factory	 Sync pulse at input of vert. oscillator, check integrator plate P301 Vert. oscillator frequency, if far off from 60 cps, check vert. oscillator components such as C311 and R317 Leakage in feedback capacitor, C315
D.	Picture displaced to left, right edge wavy	1. Open or low value of capacitor, C304
E.	Horizontal sync out, bright bar or bars in picture	 Shorted, open or leaky capacitor, C360 Improper value resistor, R361
F.	"Gear Tooth" effect	 Open or low value capacity of C356 Open or high resistance of R357
	DEFECT	IS OF THE VERTICAL DEFLECTION CIRCUIT
Ā.	Poor vertical linearity, inadequate height	 Low emission of sweep output tube, V118 Improper grid input "drive" voltage at V118 Defective sweep output transformer T301 Low B+ voltage to sweep output tube V118 Low value of cathode capacitor, C402C
B .	Inadequate picture height	 Rise in resistance value of vert. oscillator plate resistor, R319 or R374 Leakage in capacitor C312 Incorrect value of plate, or grid voltages on output tube, V118

4.

5.

1.

2.

3.

in poor linearity)

Weak vertical deflection tube, V117 or V118


Open vertical deflection coils, D301


Shorted capacitor C312, C314

4. Poor contacts in yoke plug

Continued on Defective sweep output transformer, T301 pages 48 to 52.

Low value capacitor in cathode of vert. output tube, C402C (This usually results





040

240

0

Ci39

R-F INPUT WAFEF Ш

B+ TO

Fig. 19. R-F Tuner Terminal Board

C138

GENERAL ELECTRIC


RECEIVER ALIGNMENT (Cont'd)

AUDIO I-F ALIGNMENT

NOTES:

1. Tune in a television signal. This will provide a 4.5 mc sig-nal source for audio alignment. Keep the Volume control turned down unless the speaker is connected.

2. Figure 21 shows a simple resistor network needed for the alignment of T202 secondary. These two 100K resistors should be chosen as accurately as possible, for equal resistance. Be sure to remove these resistors after completing the alignment. Align as follows:



AUDIO I-F ALIGNMENT CHART

STEP	CONNECT VTVM OR 20,000 OHMS/VOLTMETER	ADJUST	METER	REMARKS	
1	To test point VI and chassis.	L157 and T201 (top and bottom cores).	Adjust for maximum deflection.	Voltage to be read is negative with respect to chassis.	
2	V113A, pin 2 and chassis.	T202 primary (bottom core).	denection.	with respect to chaosis.	
3	Test Point VII and center of two 100K resistors. See Fig. 21.	T202 secondary (top core).	Adjust for zero volts d-c output.	Repeat steps 1, 2 and 3 to assure proper final adjustment.	

L106 TRAP ADJUSTMENT

ALIGNMENT OF LIDE I-F TRAP

The trap, L106 (Fig. 18) is incorporated in the r-f tuner to remove or attenuate any interfering frequency in the i-f range. The trap should be aligned by tuning for minimum i-f channel interference pattern on the screen. If the interference is intermittent and the interfering frequency is known, L106 may also be aligned by the use of a calibrated signal generator.

NOTES:

1. Connect 3 volts bias from the AGC line on the r-f tuner (see Fig. 19) to chassis with the positive terminal of the battery connected to chassis. 2. Use an accurate marker generator to furnish a signal of the same frequency as the interfering frequency and a sweep generator with its center frequency set approximately at the interference frequency. Connect the scope to view the response curve at the output of the video detector.

3 Use the GE-ST-8A balanced adapter and a 3-foot piece of 300-ohm transmission line to couple the r-f sweep to the antenna terminals of the receiver.

4. Be sure not to tune the trap so that it will attenuate channel No. 2.

L106 ALIGNMENT CHART

Marker	Sweep Frequencies	Observe Response	Channel Switch	Adjust
Frequency	and Input Point	Curve at	Setting	
Interference frequency	40 to 50 mc to antenna terminals	Test Point IV	2 .	Core of L106 for minimum amplitude of curve at marker

RECEIVER ALIGNMENT (Cont'd)




Fig. 15. I-F Sweep Equipment Connection Diagram

VIDEO I-F ALIGNMENT

Introduction:

The following alignment data is divided into two separate procedures. Because of the extremely high adjacent channel trap attenuation, the conventional method of sweep observation of these traps becomes difficult.

The second portion of this procedure involves the shaping of the i-f response curve in the conventional manner by the application of a sweep generator signal. During this procedure, observe the usual precautions regarding warm-up time, equipment cable lead dress and generator output cable termination, see Fig. 15.

TRAP ALIGNMENT


In many cases, the technician will have a suitable AM signal generator available. It should cover the range of 37 to 48 megacycles at fundamental frequency, with available internal 400cycle modulation. When this type of signal is used, the traps should be adjusted for minimum 400-cycle signal as observed on the oscilloscope.

Owners of General Electric sweep alignment equipment may obtain the required amplitude-modulated carrier frequencies by a simple manipulation of the equipment controls as noted below.

Those technicians who do not have either of the above equipment available are advised to omit the trap alignment procedure. With the exception of the video amplifier 4.5 mc trap L160, the traps will not become seriously mis-aligned due to tube changes. The above-mentioned 4.5 mc trap may be sweep-aligned, if desired, in which case a 4.5 mc sweep signal should be used in step 2, of trap alignment chart.

Obtaining AM Output from G-E Sweep Equipment

The General Electric ST-4A Sweep Generator will provide 60cycle square-wave amplitude-modulated signal. To obtain this signal proceed as follows:



 Turn the sweep generator sweep width control fully counterclockwise. This will provide a steady (zero sweep) carrier.
 Turn the sweep generator blanking switch "on." This will

3. The next step is to calibrate the frequency of this AM

carrier.

a. Turn the marker generator "on" and set the dial to the desired frequency (4.5 mc, 38.0 mc, 41.25 mc or 47.25 mc).

b. Slowly tune the sweep generator through the desired frequency. As the desired frequency is approached, a strong beat signal will be observed on the oscilloscope. At *exact* resonance, a zero beat condition will be noticed, on each side of which will appear a beat pattern. Minor sweep generator back-and-forth frequency drift may be noted. However, this drift is insignificant and may be disregarded.

c. Turn off the marker output.

4. Apply this AM signal according to the instructions in the chart on page 52.

5. The signal observed on the oscilloscope appears as two parallel lines. When the traps are properly tuned the distance between these lines will be at a minimum. NOTE: It may be necessary to use full output of the sweep generator and near maximum oscilloscope gain to observe proper trap tuning.

ALIGNMENT NOTES:

1. Remove V121 plate cap. Temporarily connect a 2500-ohm, 25-watt resistor from B + 260 V to Chassis.

2. Remove tube V115 from its socket.

3. Turn the Volume control to minimum and the Picture Contrast control to maximum. Turn the Brightness control fully counterclockwise.


POINT

R172


4. Set Channel Selector to channel 11 position. Set the Fine Tuning control to its maximum counterclockwise position.

5. Connect oscilloscope to test point V (picture tube grid).

6. Allow receiver and test equipment to warm up for 15 minutes. Refer to Fig. 22 for alignment adjustments location.








GENERAL ELECTRIC

RECEIVER ALIGNMENT (Cont'd)



TRAP ALIGNMENT CHART

GENERAL:-

Now that the traps have been set at their proper frequencies the i-f curve may be shaped.

NOTES-

1. Turn Picture Contrast control to minimum. 2. Connect oscilloscope to test

point III (junction of R164 and R165).

3. Apply a negative 4½-volt battery bias voltage to test point

I-F SYSTEM SWEEP ALIGNMENT

VIII. Connect positive lead of battery to chassis. 4. Calibrate the vertical gain of the oscilloscope to provide a 2-inch deflection with applied signal, 1³/₄ volts peak-to-peak.

5. Note that the following procedure uses 45.0 mc as the 100% reference point. Maintain the sweep generator output so that the baseline-to-45.0 mc marker amplitude equals 2 inches. Align as indicated in the alignment chart below.

I-F ALIGNMENT CHART

STEP	CONNECT SWEEP GENERATOR	A DJUST	DESIRED RESPONSE	REMARKS
1	Into Test Point II and chassis through .001 mf ca- pacitor. Center sweep fre- quency approx. 44.0 mc. Sweep width approx. 10 mc.	T151 for proper 42.0 mc response. T153 for proper 45.75 mc response. T152 & L167 for zero "tilt" and maximum gain without "saddle-back."	41.25 MC 42 MC 40% 55% 43.75 MC 42.5 MC 85% 45 MC- 100%	Make indicated adjustments to obtain maximum gain con- sistent with proper curve. Cor- ners of curve peak must show slight rounding. Peak of curve may extend 10 % (max.) beyond 45.0 mc marker.
2	Into Test Point I and chassis through .001 mf capacitor. Center sweep frequency approx. 44.0 mc. Sweep width approx. 10 mc.	L154 and T105 (R-F Tuner) for maximum gain and proper marker position.	41.25 MC 42 MC 35% 45% 45% 45.75 MC 42.5 MC 80% 45 MC 100%	Obtain maximum gain and proper marker positions. Peak of curve should extend 15% beyond 45.0 mc marker, with slight rounding.
3	Into R-F Tuner input through balanced adapter and 300-ohm pad and line.	C108 (R-F Tuner)	Align for zero "tilt" on ch. 10. Check chs. 7-13 and make further compromise adjustment so that each channel will have no more than $\pm 20\%$ "tilt" with the Fine Tuning ad- justed to provide the proper sound and picture i-f markers.	
4	Sweep channels 2-13. Sweep width approx. 10 mc.	L124 & L127 (R-F Tuner)	Align for zero "tilt" on channels 3 and 5. Check chs. 2–6 and make further compromise adjustment, so that each channel will have no more than $\pm 20\%$ "tilt" with the Fine Tuning adjusted to provide the proper sound and picture i-f markers.	

hallicrafters

C1400D

24" or 27"

UHF/VHF

D1400D 24" <u>or 27"</u>

VHF

A1400D 21" UHF/ VHF

CHASSIS IDENTIFICATION

B1400D

21"

The first two digits of the model number indicates the picture tube size while the last letter indicates the cabinet finish. A mahogany cabinet has an M suffix while a blonde cabinet has a B suffix.

CHASSIS NO.	MODELS CHASSIS MAY BE USED IN
A1400D	21K201B, 21K211M, 21K221B, 21K231M
B1400D	21K200B, 21K210M, 21K220B, 21K230M
C1400D	24K241M, 24K241B, 27K251M, 27K251B
D1400D	24K240M, 24K240B, 27K250M, 27K250B


The circuit of B1400D chassis is printed on pages 54-55. Chassis A1400D also uses a 21" picture tube and is practically the same as the B1400D except that provisions are included for UHF reception. Chassis C1400D and D1400D use either 24" or 27" picture tubes and are very similar to 21" chassis. The I.F. chassis are practically identical and the circuit differences will be found in the deflection circuits where circuit changes were required in order to obtain higher deflection voltages for the 24 and 27-inch picture tubes and also a higher second anode voltage. The alignment information applies to all 1400D chassis. This service material is continued through page 58.

POWER SUPPLY & I, F. CHASSIS - The Hallicrafters 1400D series television chassis are composed of two basic chassis which are bolted together by means of a single bracket in the rear and the dial support bracket in the front. One chassis contains the VHF tuner, the UHF tuner and cascode i-f amplifier if the chassis has UHF provisions, all four i-f stages and the video detector, sound i-f amplifiers, ratio detector and two audio stages, AGC tube, video amplifier, and sync clipper stage. This chassis will be referred to in this service manual as the I.F. CHASSIS.


The other chassis contains two rectifiers in a transformer type power supply for both chassis. Two 5U4G tubes are used in a full wave rectifier circuit. This chassis also contains an additional stage of sync clipping, the vertical oscillator and output stages, horizontal AFC tube, horizontal oscillator and output stages, damper tube, and high voltage rectifier. This chassis will be referred to in this service manual as the POWER SUPPLY CHASSIS.

The two chassis are connected together electrically by a nine pin plug and socket, a three pin plug and socket, and a single shielded plug and socket. The nine pin plug and socket is used primarily for supplying the I.F. CHASSIS with 150, 270, heater and bootstrap voltages. One pin is used for feeding the brightness and the retrace blanking voltages to the grid of the picture tube and one is used for feeding the sync signal from the sync clipper stage in the i-f chassis to the sync clipper stage in the power supply chassis. The three pin plug and socket is used for feeding the output from the ratio detector to the volume control, which is mounted in the power supply chassis, and then back to the audio amplifier stages in the i-f chassis. The single shielded plug is used to feed the pulse from the horizontal output transformer to the plate circuit of the AGC tube.






HALLICRAFTERS 1400 Series, continued



HALLICRAFTERS 1400 Series, continued

HORIZONTAL OSCILLATOR ADJUSTMENT

- 1. Turn the channel selector to the strongest station that can be received and tune it for the best possible picture.
- 2. Connect the d.c. test probe of a zero center scale vacuum tube voltmeter to test point (I)(V-315 pin 1).
- 3. Set the horizontal hold control (R-334) in the center of the range over which it may be rotated.
- 4. Adjust the horizontal oscillator coil (L-302) adjustment screw until the picture is in sync and a zero d.c. voltage is indicated by the vacuum tube voltmeter.




HALLICRAFTERS 1400 Series, continued

4.5 MC TRAP ADJUSTMENT & FM SOUND CHANNEL ALIGNMENT

EQUIPMENT REQUIRED

- Signal generator capable of delivering approximately a 1 volt unmodulated signal between 4 and 5 megacycles.
- 2. Vacuum tube voltmeter (VTVM).
- 3. Test circuit shown in Fig. 616A.

PROCEDURE




100.000

47 MMF



- 1. Disconnect the 1N64 video detector diode from terminal (F) in the top of T-101. CAUTION Crystal diodes are very easily damaged by excessive heat. Hold the lead between the diode and the terminal with a pair of pliers to help dissipate heat when removing the solder connection to terminal (F).
- 2. Connect the hot lead from the signal generator to terminal (F) from which the diode was disconnected. A 3300 ohm resistor should be connected in series with the generator lead and terminal (F). Set the generator to 4.5 MC.
- 3. Connect the detector circuit shown in Fig. 616A. to pin 11 (yellow wire) of the picture tube.
- 4. Adjust the generator output (unmodulated) to give a 1 volt reading on the VTVM.
- 5. Adjust the 4.5 MC trap (L-111) in the video amplifier grid circuit for a minimum VTVM reading. Use the setting nearest the outer limit of the adjusting screw. Increase the output of the generator as required to maintain a usable VTVM reading.
- 6. Remove the detector circuit and connect the VTVM to terminal (G) (V-110 plate pin 2).
- 7. Adjust L-116 and the bottom core of T-102 at 4.5 MC for a maximum VTVM reading.
- 8. Connect the VTVM to test terminal (H) shown in the schematic diagram. Adjust the secondary of T-102 (top core) at 4.5 MC for the zero reading which occurs between the positive and negative peaks. If the zero reading occurs at more than one setting, use the position nearest the top limit of the core.
- 9. Shift the signal generator an equal amount on either side of 4.5 MC and touch up the primary of T-102 (bottom core) for approximately equal peaks. Use just enough signal output to obtain one volt peaks for best results.



HALLICRAFTERS 1400 Series, continued

I-F AMPLIFIER ALIGNMENT FOR 1400D CHASSIS

EQUIPMENT REQUIRED

Marker Generator_____ RCA type WR-39C Television Calibrator or equivalent.

Oscilloscope ____

VTVM _____ RCA type WV-97A vacuum tube voltmeter or equiv.

____RCA type WO-56A or equiv.

Detector Circuit _____ Shown in Fig. 619A.

Bias Source ______ 3 volt battery or equiv.







Fig. 619A. Detector Circuit


PROCEDURE


- 1. Connect the hot lead from the sweep generator to point (A) (grid of the second i-f amplifier, V-102) through a .005 mfd. capacitor. Connect the ground lead from the generator to the receiver chassis.
- 2. Connect the vertical input terminal on the oscilloscope through a 47,000 ohm 1/2 watt resistor to point (B) in the video detector circuit.
- 3. Connect the oscilloscope terminals on the sweep generator to the horizontal input of the oscilloscope and adjust the gain for the desired test pattern width.
- 4. Connect the negative side of the 3 volt bias supply to the AGC bus at point (C) through a 1000 ohm isolating resistor. Connect the positive side of the bias supply to the receiver chassis.
- 5. Adjust T-101, L-108, and L-107 (See Fig. 617A) until the pattern shown in Fig. 618A is obtained. A marker generator loosely coupled to the hot lead from the sweep generator may be used to locate the 50% points which should fall at 41 MC and 46 MC as shown. Adjust for maximum gain and a flat topped response with the 41 and 46 MC points down 50% on the skirt of the response curve. Keep the output of the generators low so as to prevent overloading of the i-f system of the receiver.
- 6. Disconnect the sweep and marker generators from point (\widehat{A}) and reconnect to point (\widehat{D}) (V-101 grid pin 1).
- 7. Connect the hot lead for the vertical amplifier in the oscilloscope to point (E) (V-102 grid pin 1) through the detector circuit shown in Fig. 619A.
- 8. Adjust L-103, L-104, L-105, and L-306 for the response curve shown in Fig. 618C. The 41.25 MC and 47.25 MC sound traps, L-104 and L-105, must be carefully adjusted for a minimum response on the exact frequencies specified.
- 9. Disconnect the detector circuit and oscilloscope lead from test point (E) and reconnect to test point (F)
- 10. Raise the shield for the oscillator mixer tube in the VHF tuner above the ground clips that hold it in place and connect the hot lead from the signal generator to it. Loosely couple the hot lead from the marker generator to the sweep generator lead.
- 11. Adjust L-9 (in the VHF tuner) and L-102 for the response curve shown in Fig. 618D.
- 12. Repeat steps 6 and 2 which will give an overall response curve.
- 13. Touch-up the adjustments for L-107, L-108, and T-101 for a flat topped response curve with maximum gain and the band width shown in Fig. 618B. L-107 will have more effect on the high frequency side of the response curve and L-108 will have more effect on the low side. Transformer T-101 should be adjusted to control the tilt of the top portion of the curve. <u>DO NOT</u> change the settings of L-103, L-104, L-105, and L-106. Their adjustment was completed in step 8.





The 300 chassis and its complete model assembly is designed to facilitate receiver servicing. The chassis is mounted in a horizontal position within the cabinet. It is held in position within the cabinet by four bolts which thread into four mounting brackets located at the corners of the chassis. The four bolts are inserted from below the mounting shelf in the cabinet. Removal of the backboard exposes the top of the chassis. The removal of two screws from the bottom rear of the high voltage cage allows the back and top of the cage. The bottom of the chassis is made accessible by removing the bottom cover board which is held in place by several wood screws.








Figure 5. Voltmeter Isolation







Figure 6. Detector Network








Alignment continued on the page following.



The source of protection which is provided in the chassis is the fusable resistor, R801. The entire receiver is protected against overloading due to short circuiting that results in excessive input current being drawn by the selenium rectifiers. R801 will open circuits on several times normal load.

HOFFMAN Chassis 300-17 & 300-21



61

HOFFMAN Chassis 300-17 & 300-21, continued

ALIGNMENT

Before alignment is begun, tune the tuner off-channel by turning the tuner CHANNEL SELECTOR shaft so that the detent roller rests on one of the high points of the drum disc. Bias pin 1 of V704 with -60 volts, in order to eliminate spurious signals and possibility of high voltage shock hazard, or remove high voltage tube.

SIGNAL CONNECT GENERATOR OUTPUT SPECIAL CONNECTIONS STEP FREQUENCY, SIGNAL AND SETTINGS NO. MC то INDICATOR ADJUST INSTRUCTIONS SOUND I-F AND RATIO DETECTOR T101 Pri. Tune for maxi-Signal level should be low Pin 2 1 4.5 Meter across pin 7 of V102 (bottom) mum reading on enough to obtain approxi-CW of mately 4 to 7 volts on **V301** L101 meter and ground. meter. Use isolation networks shown in Figures 4 and 5. Repeat tuning of T101 pri-•• T101 Sec. Tune for zero 2 4.5 Meter across meter reading; CW ground and (top) mary and secondary until junction of R105 adjustments do not change. use same sigand C108. nal level as in step 1. TRAPS AND PICTURE I-F Tune for mini-Detector and isolating net-3 4.5 Pin 2 Meter connected L302 through detector mum reading works shown in Figures 4 CW of on meter. **V301** network to picture and 6. tube cathode lead. 41.25 Mixer grid Voltmeter across Top of Tune for min-Apply -3V bias to AGC bus. 4 See text for connection to L203 imum reading R215. CW mixer grid. Use isolating on meter. resistor between negative 43.75 ** .. L204 Tune for maxivoltmeter lead and R213. 5 Keep generator output low. CW mum. Either bias V704 with A-60 42.75 .. 8 ., ** L203 volts or remove tube. Set CONTRAST control for CW maximum contrast. Adjust ** signal level throughout I-F L202 7 Tune for maxi-45.4 Mixer grid CW mum reading alignment so that a 1 volt DC output is maintained on meter. across R215. •• ** L9 Tune for mini-8 43 CW mum reading on meter. ** ** L201 Tune for maxi-9 43 CW mum. 10 45 ** ** L9 Tune for maxi-CW mum. Repeat steps 4 through 10 until adjustments do not change. 11 Set 45.75 mc See Figure 7 for isolation 12 Approximately Mixer grid High gain scope Adjust 43.5 with 10marker at 50% network. Use markers to across R215 L202, point with L202. L203 and determine bandpass bemc sweep. L204 if Eliminate tilt tween picture carrier and Marker renecessary. with L204. 50% point on opposite skirt. auired. Bandpass should be between 3.4 mc and 3.6 mc. Adjust L9 and L201 only when absolutely necessary.

TV ALIGNMENT PROCEDURE

MOST-OFTEN-NEEDED 1954 TELEVISION SERVICING	INFORMATION
Motorola TV	CHASSIS TS-602
	TS-602 Y
	MODELS
	24K1
	¥24K1
	24K1B
HIGH VOLTAGE	¥24K1B
CONNECTOR	24K2
YOKE	¥24K2
ADJUŠTMENT THUMBNUT	24K2B
	Y24K2B
DEFLECTION	24K3
TONE	¥24K3
FOCUS COIL POSITION	24K3W
ADJUSTMENT STUD	¥24K3₩
(ONE ON EACH END)	27K2
	¥27K2
FOCUS COIL	27K2B
PICTURE	Y27K2B
CENTERING	27K3
	Y27K3
ION TRAP	
FOCUS COIL	
ECCENTRIC ADJUSTMENT STUD	Service material
(ONE ON EACH SIDE)	below and on the
	next five pages.
ADJUSTMENT OF	ION TRAP

GENERAL INFORMATION

TV CHASSIS DIFFERENCES

Chassis	VHF Tuner	UHF Tuner
TS-602 TS-602Y	VTT-42 VTT-42Y	TT - 37

FUSES - B+ and initial surge; 5 ohm special resistor Filament - fusing wire; 1" of #26 copper wire

POWER SUPPLY - 117 volts, 60 cycles, AC only

POWER CONSUMPTION - 220 watts

OPERATING CONTROLS

There is a dual control on the right and a triple control on the left of the receiver's front panel. Supplementary controls are located behind a door in the center of the front panel. See Figure 1 for control functions.

ADJUSTMENT OF ION TRAP

NOTE: The ion trap is accessible without removing the cabinet back. The picture tube rear cover is hinged at the top and can be opened by pulling on bottom edge to expose ion trap.

1. Place the magnet on the neck of the tube so that it is positioned over the slash in the gun structure. The slash is the separation between grids #1 and #2.


2. Set the brightness control at low intensity.

3. Move the magnet a short distance forward and backward, at the same time rotating it to obtain the brightest raster:

4. Keep brightness at low intensity until the ion trap is properly set. NOTE: A few precautions to keep in mind while adjusting the ion trap are:

a. If the magnet has to be moved more than i/2" forward from the slash, the ion trap is probably weak and should be replaced.

b. Never correct for a shadowed raster with the ion trap if such correction results in decreased brightness. The ion trap is always adjusted for maximum brightness and, if shadows occur at this setting, they should be elim inated by adjusting the focus coil or adjusting the yoke.




DC Meter: Low range electronic voltmeter

Procedure:

1. Connect the signal generator to top of the 4700 ohm detector load resistor R-46.

4. With the signal generator accurately set at 4.5 mc and maximum output, adjust the trap L-32 for a null or minimum reading on the voltmeter.

lead) and chassis.



PICTURE TUBE REMOVAL

1. Remove the mounting board containing the chassis and picture tube from the cabinet by removing the screws hold-ing the board to the cabinet.

2. Remove the picture tube socket, ion trap, and high voltage lead.

4. Remove the strap retaining screws which hold the picture tube to the front picture tube support bracket.

5. Remove the picture tube with band, and place face up in unused tube carton.

6. Loosen the band clamping nuts and remove band from old tube. DO NCT BEND OR KINK BAND.

D;

3. Loosen the tie rod nuts.

ALIGNMENT

Motorola Chassis TS-602

GENERAL

The chassis should be mounted on angle iron brackets so that all connections and adjustments are readily accessible.

Since the power cord circuit is broken by the interlock when the cabinet back is removed, it is necessary to obtain an extra power cord with the female interlock receptacle in order to make a power connection to the receiver. Order Motorola Part No. 30B470756.

It is important that an isolation transformer be used between the receiver and line when any test equipment is attached to the chassis. Due to the full-wave rectifier, there is always a potential difference between the chassis and earth. This precaution is especially important if grounded test equipment is used. NEVER GROUND THE RECEIVER CHASSIS DURING TESTING OPERATIONS OR INSTALLA-TION UNLESS AN ISOLATION TRANSFORMER IS USED.

For all of the following procedures, the line voltage must be set at 117 volts. If necessary, a variac should be used to obtain the proper line voltage.

ORDER OF ALIGNMENT

A complete receiver alignment can be most conveniently performed in the following order:

- 1. IF & Mixer Transformers
- 2 Oscillator & RF Sections
- 3. IF Trap
- 4. 4.5 Megacycle Trap
- 5. Audio Take-Off Interstage Coil and Ratio Detector
- IF AMPLIFIER ALIGNMENT

Ø

Je

Equipment Required:

IF Sweep Generator meeting the following requirements:

(Continued)

1. 38 to 50 mc approximately 12 mc sweep width.

2. Output constant and adjustable to at least 0.1 volt maximum.

3. Accurately calibrated, adjustable markers

Cathode Ray Oscilloscope - Preferably one with a calibrated attenuator.

AM Signal Generator - Adjustable Output

NOTE: If there are no built-in markers in the sweep generator, loosely couple the output of an accurately calibrated AM signal generator to the IF strip. At all times, keep the marker output low enough to prevent the markers from distorting the response curve.

If a wide band scope is used, the markers will be more distinct if a capacitor of 100 to 1000 mmf is placed across the scope input. Use the smallest size possible, since too large a capacitor will affect the shape of the curve.

NOTE: Caution should be observed that all coils are tuned with slugs tuned away from the center of the coil.

> Keep the signal input low, to prevent flattening the top of the curve, due to limiting in the video or scope amplifiers.


The dressing of plate and grid components in the IF circuit affects tuning. Do not move indiscriminately.

Procedure:

1. Remove the horizontal output tube V-17 to eliminate RF interference in the oscilloscope. Place a 2500 ohm 25W resistor from B++ to chassis to normalize the bus voltages.

2. By means of an external battery, apply a voltage to the IF AGC line, so that a negative 3V bias appears at pin 1 of the test receptacle.

3. Attach a scope to pin 3 (video detector output) of the test



Motorola Chassis TS-602, Alignment Information, continued.

receptacle (J-6) and chassis. If a stronger output is required, connect the oscilloscope between the picture tube cathode (yellow lead) and chassis. The curve seen at this point will be opposite in polarity to that seen at the detector load.

4. Turn AREA SELECTOR SWITCH (S-2, Figure 2) to LOCAL position. Set channel selector switch to channel 13. Set contrast control to minimum.

5. Detune the oscillator by placing a 470 mmf capacitor from the channel 13 coil to chassis.

6. Using leads as short as possible, connect the sweep generator through a 1000 mmf capacitor to test receptacle (J-7), feeding into the grid of the third IF tube (V-5, see Figure 7). (Do not use the loose or "spraying" method of coupling.) Set the generator center frequency to 44 mega-cycles with a sweep deviation of 12 megacycles.

7. Connect an AC voltmeter to the high side of detector load resistor (R-46) and chassis. Adjust sweep output to give 3 volts AC at the detector load.

8. Tune the primary and secondary of the 3rd IF transformer (T-7) to place a 45. 75 mc marker on the high side of the response curve approximately 5 to 10% down from maximum response and a 42. 25 mc marker on the low side of the response curve approximately 5 to 10% down from maximum response. See Figure 8.




FIGURE 8. 3RD IF RESPONSE CURVE

9. Move the sweep generator and capacitor to test receptacle (J-5, see Figure 7) feeding into the grid of the 1st IF stage. Set the sweep generator to 45, 75 mc and adjust the 1st IF transformer T-5 to place the 45, 75 mc marker 30%down from maximum response on the high side of the curve. See Figure 9. The resonance point of the IF coils and the traps will be found at two settings of the core. The correct setting is the one with the cores at the outer end of the winding (toward the top).

10. Set the sweep generator to 42.25 mc and adjust the 2nd IF transformer T-6 to place the 42.25 mc marker 30% down from maximum response on the low side of the curve. See Figure 9. The resonance point of the IF coils and the traps will be found at two settings of the core. The correct setting is the one with the cores at the outer end of the winding (toward the top).

11. Set the sweep generator to 47.25 mc. Adjust the trap

L-27, which is located at the top of the 1st IF transformer, until the marker is at maximum attenuation on the curve. See Figure 9. Make sure the core is toward the outside of the trap winding (toward the top).

12. Set the sweep generator to 41.25 mc. Adjust the trap L-28, which is located at the top of the 2nd IF transformer, until the marker is at maximum attenuation on the curve. See Figure 9. Make sure the core is toward the outside of the trap winding (toward the top).




FIGURE 9. OVERALL IF RESPONSE CURVE

13. Apply the sweep generator and capacitor to the test receptacle J-3, which feeds into the grid of the mixer. See Figure 7.

14. Adjust the mixer coils L-25 & L-26 to the response and markers shown in Figure 10. The mixer coils should be tuned so the slugs are toward the outside of the coils (toward the chassis). L-25 affects the high side of the curve, while L-26 affects the tilt.




FIGURE 10. MIXER RESPONSE CURVE

NOTE: It is important that the 41.25 mc and the 47.25 mc carriers be attenuated as much as shown in Figure 10. To calculate, connect an AM generator directly to the mixer grid (pin 2 of V-2) and a VTVM across the detector load resistor R-46. Take voltage readings at 41.25 mc, 44 mc, and 47.25 mc and divide per following formula:

voltage reading at 41.25 mc voltage reading at 44 mc voltage reading at 47.25 mc voltage reading at 47.25 mc voltage reading at 44 mc

Motorola Chassis TS-602, continued

BANDWIDTH

The IF bandwidth may be checked with an AM signal generator, if desired. Connect the generator, through a 1000 mmf capacitor, directly into the grid of the mixer tube (pin 2 of V-2) and an electronic voltmeter across the video detector load resistor R-46. Set the generator to 44 mc and adjust its output for a 1 volt reading on the meter. Double the output of the generator, Tune to both sides of 44 mc and note the frequencies at which the meter again reads 1 volt. These frequencies indicate the 6 db bandwidth. By watching the meter while tuning slowly through the band, any serious peaks or holes in the response curve can be detected.

REGENERATION

After the mixer and IF stages have been aligned, a check for regeneration in the IF strip should be made as follows:

1. Detune the oscillator by placing a 470 mmf capacitor from channel 13 coil to ground.

2. Remove the bias and observe the response curve on the scope as taken between the picture tube cathode (yellow lead) and chassis. The bandwidth may change with the bias removed, but should not change more than 0.3 mc. If the bandwidth does change more than 0.3 mc, check the cathode resistors or change tubes.

3. Set the contrast control at maximum gain.

4. Decrease the generator input until the output signal shows a marked decrease.

Any regeneration present will be indicated by sharp peaks on the overall response curve.

MIXER SENSITIVITY MEASUREMENTS

1. Connect an AM signal generator set at 44 mc directly into the grid of the mixer tube (pin 2 of V-2) through a capacitor of 1000 mmf.

2. Remove battery bias from the AGC line.

3. The 470 mf capacitor should be left on from the channel 13 coil to ground to detune the oscillator.

4. Connect the electronic voltmeter across the video detector load resistor R-46. Turn contrast control to maximum.

5. Turn area selector switch to fringe position (fully clock-wise).


6. The signal required to produce 1 volt DC above noise voltage at the detector should be less than 90 microvolts.

IF SENSITIVITY MEASUREMENT

1. Move the generator to test receptacle J-5, feeding into the grid of the 1st IF tube V-3.

2. Connect the electronic voltmeter across the video detector load resistor R-46 (4700 ohms).

3. The sensitivity at 44 mc for l volt DC at the detector should be at least 600 microvolts.



MODELS

21K4WDY

21K4WY

21K4Y

21K5BD

21K5BY

21K5DY

21K6DY

21K5D

21K5Y 21K6D

21K5RDY

21C1BD

21C1BY

21C1DY

21C1D

21C1Y

21F2F

21F2Y

21F2FB

21C1BDY

See the next two pages for complete circuit diagram of basic chassis. 21F2FBY 21F2FY

otorola

Complete service material on Chassis TS-292A is in Volume TV-7, 1953 TV manual, pages 91 to 98. The production changes after TS-292B-04 are printed below and the differences of other chassis are also explained.

CHASSIS DESCRIPTION

The basic chassis is TS-292. Suffixes (B-04, C-01, etc.) to this basic number indicate production changes. Prefixes (WTS and VTS) indicate only mechanical differences between chassis. A "Y" suffix designates a chassis containing a factory-installed UHF tuner.

CHASSIS WTS-292 SERIES

Same as chassis TS-292 with corresponding suffix, except for different picture tube front support brackets, made necessary by a thicker safety glass window in some cabinets (e.g., chassis WTS-292B-04 is electrically the same as TS-292B-04). Chassis WTS-292 uses the TT-44 Cascode VHF tuning unit.

CHASSIS TS-292Y, WTS-292Y, VTS-292Y SERIES

Chassis model numbers with a "Y" suffix (TS-292BY-04, WTS-292CY-02, etc.) indicate that the chassis contain factory-installed UHF tuners. Chassis TS-292Y and WTS-292Y use the TT-52M UHF tuning unit, and chassis VTS-292Y uses the TT-60M UHF tuning unit.


	21F 3BD	21K6Y
CHASSIS	21F3BDY	21K7D
TS-292B-04	21F3BY	21K7 DY
WTS-292B-04	21F 3D	21K7Y
VTS-292B-05	21F 3DY	21K9
	21F 3 Y	21K9Y
THRU	21K 4AY	21K10
TS-292C-03	21K4BD	21 K 10B
WTS-292C-03	21K 4 B D Y	21K10BY
VTS-292C-03	21K4BY	21K10Y
	21K4C	21K11
TS-292AY SER	21K4CB	21K11B
WTS-292BY SER	21K4CBY	21K11BY
VTS-292BY SER	21K4CW	21K11Y
THRU	21K4CW Y	21T4ACY
	21K4CY	21T7
TS-292CY-03	21K4D	21T7B
WTS-292CY-03	21K4DY	21 T 7BY
VTS-292CY-03	21K4WD	21T7Y


CHASSIS VTS-292 SERIES

Electrically, the same as chassis TS-292 with corresponding suffix (e.g., chassis VTS-292B-05 is the same as TS-292B-05). Mechanically, the picture tube rear tilt bracket has been removed, and the VTS-292 picture tube front support brackets are different from the TS-292 brackets because of a different type window and mask in some cabinets. Chassis VTS-292 uses the TT-45 Cascode VHF tuning unit and a new volume control, both with longer shafts than the tuner and volume control on the TS-292 chassis.

Chassis Chassis Coding Changes Coding Changes TS-292B-04 Fusing wire (F-1) added to filament cir-C-103 (33), C-104 (22), R-96 (1000), and WTS-292B-04 cuit. R-84 (470) added to screen circuit of L-27 added to 3rd IF stage. 6BQ6GT, to reduce barkhausen oscillation. C-28 (1500) changed to 1000 mmf C-105 (470) and R-97 (15K) added to TS-292B-05 R-82 (4700) changed to 6800 ohms to reduce video amplifier stage. WTS-292B-05 horizontal over-drive and fold-over. C-63 (22) removed from 1st clipper. VTS-292B-05 TS-292C-01 These chassis incorporate all changes listed TS-292B-06 R-62 (3300) changed to 1800 ohms and R-63 WTS-292C-01 under "B-06" and "C-00". WTS-292B-06 (1800) changed to 3300 ohms, to increase VTS-292C-01 VTS-292B-06 blanking pulse at the grid of the picture tube. (This change did not occur in some TS-292C-02 R-53 (680K) changed to 1 meg, to improve chassis until "C-01".) WTS-292C-02 interlace. VTS-292C-02 NOTE: Chassis marked "C-00" do not in-TS-292C-00 WTS-292C-00 corporate the change above in "B-06". Com-TS-292C-03 C-75 (5000 mmf, 2000V) added from picture VTS-292C-00 pensating coil L-16 and 4.5 mc trap L-17 WTS-292C-03 tube focusing anode (blue lead) to chassis, interchanged, to improve video response. VTS-292C-03 and C-73 (5000 mmf) changed to capacitor "Framelock" circuit added, as listed with 2000V rating, to prevent high voltage below, to improve vertical sync under noise flash-over within the picture tube and the conditions: vertical output tube, respectively.

PRODUCTION CHANGES







RECEIVER MODEL BREAKDOWN CHART

	and the second	
		TV
		Chassis
Model	Cabinet Description	Used
17K17	Console, red-brn mahogany	TS-402
¥17K17	Console, red-brn mahogany	TS-402Y
17K17B	Console, limed oak	TS-402
¥17K17B	Console, limed oak	TS-402Y
17T15A	Table, red-brn mahogany; plastic	VTS-402
¥17T15A	Table, red-brn mahogany; plastic	VTS-402Y
17T15AE	Table, ebony plastic	VTS-402
¥17T15AE	Table, ebony plastic	VTS-402Y
17T16	Table, red-brn mahogany	TS-402
¥17T16	Table, red-brn mahogany	TS-402Y
17T16B	Table, limed oak	TS-402
¥17T16B	Table, limed oak	TS-402Y
21C2	Table, red-brn mahogany: with de-	TS-502
	tachable, console-height legs	
¥21C2	Table, red-brn mahogany: with de-	TS-502Y
12102	tachable, console-height legs	
21C2B	Table, limed oak: with detachable,	TS-502
21028	console-height legs	
811010	Table, limed oak: with detachable,	TS-502Y
Y21C2B	console-height legs	
	Combination, red-brn mahogany	TS-502
21F5		TS-502 Y
¥21F5	Combination, red-brn mahogany	TS-502 1
21F5B	Combination, limed oak	TS-502Y
Y21F5B	Combination, limed oak	
21K12A	Console, red-brn mahogany	WTS-502
¥21K12A	Console, red-brn mahogany	WTS-502Y
21K12AB	Console, limed oak	WTS-502
¥21K12AB	Console, limed oak	WTS-502Y
21K12WA	Console, walnut	WTS-502
¥21K12WA	Console, walnut	WTS-502Y
21K13	Console, red-brn mahogany	TS-502
¥21K13	Console, red-brn mahogany	TS-502Y
21 KI 3 B	Console, limed oak	TS-502
¥21K13B	Console, limed oak	TS-502Y
21K14	Console, red-brn mahogany	TS-502
¥21K14	Console, red-brn mahogany	TS-502Y
21K14B	Console, limed oak	TS-502
Y21K14B	Console, limed oak	TS-502Y
21K15	Console, walnut	TS-502
¥21K15	Console, walnut	TS-502Y
21 K16	Console, birch	TS-502
Y21K16	Console, birch	TS-502Y
21K16W	Console, walnut	TS-502
Y21K16W	Console, walnut	TS-502Y
21 K17	Console, birch: with iron stand	TS-502
¥21K17	Console, birch: with iron stand	TS-502Y
21T8A	Table, red-brn mahogany; plastic	TTS-502
¥21T8A	Table, red-brn mahogany; plastic	TTS-502Y
21T8AE	Table, ebony plastic	TTS-502
	Table, ebony plastic Table, ebony plastic	TTS-502Y
Y2IT8AE		VTS-502
21711	Table, red-brn mahogany; metal	VTS-502Y
Y21T11	Table, red-brn mahogany; metal	VTS-502
21T11B	Table, blonde; metal	VTS-502Y
Y2ITIIB	Table, blonde; metal	VTS-502
21T11W	Table, walnut: metal	VTS-502Y
Y21T11W	Table, walnut: metal	1 13-3021

CHASSIS TS-402 SER TS-502 SER

ALIGNMENT

IF AMPLIFIER ALIGNMENT

Equipment Required:

IF Sweep Generator meeting the following requirements:

1. 38 to 50 mc, approximately 10 mc sweep width

2. Output constant and adjustable to at least 0.1 volt maximum.

3. Accurately calibrated, adjustable markers

Cathode Ray Oscilloscope - Preferably one with a calibrated attenuator.

AM Signal Generator - Adjustable Output

NOTE: If there are no built-in markers in the sweep generator, loosely couple the output of an accurately calibrated AM signal generator to the IF strip. At all times, keep the marker output low enough to prevent the marker from distorting the response curve.

If a wide band scope is used, the marker will be more distinct if a capacitor of 100 to 1000 mmf is placed across the scope input. Use the smallest size possible, since too large a value will affect the shape of the curve.

If necessary, use a variac to obtain input of 117 volts.

NOTE: Keep the signal input between 3 and 5 volts peak-to peak, at the detector, to prevent overloading of the IF or scope amplifiers.

> To check for crystal overloading an AM signal generator, set at 44 mc and fed into the first IF grid, should be used. With the AGC shorted to ground, the output at the detector load R-46 should be at least 13V DC before limiting occurs or increasing the input gives no corresponding increase in output.

> The dressing of plate and grid components in the IF circuit affects tuning. Do not move indiscriminately.

The resonance point of the IF coils and the trap can be found at two settings of the core. Be sure that the coils are tuned with the cores away from the center of the coil form so as not to affect the coupling between the coil and the trap windings.

Procedure:

1. Turn the AREA SELECTOR switch to LOCAL position.

2. By means of an external battery, apply a negative 3 volt bias, through a decoupling resistor of 47K ohms, to the AGC line, which is connected to pin 1 of the test receptacle J-7. See Figure 5 for receptacle location. Check to make sure that bias is still 3 volts after sweep is applied.

3. Turn tuner to channel 13.

4. Stop oscillator by shorting grid (pin 9) of V-2 to ground with a short lead.

Circuit diagram on pages 74-75, alignment continued on page 73.




FIGURE 5. ALIGNMENT ADJUSTMENT LOCATIONS

5. Using leads as short as possible, connect the sweep generator, through a 1000 mmf capacitor, to test receptacle J-6 feeding into the grid of 1st IF tube V-3. See Figure 5. (Do not use the loose or "spraying" method of coupling.) Set the generator center frequency to 44 mc, with a sweep deviation of 10 mc.


6. Through a 47K ohm decoupling resistor, connect the oscilloscope across the video detector load resistor R-46 (4700) which may be reached from pin 3 of test receptacle J-7.


7. Adjust trap L-23 (top slug of the 2nd IF transformer T-2) so the trap suck-out falls on the 41.25 mc marker. The sweep generator input should be adjusted to a level sufficient to clearly define the trap.


8. Adjust trap L-22 (top slug of the 1st IF transformer T-1) so the trap suck-out falls on the 47.25 mc marker. Temporarily removing the AGC -3 volt bias may define the trap suck-out to a greater degree).

9. Tune the 1st lF transformer, T-1, to place a 45.75 mc marker on the high side of the response curve 40% down from maximum response. At the same time, adjust T-3 to provide a flat top or symmetrical response curve. Tuning

the two transformers together will make for proper marker placement and "jacking" action of T-3. See Figure 6.







MOTOROLA, continued.

10. Tune the 2nd IF transformer, T-2, to place a 42.25 mc marker on the low side of the response curve 50% down from maximum response. At the same time, adjust T-3 to provide a flat top or symmetrical response curve as in step 9. See Figure 6.

11. Move the generator and capacitor to test receptacle J-3. See Figure 5.

12. Tune the convertor coils L-15 and L-21 together so that the bandpass appears as in Figure 7. L-15 positions the curve and L-21 levels it.

This is a double-tuned bottom coupled circuit. L-15 and L-21 should be tuned simultaneously so that the convertor response is centered over the IF response.


BANDWIDTH

The IF bandwidth may be checked with an AM signal generator if desired. Connect the generator, through a 1000 mmf capacitor, to test receptacle J-3 in the grid circuit of the mixer tube, V-2, and an electronic voltmeter across the video detector load resistor R-46 (4700). Apply 3 volt bias as in 2nd step of IF procedure. Short out R-10 (4700), set the generator frequency to 44.00 mc, and adjust its output for a 1 volt reading on the meter. Double the output of the generator. Tune to both sides of 44 mc and note the frequencies at which the meter again reads 1 volt. These frequencies indicate the 6 db bandwidth points and should be even with the low marker between 42.1 and 42.25 and the high marker between 45.3 and 45.75. By watching the meter while tuning slowly through the band, any serious peaks or holes in the response curve can be detected.

REGENERATION

After the mixer and IF stages have been aligned, a check for regeneration in the lF strip should be made as follows:

1. Remove the battery bias and observe the response curve. The bandwidth may change with the bias removed, but should



not change more than 0.2 mc. If the bandwidth does change more than 0.2 mc, check the cathode resistors, bypass capacitors, and tubes.

2. Any regeneration present will be indicated by sharp peaks on the overall response curve.

NOTE: The oscillator should be stopped, as described, during this procedure.

CAUTION: Do not inject too much marker signal.

AUDIO TAKE-OFF, INTERSTAGE COIL, & RADIO DETECTOR ALIGNMENT

Refer to Figure 5 for location of adjustments.

1. If possible, it is desirable to align the audio section from an actual station signal, since the 4.5 mc alignment will be exact. To permit operation below the limiting level of the audio drive tube, for sharp alignment, the fine tuning should be turned off the station slightly so that there is between 6 and 8V as measured from plus side of C-56B and chassis.

2. If a signal generator is used, tune it accurately to 4.5 mc, and adjust the output to approximately 5,000 microvolts. Connect the high side of the signal generator to pin 3 of test receptacle J-7 and the low side to chassis. The following steps apply whether the station signal or signal generator is used.

3. From positive side of electrolytic capacitor C-56B (10 mf) through a 10K ohm decoupling resistor, connect an electronic voltmeter to chassis.

4. Tune audio take-off coil L-33 for maximum reading on meter.

5. Tune interstage trimmer C-66 for maximum reading on meter.

NOTE: As adjustments are brought to resonance, it is advisable to reduce the signal generator output to prevent overloading.

6. Tune ratio detector T-4 primary (top core) for maximum reading on meter.


NOTE: Both the primary and secondary of the ratio detector transformer have two tuning points. Only one, with the cores at the outer end of the windings, is the proper point.

7. Connect a matched pair of 100K resistors across the ratio detector load R-62.

8. Connect the ground side of meter to the mid-point of the 100K resistors and the high side to the output of the deemphasis network (junction of R-63 (33K) and C-74 (1000 mmf).

9. Adjust T-4 secondary (bottom core) for zero response on the lowest scale of the meter. Be sure the slug is tuned to the outside of the transformer winding. This corresponds to the cross-over point of the FM detector curve. If desired, the symmetry of the curve may be checked by tuning the signal generator 25 Kc above and below 4.5 mc and noting the plus and minus voltage produced, reversing the meter connections, as necessary. For proper balance of the ratio detector system, the voltages in each direction should be approximately equal. If not, check the tuning of L-33, C-66, and both the primary and secondary of T-4, the ratio detector transformer. If necessary, replace the ratio detector tube V-9.

10. Repeat steps 4 through 9 for maximum accuracy.



MODELS

MODELS					
MODEL NO.	CHASSIS NO.	PICTURE TUBE	CABINET STYLE		
2053-A	17B1 or 17B2	20" Rect.	Consolette		
2054-A	17B1 or 17B2	20" Rect.	Console Comb.		
2055-A	17B1 or 17B2	20" Rect.	Table Model Leatherette		
2055-B	17B2	20" Rect.	Table Model Leatherette		
2056-A	17B1 or 17B2	20" Rect.	Consolette W/Doors		
2457-A	17B3 or 17B4	24" Round	Consolette With Doors		
2158-A	17B5 or 17B6	21" Rect.	Consolette With Doors		
2159-A	17B5 or 17B6	21" Rect.	Consolette		
2162-A	17B5 or 17B6	21" Rect.	Table Model		
2461-A	17B3 or 17B4	24" Round	Consolette		
317T2	37A2	17BP4A	Table Leatherette		
321T1	17B2	21WP4	Table Masonite		
321T2	17B2	21WP4	Table Leatherette		

Rotate the horizontal hold control (found beneath the Muntz nameplate) fully counter-clockwise. The picture should remain in horizontal sync. Rotate the control fully clockwise and the picture should fall out of sync showing one vertical black blanking bar near the center of the picture. If the horizontal oscillator does not fill the above requirements, the circuit needs readjusting and can usually be done in the customer's home by readjustment of the Horz. Range Trimmer, the top Horz. Slug, the Horz. Drive and the Horz. Hold control until settings are found that fulfill the above procedure. If these con-ditions cannot be obtained, the bottom slug of T-6 under the chassis probably requires adjustment. Then follow the procedure listed under "Complete Alignment of Horizontal Oscillator." For a stable setting of the Horz. Hold Control, turn the control fully clockwise. The picture should slip out of sync by one vertical black blanking bar. Now move the control counter-clockwise until picture locks into sync. Final setting of this control should be 20 degrees counter-clockwise from where the picture pulls into sync.

COMPLETE ALIGNMENT OF HORIZONTAL OSCILLATOR (A. F. C.)

- (a) Tune in a known good signal (test pattern where possible) and adjust the contrast control well below an over-contrast condition.
- (b) Turn both Horz. Osc. slugs out of coil can No. LO-0039 (T-6) as far as possible. Caution: For manufacturing convenience both of the oscillator adjustments are within the can No. LO-0039. If the Horz. Osc. slugs are turned too far in, a coupled condition is reached which is undesirable.
- (c) Place jumper wire between terminals C and D of T-6.
- (d) Preset Horz. Range Trimmer ¼ turn out from full "in" position. Turn Horz. Hold control fully clockwise. Through adjustment of top slug of T-6 cause the picture to sync. Readjust Horz. Range Trimmer slightly in order to sync picture.

- (e) With picture in sync., check picture width and linearity adjusting Horz. Drive and Linearity controls if necessary until a normal picture is obtained.
- (f) Remove jumper between terminals C and D of T-6. Picture should remain in sync. If it does not, re-adjust Horz. Range Trimmer or top slug of T-6. *IMPORTANT*: The Oscilloscope used in the following adjustment must have a flat vertical amplifier response up to 500 K. C. or better or a false waveform will result. A scope with poor vertical response will show a perfect waveform as shown in Figure 6A but when checked against a good wide band oscilloscope, the waveform will be found to have considerable tilt. This is highly undesirable because the bottom core is not adjusted properly, although we are led to believe it is.
- (g) Connect scope having a 10 mmf. condenser in series with the vertical lead to point C Fig. 6.

Adjust bottom slug of T-6 until the broad and sharp peaks are of equal height (Fig. 6A) keeping picture in sync at all times. If picture goes out of sync at any time repeat procedure under step No. f. If the picture still goes out of sync., there is a defect in the Horz. control and A.F.C. circuit. Try a new 6SN7 tube before checking further.

The above adjustment is very important to correct circuit operation. If the broad peak is lower than the sharp peak the noise immunity becomes poor, hence the osc. is not stabilized as well resulting in greater drift. If the broad peak is higher than the sharp peak, the oscillator becomes over-stabilized and double triggering can occur when the hold control approaches full clockwise position. REMOVE SCOPE.

(h) Set the Horz. Hold control to extreme clockwise position and adjust top slug of T-6 for one vertical blanking bar. Rotate Horz. Hold control fully counter-clockwise. Picture should remain in sync.

ALIGNMENT INSTRUCTIONS

MUNTZ TV, continued

Avoid excessive signal input when using V.T.V.M. as alignment indicator. Use lowest scale on V.T.V.M. and just enough signal from the generator to override the noise level at all times. Run coil slugs at points A, B, C, and D in Figure 7 down all the way before proceeding. A 22.000 ohm isolation resistor, for scope or V.T.V.M., is provided beneath the chassis terminating at Point "E" Figure 7.

STEP NO.	SIGNAL GENERATOR FREQUENCY	SIGNAL GENERATOR FREQUENCY	CHANNEL	CORRECT V.T.V.M.	FIGURE NO. 7 ADJUST	REMARKS
#1	High side thru .001	24.25	2 or 13	D.C.	C (Z-5)	Short Antenna Connections. To avoid distortion
#2	to ungrounded tube	22.5	2 or 13	Probe	A (L-5)	which may be caused by AGC action keep the
#3	shield floating over	22.5	2 or 13	To Test	D (Z-6)	attenuator of the signal generator to a minimum
#4	converter tube (V-2). Low side to chassis	25.	2 or 13	Point "E"	B (Z-4)	just enough to override noise level voltages. Adjust for maximum.

OVERALL VIDEO I.F. RESPONSE EMPLOYING I.F. CURVE

Precautions to be observed before making the following adjustments: When observing the television receiver band pass characteristics on the scope, it is extremely important to avoid distortion of the response curve which would occur when using a large signal input from the sweep and marker generators.

Always set the generator attenuator below the point where its output voltage starts to alter the shape of the response curve shown on the scope. This applies to both sweep and marker generators.


STEP NO.	SWEEP GENERATOR COUPLING	SWEEP GENERATOR FREQUENCY	MARKER GENERATOR FREQUENCY	CHANNEL	CONNECT SCOPE	FIGURE NO. 7 TOUCH UP	REMARKS
#6	High side thru .005 to un- grounded tube shield float- ing over converter tube (V-2). Low side to chassis.	23 M.C. (10 M.C. Sweep)	20.6 M.C. 22.6 M.C. 24.3 M.C. 25.1 M.C.	2 or 13	Point E	A B C D	Short Antenna Connections. Check response curve to Fig. 8 and touch up where necessary.

DISCRIMINATOR AND SOUND I.F. ALIGNMENT

EQUIPMENT: A.M. Generator and V.T.V.M. indicator. Connect two matched 100K ohm resistors in series from Pin #2 of the 6T8 to chassis ground. Fig. 9

STEP NO.	SIGNAL GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	CHANNEL	CONNECT V.T.V.M.	FIGURE NO. 7 ADJUST	REMARKS
#7	High side thru .1 blocking condenser to side of Xtal (Y-1). Low side to chassis	4.5 M.C. (unmod) Max. Signal output of generator	2∙or 13	Pin #2 of 6T8 and chassis ground	F , H	Turn picture control (contrast) all the way counter-clockwise. Adjust for maximum reading. Use non- metallic screw driver.
#8	Same as Step #7	4.5 M.C. (unmod)	2 or 13	Move neg. lead of V.T.V.M. to point T. pos. lead to Point 5. Be sure V.T.V.M. case is not grounded during this adjustment.	G	The correct setting is when V.T.V.M. Pointer is at zero "cross over point." Use non-metallic screw driver.

DISCRIMINATOR AND SOUND I.F. SWEEP ALIGNMENT



MUNTZ TV, continued

DUMMY

carbon res.

Two 120 ohm

carbon res

STEP

No.

#9

#10

R.F. ALIGNMENT Remove 1st I.F. Amplifier tube V7 before making adjustments L, J, M. FIGURE SWEEP MASTER MARKER GENERATOR CONNECT No. 7 ADJUST OSC. GEN. ANTENNA COUPLING (MC) FREQ. (MC) CHANNEL SCOPE Across ant Adjust to response curve 207.50 Two 120 ohm term. with 120 205.25 R.F. Test Point N, Points (10 MC 12 Figure No. 12 with mark-L. J. M ohms in each 209.75 Figure No. 7 ers as shown. sweep) lead. 211.25 213.50 13 215.75

11

10

9

8

7

6

5

4

3

2

R.F. Test Point N.

Figure No. 7

199.25

203.75 193 25

197.75 187.25

191.75 181.25

185.75

175.25

179.75

83.25

87.75 77.25

81.75 67.25

71.75 61.25

65.75 55.25

59.75

201.50

195.50

189.50

183.50

177.50

85.50

79.50

69.50

63.50

57.50

Across ant

term. with 120

ohms in each

lead


REMARKS


Check all channels to see


that they have not been


seriously affected.

OSCILLATOR ALIGNMENT











OLYMPIC RADIO & TELEVISION INC.

Chassis TN-21, used in Models 21C65, 21C68, 21C72, 21C73, 21D60, 21D64, 21K61, 21K62, 21K63B, 21T58, 21T69, 21T70, and 21T74, is covered by diagrams below and on page 84. Chassis TM-17, used in Models 17C57, 17K55, 17T56, uses 17HP4 picture tube, but is very similar to TN chassis. TV section of the combination set TNA-21, Model 21K101, is also similar.





Packard-Bell

CHASSIS TYPE 2040 is a 20 tube TV chassis which mounts a 21 inch electrostatic focus picture tube on all models except the 17 inch table model. It features a Local-Distance switch located on the rear chassis apron to insure optimum performance in either fringe or metropolitan areas. This chassis is used on the following models: (VHF Tuner) (VHF-UHF Tuner)

2041	2141	Table Model, 21 inch
2042	2142	Standard Console, 21 inch
2043	2143	De Luxe Console, 21 inch
2044	2144	Table Model, 17 inch

Complete circuit diagram is printed on the next page, over.

ALIGNMENT PROCEDURE CHASSIS 2040

PICTURE I-F ALIGNMENT:

- Connect a vacuum tube voltmeter between point "A" and ground.
- Loosely couple signal generator to mixer tube in tuner.

Step 3.	Sig. Gen. Freqncy. 45.50 Mc.	Adjust S-15	For MAXIMUM
4.	45.50 Mc.	(mixer I-F in tuner) S-6	MAXIMUM
5.	41.80 Mc.	S-5	MUMIXAM
6.	43.30 Mc.	S-8	MAXIMUM
7.	44.50 Mc.	S-10	MAXIMUM
8.	39.75 Mc.	S-4 and S-9	Minimum
9.	47.25 Mc.	S-3 and S-7	Minimum

REPEAT STEPS 3 THROUGH 9

- Connect oscilloscope to point "B", using a 22,000 ohm isolating resistor in series with the scope probe. Connect an electrolytic capacitor, 5 mfd., 50 volt, between point "A" and ground, the negative lead to point "A".
- Connect sweep generator to antenna terminals through an impedance matching network. (Antenna terminals 300 ohms balanced.)
- 12. Rotate tuner to channel 3, and set sweep generator to center frequency of channel, (63 Mc.). With a sweep width of 10 Mc., adjust generator output to develop approximately 2 volts of A. G. C.
- 13. With signal generator loosely coupled to converter tube, adjust output to provide the markers shown on the response curve, Fig. 1. Check the position of the markers one at a time.
- 14. Observe the waveform obtained on the oscilloscope and compare it with the waveform shown in Fig. 1. If the spot frequency alignment has been carefully

done, the comparison will be favorable. However, slight retouching of the I-F adjustments may be required. It should not be necessary to change any adjustment appreciably. The markers should be located as follows:

The 47.25 Mc. and the 39.75 Mc. at minimum response. (These markers will be at too low a level to show on scope.)

The 45.75 Mc. marker at 50% response.

- The 43.30 Mc. marker at 95% response.
- The 45.00 Mc. marker at 97% response.

The 41.25 Mc. marker at 8% response.

IMPORTANT: The 45.00 Mc. marker must not exceed 97% response on channel 3 or picture may smear on higher channels.


ALIGNMENT OF 4.5 Mc. TRAP:


- Connect signal generator between point "B" and ground through a .001 mfd isolating capacitor.
- 2. Turn contrast control to maximum.
- Connect a R-F vacuum tube voltmeter to point "C". If an R-F VTVM is not available, connect a germanium diode crystal in series with the positive probe of a conventional VTVM.
- 4. Set signal generator to 4.50 Mc., exactly, with the output at one volt or more.
- 5. Adjust trap, S-11, for minimum VTVM reading

NOTE: If signal generator is not capable of one volt output, it will be necessary to adjust the trap by visual means. To do this, observe the picture and adjust the trap to eliminate the 4.5 Mc. beat.

SOUND I-F AND RATIO DETECTOR ALIGNMENT:

- Connect signal generator between point "B" and ground.
- 2. Connect VTVM between point "D" and ground.
- 3. With generator frequency at 4.50 Mc., adjust S-12 and S-1 for MAXIMUM output.
- 4. Connect VTVM between points "E" and "F".
- 5. Adjust Ratio Detector secondary, S-2, for zero between positive and negative peaks.






PHILCO

R-F CHASSIS R-181 AND DEFLECTION CHASSIS D-181

R-F Chassis R-181U incorporates a UHF tuner for UHF reception, and is used in UHF models.



For a complete list of models using these chassis, see listing on page 96. (This material is printed through the courtesy of the Philco Corp.)

CIRCUIT DESCRIPTION

Philco "B line", Code 130 Television Receivers use two chassis—r-f chassis R-181, containing the r-f, video, audio, and sync circuits, and deflection chassis D-181, containing the power and deflection circuits. Since these chassis are not isolated from the 60-cycle power line, all protruding shafts and mounting feet are insulated from the chassis.

CAUTION: See A-C LINE ISOLATION.

A separate subchassis contains the r-f amplifier, the oscillator, and the mixer. The r-f amplifier uses a 6BZ7 tube, V1. The oscillator and mixer each use one half of a 12AZ7 tube, V2. The output of the mixer is fed to a three-stage, stagger-tuned, i-f amplifier system employing three 6CB6 tubes. A type 1N64 crystal diode is used for the video detector, the output of which is amplified by a single-stage video amplifier utilizing a type 12BY7 tube, V6. The connections at the detector are such as to produce a composite video signal with negative-going sync pulses. The signal, which is subjected to a 180-degree phase shift through the video amplifier, is applied to the cathode of the picture tube; therefore, the sync pulses at this point are positive-going. The grid of the picture tube is returned to ground through a resistor (R309). A blanking pulse, taken from the vertical output stage, is applied across R309, for suppression of the vertical retrace.

Sound i.f. (intercarrier) is obtained by utilizing the beat frequency produced when the 26.6-mc. video carrier and the 22.1-mc. sound carrier are mixed in the video detector. The 4.5-mc. beat frequency is the difference between 26.6 mc. and 22.1 mc., and contains the FM sound signal. This 4.5-mc. signal contains only a negligible amount of video amplitude modulation, provided that the amplitude of the 22.1mc. signal is considerably lower than that of the 26.6mc. signal. The proper relationship between the two carriers is established during the alignment of the receiver. The oscillator is tuned primarily to obtain the best picture, since the 4.5-mc. relationship always exists between the two carriers. The 4.5-mc. sound i.f. (intercarrier), which is taken from the plate circuit of the video amplifier, is passed through a 4.5-mc. sound i-f stage using a 6AU6 tube, V7, and is then applied to the FM detector, which utilizes two diode sections of a 6T8 tube, V8A. The triode section of the 6T8, V8B, is used as the first audio amplifier. The power amplifier uses a 6K6CT tube, V9.

A portion of the video signal appearing at the grid of the video amplifier is applied to the pentode section of a 6U8 tube which operates as a sync amplifier, V10A. The output of this stage is composite video with positive-going sync, and is applied to grid 3 (pin 7) of the 6BE6 sync separator, V11. Since grid-leak bias is used on grid 3, the tips of the sync pulses are clamped to zero, and the video components swing in a negative direction from zero. Because of the cut-off characteristics of grid 3, the video components are eliminated, and only negative-going sync pulses appear in the plate circuit of the sync separator. At the same time, however, a signal is taken from the video detector and applied to grid 1 (pin 1) of the 6BE6 tube. This grid is returned to B plus, and the bias is maintained close to zero, because of a small grid-current flow. Since the signal applied to grid 1 is composite video with negative-going sync, any noise modulation present in the signal appears in the form of sharp spikes, driving in a negative direction. The circuit constants are chosen to allow grid 1 to cut off plate current whenever the signal goes more negative than the sync pulses. A series grid-limiting resistor (R614) is also incorporated, to prevent the video components from appearing in the plate circuit of the sync separator. A-G-C voltage is also developed in the sync separator circuit in the following manner: On tips of the sync pulses, grid 3 (pin 7) of the 6BE6 tube draws current, which flows downward

(Continued on the next 10 pages)

PHILCO CHASSIS TYPES R-181, D-181

through the network composed of R609, R610, R611, L214, and R211, causing capacitors C604, C602, and C603 to assume negative charges that are proportional to the amount of peak signal applied to grid 3. The tuner a-g-c voltage is delayed by means of a resistor divider network, which applies a small positive voltage to the tuner a-g-c circuit. This positive voltage prevents a-g-c action from lowering the tuner gain on weak signals. To prevent the delay voltage from driving the tuner a-g-c voltage positive on weak signals, a diode clamp (part of V8B) is connected across C602.

The negative-going sync pulses appearing in the plate circuit of the sync separator are fed to the sync inverter stage, V10B (triode section of the 6U8 tube). This stage acts as a phase-splitter circuit; positive sync pulses appear in the plate circuit, and negative sync pulses are taken from the cathode. Both positive and negative sync pulses are fed through the interchassis cable into the deflection chassis.

Proper triggering of the vertical oscillator requires negative synchronizing pulses. The vertical sync signal is separated from the horizontal sync signal by the integrator circuit, and is fed to the grid of the vertical oscilator (V12), a cathode-coupled multivibrator. The output of the vertical oscillator is amplified by a type 12B4 tube, V13, which is employed as the vertical output amplifier. The output of the amplifier is applied to the vertical-deflection coils through the vertical-output transformer.

The horizontal sweep circuits require both positive and negative sync pulses. The phase-comparer circuit uses a 6AL5 tube, V14. Positive sync pulses are applied to the plate of V14A, and negative sync pulses are applied to the cathode of V14B. A saw-tooth voltage is fed to the plate of V14B and to the cathode of V14A, for comparison of the sync and horizontal sweep voltages. When the saw-tooth and sync signals are exactly in phase, no voltage is developed across R800, but when the two signals are out of phase, either a positive or a negative voltage is developed, depending upon whether the horizontal-oscillator frequency is lower or higher than the sync-pulse frequency. The grid circuit of the horizontal oscillator, a 12AU7 (V15) cathode-coupled multivibrator, is connected to R800 through a filter network; when the voltage at this point goes in a positive direction, the frequency of the horizontal oscillator is increased, and when the voltage swings negative, the frequency of the oscillator is decreased. In this manner the frequency of the horizontal oscillator is controlled over the lock-in range of the circuit. The horizontaloscillator hold control (R812) adjusts the horizontaloscillator frequency so that it is within the control range of the phase comparer. The output of the

88

horizontal oscillator is fed to the horizontal output amplifier, which makes use of a 6BQ6GT tube, V16. The screen voltage for the horizontal amplifier is supplied from a voltage-divider network, R816, R817, (the WIDTH control), R818, R307 (the BRIGHTNESS control), and R311 are parts of this divider. R817 varies the voltage applied to the screen, thus adjusting for proper picture width. Adjusting R307 for brightness varies the bias on the picture tube. The change in bias causes a change in beam current, and would tend to result in a change in picture width and variation in the second-anode voltage. However, when the control arm of the BRIGHTNESS control, R307, is moved toward ground, less of the control is shunted by the 22K resistor, R311, and the total resistance of the voltage divider is increased. This increase in resistance results in a decrease in the current through the divider, and the screen voltage on the horizontal amplifier is increased proportionally, thus compensating automatically for the increase in beam current in the picture tube. The horizontal amplifier feeds the deflection coils through the horizontal output transformer. A 6AX4GT tube, V17, is used as the horizontal damper.

The second-anode voltage for the picture tube is supplied by one 1B3GT high-voltage rectifier tube, V18. The B plus voltage for the receiver is supplied by two selenium rectifiers, CR100 and CR101, in a full-wave, voltage-doubler circuit, operating directly from the power line. Bias voltage is obtained from across a filter choke, L405, which is in series with the negative side of the B plus supply. The B plus boost voltage, derived from the horizontal damper circuit, supplies higher B plus voltage to the vertical oscillator and the first anode of the picture tube. Filament voltage for all the tubes except the high-voltage rectifier is supplied by a step-down transformer. Filament voltage for the high-voltage rectifier is supplied by a winding on the horizontal output transformer.

IMPORTANT A-C LINE ISOLATION

CAUTION: One side of the a-c line is connected to the chassis through C101 and L405. The other side of the a-c line is connected to the chassis through R100, F100, CR100, and C103, in series. Grounding the chassis will result in a short circuit across one or the other of these two branches in the voltage-doubler circuit. During servicing and alignment it is desirable that an a-c line isolation transformer capable of handling at least 225 watts (Philco Part No. 45-9600) be used. Failure to use an isolation transformer will greatly increase the shock hazard, and may result in damage to the test equipment or receiver, or both.

PHILCO CHASSIS TYPES R-181, D-181

HORIZONTAL-OSCILLATOR ADJUSTMENT

To adjust the horizontal-oscillator circuit, tune in a station and proceed as follows:

1. Reduce the width of the picture until approximately 1 inch of blank screen appears at the righthand and left-hand sides of the picture.

2. Increase the BRIGHTNESS control setting until the blanking becomes visible. This will appear as a dark vertical bar on each side of the picture.

3. Connect a .1- μ f. condenser from the test point, adjacent to TC800, to ground. (The plate side of the horizontal ringing coil, L800, is connected to the test point.)

4. Set the HORIZONTAL HOLD control to the approximate center of its mechanical rotation.

5. Adjust the HORIZ. HOLD CENTERING control until equal portions of the blanking bar appear on both sides of the picture.

6. Remove the .1- μ f. condenser from the test point.

7. Adjust the horizontal ringing coil, L800, until equal portions of the blanking bar again appear on both sides of the picture.

8. Rotate the HORIZONTAL HOLD control through its range. The picture should fall out of sync on both sides of the center of its rotation. If the picture does not fall out of sync on both sides, readjust the HORIZ. HOLD CENTERING control.

9. Rotate the HORIZONTAL HOLD control through its range, and observe the number of diagonal blanking bars that appear just before the picture pulls into sync. The pull-in should occur with from 1 to 2 diagonal bars when the sync position is approached from either direction. If proper pull-in is not obtained, repeat the above procedure.

VIDEO-DETECTOR PEAKING-COIL ADJUSTMENT

The video-detector peaking coil, L214, is adjusted at the factory for proper transient response of the video circuit. Ordinarily, this coil will require no further adjustment by the serviceman. On any station where excessive overshoot or excessive smear is present, a slight adjustment of L214 may improve the picture quality on that station; however, this adjustment may sacrifice the quality on other channels. If L214 is replaced in servicing, adjustment will be required.

Before adjusting L214, check the tuner alignment and i-f alignment. (Never adjust L214 until the alignment of the receiver is correct.) Then tune in a station and adjust L214 until there are no trailing whites or smear in the picture. Turning TC206 clockwise reduces trailing whites and overshoot; turning TC206 counterclockwise reduces picture smear and increases trailing whites. The proper position is the point where no smear or trailing whites appear in the picture.

TELEVISION ALIGNMENT

GENERAL

The alignment consists of tuning each i-f coil to a given frequency, using an AM signal, and then feeding in a sweep signal at the antenna terminals and touching up the adjustments to obtain the desired pass band.

The over-all response curve (r-f, i-f) of the circuits from the antenna terminals to the video detector, after the i-f stages have been aligned, should appear essentially the same, regardless of the channel under test. If not, the tuner should be aligned.




Figure 1. Antenna-Input Matching Network





Figure 2. Video I-F Alignment Jig

TELEVISION TUNER ALIGNMENT

After the tuner is serviced, or if an i-f alignment is required, the tuner alignment should be checked by observing the tuner response curve, as given under Bandpass Alignment. If the response curve does not fall within the limits shown in figure 5, the tuner should be realigned. If realignment is necessary, use the procedure given below.

Since the frequency of the local oscillator affects the tuner response, the local-oscillator alignment should be made first.



Oscillator Alignment

General

Tuning cores are provided in the oscillator coils at channels 13, 11, 9, 7, 6, and 4. By adjusting these tuning cores, all channels may be placed on frequency. This procedure should be carried out with the highest-frequency channel first, since the alignment of each channel affects the alignment of all the channels below it in frequency. The channel adjustments are so arranged that, with one exception, each adjustment corrects the tuning of more than one channel. The coverage of the various adjustments is as follows:

Channel Adjustment	Channels Corrected By Adjustment
13	13 and 12
11	11 and 10
9	9 and 8
7	7 only
6	6 and 5
4	4, 3, and 2

The FINE TUNING cam should be preset for all adjustments by placing the stop on the FINE TUN-ING cam between the Channel 7 and 8 holes on the front plate of the tuner. See figure 4.




Figure 4. Television Tuner, Showing Locations of Adjustments

Figure 3. Sound I-F Alignment Jig

Procedure Using Signal Generator

An r-f signal (unmodulated), at the oscillator frequency, is fed into the antenna input from an AM signal generator, and the oscillator tuning cores are adjusted for zero beat. The r-f signal frequency should be accurately determined. It is preferable that the signal be taken from a crystal-controlled source; if this is not available, the signal generator may be calibrated against the television station.

1. Connect the hot lead of the oscilloscope to the mixer plate test point, G2, through a 1000-ohm resistor, and connect the ground lead of the oscilloscope to the chassis, near the test point. (High oscilloscope gain may be necessary to obtain a visual beat. In this instance, base-line hum may be ignored.)

2. Connect the AM (marker) generator to the 300ohm antenna-input terminals. For this purpose the antenna-input matching network is not required.

3. Disconnect the white (a-g-c) lead from the tuner, and connect it to the negative terminal of a $1\frac{1}{2}$ -volt battery. Ground the positive terminal. If regeneration is observed, the bias may be increased to 4 or 5 volts, to reduce the regeneration.

4. Mechanically preset the fine-tuning cam as shown in figure 4.

5. Feed in an r-f signal (unmodulated), at the oscillator frequency for Channel 13, with the CHANNEL SELECTOR set for Channel 13.

6. Adjust the Channel 13 tuning core (see figure 4).7. Reset the signal-generator frequency and the CHANNEL SELECTOR, and adjust the tuning cores for Channels 11 and 9, respectively.

8. Repeat steps 5, 6 and 7 until Channels 13, 11, and 9 are within plus or minus 500 kc. of the correct frequency.

9. Feed in r-f (unmodulated) signals, at the oscillator frequencies for Channels 7, 6, and 4, consecutively (see NOTE below), and adjust the respective tuning cores (see figure 4).

NOTE: The exact position of the FINE TUNING cam should be marked when Channel 4 is correctly aligned. This position is to be used in step 4 of the i-f alignment procedure.

PHILCO CHASSIS TYPES R-181, D-181

Procedure Using Station Signal

The following simplified procedure may be used to align the oscillator when the television i-f alignment is satisfactory and a station signal is available:

1. Mechanically preset the FINE TUNING cam to the center of its range (see figure 4).

2. Tune in the highest-frequency channel to be received.

3. Adjust the tuning core for that channel, or the next highest channel, for the best picture; that is, starting with sound in the picture, turn the tuning core until the sound disappears. Repeat for each channel received in the area.

Bandpass Alignment

General

The bandpass alignment consists of aligning the tuner at Channels 13 and 6, and then making it track down to Channels 7 and 2, respectively.

During the alignment, a fixed bias of 1½ volts is applied to the r-f amplifier tube.

An FM (sweep) signal is applied to the antennainput circuit, and an oscilloscope is connected to the mixer plate circuit. The oscilloscope gain should be as high as possible, consistent with hum level and "bounce" conditions. Hum conditions will cause distortion of the time base and response. Bounce conditions, which are caused by poor line regulation, will cause the response and time base to jump up and down. The use of too high an oscilloscope gain aggravates these conditions, whereas the use of too low a gain necessitates increasing the generator output to a point where the tuner may be overloaded. Overload may be checked by changing the generator output while observing the shape of the response curve; any change in the shape of the curve indicates overload, in which case a lower generator output and higher oscilloscope gain must be used. The tuner coupling link should be disconnected from the i-f section and a 40- to 70-ohm resistor connected across the open end of the link, to eliminate the absorption effect of this coil on the response curve.

1. Disconnect the white (a-g-c) lead from the tuner, and connect it to the negative terminal of a 1½-volt battery. Ground the positive terminal.

2. Disconnect the tuner link at terminal board B11-5 and B11-7 (see figure 36), and connect a 40- to 70-ohm carbon resistor to the two leads of the link.

3. Connect a 1000-ohm resistor in series with the hot lead of the oscilloscope. Connect the other end of the resistor to the mixer plate test point, G2, and connect the ground lead of the oscilloscope to the chassis, near the test point.

4. Connect the FM (sweep) generator to the 300ohm antenna-input terminals through an antenna-input matching network. See figure 1.




Figure 5. Television Tuner Response Curve, Showing Bandpass Limits

Procedure

1. Set the CHANNEL SELECTOR and FM (sweep) generator to Channel 13 (213 mc.): Adjust the generator for sufficient sweep to show the complete response curve.

2. Establish the channel limits (see figure 5) by using the marker (AM r-f) signal generator to produce marker pips on the response curve. (Set the marker generator first to 210 mc., then to 216 mc.) The curve should be reasonably flat between the limits shown in figure 5.

3. Adjust TC502 and TC504 (figure 4) for a symmetrical, approximately centered pass band. Set the marker generator to 213 mc. Detune TC504 counterclockwise until a single peak appears. Adjust TC502 until the peak falls on the 213-mc. marker. It may be necessary to increase the output of the generator during this adjustment. Then adjust TC500 for maximum curve height and symmetry of the single peak. The antenna circuit is now tuned for the highfrequency channels.

4. Readjust TC502 and TC504 for a symmetrical response, centered about 213 mc., and falling within the limits shown in figure 5.

5. Set the CHANNEL SELECTOR and FM generator to Channel 7 (177 mc.).

6. Establish the channel limits by using the marker generator to produce marker pips on the response curve. (Set the generator first to 174 mc., then to 180 mc.). The curve should be reasonably flat between the limits.

7. On Channel 7, note the response curve, with respect to tilt and center frequency. The curve should be centered in the pass band, and should be symmetrical.




Figure 6. Television Tuner Response Curve, Showing Tracking Compensation

8. If the curve is not symmetrical, and appears unbalanced, as shown in figure 6, leave the generator and tuner set to Channel 7, and adjust C508 and C512 (see figure 4) to obtain a response curve which is the mirror image (tilt in the opposite direction) of the original. This is a form of overcompensation, to allow for the effect of Channel 13 adjustment on Channel 7. For example, if the Channel 7 response appears as in figure 6A, then the trimmer should be adjusted to obtain the response shown in figure 6B.

9. Reset the CHANNEL SELECTOR and generators to Channel 13. Readjust TC502 and TC504 for a symmetrical and centered pass band. See step 4.

10. Set the CHANNEL SELECTOR and generators to Channel 7, and check the response for center frequency and symmetry. Repeat steps 8 and 9 as many times as necessary to obtain the most symmetrical and centered response curves on Channels 13 and 7. Channels 7 through 13 are now correctly aligned.

11. Set the CHANNEL SELECTOR and sweep generator to Channel 6 (85 mc.).

12. Establish the channel limits, using the marker generator to produce marker pips on the response curve. (Set the generator first to 82 mc., then to 88 mc.)

13. Adjust TC503 and TC505 for a symmetrical, approximately centered pass band. Set the marker generator to 85 mc. Detune TC505 counterclockwise until a single peak appears.

CAUTION: Do not turn TC505 excessively, or it will fall out of the coil.

Adjust TC503 until the peak falls on the 85-mc. marker. It may be necessary to increase the output of the generator during this adjustment. Then adjust TC501 for maximum curve height and symmetry of the single peak. The antenna circuit is now tuned for Channels 2 through 6. To prevent overloading, the output of the generator should be reduced after this adjustment is completed.

14. Readjust TC503 and TC505 for a symmetrical response, centered about 85 mc.

VIDEO I-F ALIGNMENT

Preliminary

Before proceeding with the alignment or making an alignment check, observe the following preliminary instructions:

1. Preset the CONTRAST and BRIGHTNESS controls to the maximum counterclockwise position.

2. Preset the CHANNEL SELECTOR to Channel 4.

3. Insert the video i-f alignment jig into J200.

4. Connect the oscilloscope to the 2200-ohm resistor from the video i-f alignment jig. Connect the ground lead of the oscilloscope to the ground lead of the jig.

5. Connect a 3-volt bias battery to the video i-f alignment jig, with the negative terminal of the battery to the bias lead of the jig, and the positive terminal to the ground lead.

6. Connect the AM generator to the mixer test point, G-1, through a mixer jig, and adjust the generator for approximately 30 percent modulation at 400 cycles. Adjust the output of the generator during alignment, to keep the output at the second detector below .6 volt, peak to peak.




Figure 7. R-F Chassis R-181, Top View, Showing Locations of Adjustments

Procedure

1. Tune the AM generator to 28.1 mc., and adjust TC200 (see figure 7) for minimum output, as observed on the oscilloscope.

2. Tune the AM generator to 22.1 mc., and adjust TC203 for minimum output, as observed on the oscilloscope.

NOTE: In steps 1 and 2 it is necessary to keep the generator output sufficiently high that a null indication may be observed on the oscilloscope; however, avoid overloading of the receiver by excessive signal. 5. If the response curve does not fall within the limits shown in figure 8, the adjustment of the tuning cores may be touched up slightly while observing the response curve with the sweep generator. Do not touch the setting of TC200 and TC203. To adjust the curve, adjust TC201 and TC204 for proper video carrier level. The top of the curve may be leveled by adjusting TC205, and the low-frequency

LECTOR to Channel 4, and tune the sweep gen-

erator for output on Channel 4. After the equipment is properly connected, adjust the FINE TUN-

ING control to the mark previously made (see NOTE

under Oscillator Alignment).

PHILCO CHASSIS TYPES R-181, D-181

Circuit diagrams on the next three pages.

side of the curve may be adjusted by adjusting TC202. By means of these adjustments the response curve should be brought within the limits shown in figure 8.

CAUTION: Do not turn any of the tuning cores excessively. To retouch, only turn the tuning cores slightly. This caution applies particularly to TC202.

SOUND 1-F ALIGNMENT

1. Remove the 1st v-i-f tube, and connect a v.t.v.m. or a 20,000-ohms-per-volt voltmeter to the sound i-f alignment jig. Adjust the VOLUME control for moderate speaker output.

2. Feed in an accurately calibrated 4.5-mc. AM signal through the 2200-ohm resistor in the video i-f alignment jig, to pin 2 of J200.

3. Tune TC400, TC401, and TC402 for maximum indications on the meter. The point of maximum meter indication for TC402 should also be the point of minimum speaker output.


4. Tune TC402 for minimum speaker output.

5. Connect an r-f probe or crystal detector to the cathode (pin 11) of the picture tube. See NOTE below.

6. Tune TC300 for minimum indication on oscilloscope. (If a crystal detector is not available, TC300 may be adjusted for minimum beat pattern, as observed on the picture tube, with a station picture present.)

7. Replace the 1st v-i-f tube. Tune in a station and use the speaker output as an indication.


8. Turn the FINE TUNING control clockwise to obtain a slightly fuzzy picture.




1N34 CRYSTAL 220UUF PART NO PART NO. 62-122001001 54-6001 то 100,000 OHMS 470 U U F 100,000 OHMS OSCILLOSCOPE PART NO PART NO. PART NO INPUT 66-4108340 62-147001001 66-4108340 GND


Figure 9. Wiring Diagram of Crystal Detector

9. Tune TC402 for minimum AM (noise) output. NOTE: The R-F Probe, Part No. 76-3595, is used as a detector of the 4.5-mc. signal, and the oscilloscope is used as an indicating device. An alternate crystal detector may be made up as shown in figure 9.




PHILCO CHASSIS TYPES R-181, D-181






PHILCO CHASSIS TYPES R-181, D-181



PHILCO

R-F CHASSIS R-191 AND DEFLECTION CHASSIS D-191



R-F Chassis R-194 and Deflection Chassis D-194 used in combination sets, are similar to units R-191 and D-191, described on pages 98 to 104, inclusive. Chassis R-191U incorporates a UHF tuner to provide UHF reception. Chassis R-192U uses a different VHF tuner and a UHF tuner unit. A complete list of models using these chassis is given on page 102.

Philco "B" line, Code 140, Television Receivers use two chassis—the r-f chassis R-191, containing the r-f, video, audio, and sync circuits, and deflection chassis D-191, containing the power and deflection circuits. Since these chassis are not isolated from the 60-cycle power line, all protruding shafts and mounting feet are insulated from the chassis.

HORIZONTAL-OSCILLATOR ADJUSTMENT

To adjust the horizontal-oscillator circuit, tune in a station and proceed as follows:

1. Reduce the width of the picture until approximately 1 inch of blank screen appears at the righthand and left-hand sides of the picture.

2. Increase the BRIGHTNESS control setting until the blanking becomes visible. This will appear as a dark vertical bar on each side of the picture.

3. Connect a .1 μ f. condenser from the test point, adjacent to TC800, to ground. (The plate side of the horizontal ringing coil, L800, is connected to the test point.)

4. Set the HORIZONTAL HOLD control to the approximate center of its mechanical rotation.

5. Adjust the HORIZ HOLD CENTERING control until equal portions of the blanking bar appear on both sides of the picture.

6. Remove the .1- μ f. condenser from the test point.

7. Adjust the horizontal ringing coil, L800, until equal portions of the blanking bar again appear on both sides of the picture.

8. Rotate the HORIZONTAL HOLD control through its range. The picture should fall out of sync on both sides of the center of its rotation. If the picture does not fall out of sync on both sides, readjust the HORIZ HOLD CENTERING control.

9. Rotate the HORIZONTAL HOLD control through its range, and observe the number of diagonal blanking bars that appear just before the picture pulls into sync. The pull-in should occur with from 1 to 2 diagonal bars when the sync position is approached from either direction. If proper pull-in is not obtained, repeat the above procedure.

VIDEO PEAKING-COIL ADJUSTMENT

The video peaking coil, L303, is adjusted at the factory for proper transient response of the video circuits. Ordinarily, this coil will require no further adjustment by the serviceman. On any station where excessive overshoot or excessive smear is present, a slight adjustment of L303 may improve the picture quality on that station; however, this adjustment may sacrifice the quality on other channels. If L303 is replaced in servicing, adjustment will be required.

Before adjusting L303, check the tuner alignment and i-f alignment. (Never adjust L303 until the alignment of the receiver is correct.) Then tune in a station and adjust L303 until there are no trailing whites or smear in the picture. Turning TC301 clockwise reduces trailing whites and overshoot; turning TC301 counterclockwise reduces picture smear and increases trailing whites. The proper position is the point where no smear or trailing whites appear in the picture.

The above procedure for adjustment of TC301 applies to a particular station exhibiting smear or overshoot. After TC301 is adjusted, reception on all the other stations should be checked, to make certain that the adjustment has not impaired the picture quality.

PHILCO R-191 and D-191, continued

VIDEO I-F ALIGNMENT

Preliminary

Before proceeding with the i-f alignment or making an alignment check, observe the following preliminary instructions:

1. Preset the CONTRAST and BRIGHTNESS controls to the maximum counterclockwise position.

2. Preset the CHANNEL SELECTOR to Channel 4.

3. Insert the video i-f alignment jig (figure 2) into J200.

4. Connect the oscilloscope to the 15,000-ohm resistor from the video i-f alignment jig. Connect the ground lead of the oscilloscope to the ground lead from the adapter.

5. With a voltmeter connected across the points shown in figure 2, set the potentiometer to furnish -6 volts of bias.

6. Connect the AM generator to the mixer test point, G1, through a mixer jig (described in step 4 of procedure given below), and adjust the generator for approximately 30 percent modulation with 400 cycles. Adjust the output of the generator during the alignment to keep the output at the second detector below .6 volt, peak to peak.

Procedure

1. Preset condenser C526 for minimum capacitance (turn screw counterclockwise).

2. Tune the AM generator to 47.25 mc., and adjust C200 for minimum output, as observed on the oscillo-scope. See figure 7.

NOTE: It is necessary to keep the generator output sufficiently high that a null indication may be observed on the oscilloscope; however, avoid overloading of the receiver by excessive signal. 3. Tune the AM generator to the frequencies indicated below, and adjust the trimmers for maximum output, as observed on the oscilloscope.

- a. 45.7 mc.-adjust C526
- b. 42.6 mc.--adjust C202
- c. 45.0 mc.--adjust C206
- d. 43.2 mc.—adjust C210
- e. 44.3 mc.—adjust C212

4. Connect the sweep generator and r-f marker generator to the antenna terminals through a matching jig. (If a separate oscilloscope is used, connect the sweep output of the generator to the horizontal input of the oscilloscope.) Set the CHANNEL SELECTOR





Figure 2. Video I-F Alignment Jig



PHILCO R-191 and D-191, continued




Figure 7. R-F Chassis R-191, Top View, Showing Locations of Adjustments

to Channel 4, and tune the sweep generator for output on Channel 4. Tune the r-f marker generator to the video carrier frequency of Channel 4 (67.25 mc.), and tune the i-f marker generator (capacitively coupled to the mixer grid) to 45.75 mc. Note two marker generators are used for this procedure. The r-f marker generator is connected to the antenna terminals, while the i-f marker generator is coupled capacitively to the mixer grid test point, G1. A jig constructed from a piece of fiber tubing, with $3'_{16}$ -inch inside diameter, and a brass machine screw which fits tightly into the tubing, is used to couple the generator capacitively to the test point. The

screw is adjusted so that its tip clears the test point by approximately $\frac{1}{64}$ inch. The output cable of the marker generator is connected to the head of the brass screw in the jig and to the chassis near the mixer tube. Both marker generators should be adjusted for the minimum output required to make the markers barely visible. Failure to observe this precaution, or the use of excessive output from the sweep generator, will cause misleading results. After the equipment is properly connected, adjust the FINE TUN-ING control for zero beat of the two markers, as observed on the oscilloscope. When zero beat is obtained, remove the i-f marker.

5. If the response curve does not fall within the limits shown in figure 8, the adjustment of the trimmers may be touched up slightly, while observing the response curve. Do not retouch the setting of C202 at this point. To adjust the curve, first adjust C206 and C212, alternately, until maximum improvement has been obtained. C212 affects the tilt of the curve, and C206 affects the dip of the curve. After C212 and C206 have been adjusted, adjust C210 for proper slope at the 42.5-mc. side of the curve, then adjust C526 for proper level at the video carrier frequency (45.75 mc.). After these adjustments have been made, if the response curve still does not fall within the limits shown in figure 8, a slight readjustment of C202 is permissible.

CAUTION: Do not turn any of the trimmers excessively. To retouch, turn the trimmers only slightly.

SOUND I-F ALIGNMENT

1. Remove the 1st v-i-f tube, and connect a v.t.v.m. or a 20,000-ohms-per-volt voltmeter to the sound i-f alignment jig (figure 3). Adjust the VOL-UME control for moderate speaker output.

2. Feed in an accurately calibrated 4.5-mc. AM signal, through the 2200-ohm resistor in the video i-f alignment jig, to pin 2 of J200.

3. Tune TC400, TC401, and TC402 for maximum indications on the meter. The point of maximum meter indication for TC402 should also be the point of minimum speaker output.

4. Tune TC402 for minimum speaker output.

5. Connect an r-f probe or crystal detector to the grid (pin 2) of the picture tube. See NOTE below.

6. Tune TC300 for minimum indication on oscilloscope. (If a erystal detector is not available, TC300 may be adjusted for minimum beat pattern, as observed on the picture tube, with a station picture present.)

7. Replace the 1st v-i-f tube. Tune in a station, using the speaker output as an indication of correct tuning.

PHILCO R-191 and D-191, continued






Figure 8. Over-All, R-F, I-F Response Curve, Showing Tolerance Limits










Figure 9. Wiring Diagram of Crystal Detector


8. Turn the FINE TUNING control clockwise to obtain a slightly fuzzy picture.

9. Tune TC402 for minimum AM (noise) output.


NOTE: The R-F Probe, Part No. 76-3595, is used as a detector of the 4.5-mc. signal, and the oscilloscope is used as an indicating device. An alternate crystal detector may be made up as shown in figure 9.


OSCILLOSCOPE WAVEFORM PATTERNS

These waveforms were taken with the receiver adjusted for an approximate peak-to-peak output of 2 volts at the video detector. The voltages given with the waveforms are approximate peak-to-peak values. The frequencies shown are those of the waveforms not the sweep rate of the oscilloscope.




Vertical-Oscillator Plate, Pin 6 260 volts, 60 c.p.s.






PHILCO Circuit Diagram of R-F Chassis R-191

SECTION 4-SOUND



PHILCO Deflection Chassis D-191



104

Figure 35. Deflection Chassis D-191, Schematic Diagram

PHILCO R-F CHASSIS R-201 DEFLECTION CHASSIS D-201

R-F Chassis R-202 and R-204, and Deflection Chassis D-202 and D-204, are used in combination sets, and are similar to R-F Chassis R-201 and Deflection Chassis D-201 described on pages 105 to 110, inclusive.

List of models using these chassis is printed on page109.

VIDEO I-F ALIGNMENT Preliminary

1. Preset the CONTRAST and BRIGHTNESS controls to the maximum counterclockwise position.


2. Preset the CHANNEL SELECTOR to Channel 4.

3. Insert the video i-f alignment jig into J200.

4. Connect the oscilloscope to the 15,000-ohm resistor from the video i-f alignment jig. Connect the ground lead of the oscilloscope to the ground lead from the adapter.

5. With a voltmeter connected across the points shown in figure 2, set the potentiometer to furnish -14 volts of bias.

6. Connect the AM generator to the mixer test point, G1, through a mixer jig, and adjust the generator for approximately 30 percent modulation at 400 cycles. Adjust the output of the generator during the alignment to keep the output at the second detector below .6 volt, peak to peak.




PHILCO R-201 and D-201, continued

NOTE: If the i-f shield has been removed for repairs, it must be replaced before proceeding with the alignment.

Procedure

1. Tune the AM generator to 47.25 mc., and adjust C201 for minimum output, as observed on the oscilloscope.



2. Tune the AM generator to 41.25 mc., and adjust C203 for minimum output, as observed on the oscilloscope.

3. Tune the AM generator to the frequencies indicated below, and adjust the trimmers (see figure 8) for maximum output.

a.	42.7 mc.—adjust C514
b.	44.75 mcadjust C204
c.	45.7 mcadjust C210
d.	44.4 mc.—adjust C215
e.	43.0 mcadjust C218
f.	42.0 mc.—adjust C206
	-

4. Increase the bias (by means of the potentiometer) until the scope presentation of step f, above, is reduced to 50 percent of its previous amplitude, and retouch C206 for maximum indication on the oscilloscope.

5. Connect the sweep generator and r-f marker generator to the antenna terminals through a matching jig. (If a separate oscilloscope is used, connect the sweep output of the generator to the horizontal input of the oscilloscope.) Set the CHANNEL SE-LECTOR to Channel 4, and tune the sweep generator for output on Channel 4. Tune the r-f marker generator for the video carrier frequency of Channel 4 (67.25 mc.), and tune the i-f marker generator (connected through jig to mixer grid) to 45.75 mc. Note that two marker generators are used for this procedure. The r-f marker generator is connected to the antenna terminals, while the i-f marker generator is connected capacitively to the mixer grid test point, G1. A jig constructed from a piece of fiber tubing, with $\frac{3}{16}$ inch inside diameter, and a brass machine screw which fits tightly into the tubing, is used to connect the generator capacitively to the test point. The screw is adjusted so that it clears the test point by approximately $\frac{1}{64}$ inch. The output cable of the marker generator is connected to the head of the brass screw in the jig and to chassis near the mixer tube. Both marker generators should be adjusted for the minimum output required to make the markers barely visible. Failure to observe this precaution, or the use of excessive output from the sweep generator, will cause misleading results. After the equipment is properly connected, adjust the FINE TUN-ING control for zero-beat of the two markers, as observed on the oscilloscope. When zero beat is obtained, remove the i-f marker.

6. If the response curve does not fall within the limits, as shown in figure 9, the adjustment of the trimmers may be touched up slightly, while observing the response curve. Do not retouch the setting of C201, C203, or C206. To adjust the curve, first ...djust C215 and C218 alternately until maximum improvement has been obtained. C215 affects the tilt




Figure 9. Over-all R-F, I-F Response Curve

of the curve, and C218 affects the dip of the curve. After C215 and C218 have been adjusted, adjust C514 for proper slope at the 42.25-mc. side of the curve, and then adjust C204 and C210 for proper level at the video carrier frequency (45.75 mc.).

CAUTION: Do not turn any of the trimmers excessively. To retouch, only turn the trimmers slightly.

SOUND I-F ALIGNMENT

The sound i-f system may be aligned by the use of a station signal or an accurately calibrated signal gencrator, for the signal source. If the station signal is used, tune the FINE TUNING control for the best picture, regardless of sound. It will be necessary to reduce the signal input to the receiver, so that the d-c output at the sound detector, as measured with the aid of the sound i-f output alignment jig (between point "B" and ground), is kept below 5 volts, maximum, and preferably below 3 volts. To establish this level in strong signal areas, it may be necessary to short the antenna terminals and to apply bias to the a-g-c circuit. The signal input to the receiver may be adjusted by varying the length of the shorting lead. The bias may be applied to the a-g-c circuit by means of the jig shown in figure 3. The sound i-f output alignment jig shown in figure 4 should be used for convenient connection of the meter to the sounddetector output.

When a signal generator is used, bias should be applied to the a-g-c circuit, to avoid any possibility of regeneration, using the sound i-f input alignment jig (figure 3). In addition, the first video i-f tube should be removed, to aid in the reduction of circuit noises from the i-f system.

1. Connect the generator through the 2200-ohm resistor, in the sound i-f input alignment jig, to pin 2 of J200. The generator should be adjusted for unmodulated output at 4.5 mc.

2. Insert the sound i-f output alignment jig into the volume-control socket (J401), and insert the volume-control plug (PL401) into the top of the jig. Connect the clip lead to the FM test point (J400); connect a 20,000-ohms-per-volt voltmeter between point "B" and the ground lug of the jig, with the negative lead of the meter going to point "B."

3. Adjust TC300, TC400, TC401, and TC402 for maximum output, as indicated on the meter. If the output exceeds 5 volts, reduce the signal input to the receiver.

4. Shift the positive lead of the meter to point "C" on the sound i-f output alignment jig, and adjust TC403 for zero crossover. Zero crossover is indicated by a zero indication on the meter. When TC403 is turned in one direction from this zero point, the meter will swing positive; turning TC403 in the opposite direction will cause a negative swing. (To aid in reading a positive and negative swing on the meter, set the pointer, by means of its zero-adjustment screw, to a convenient calibration mark on the scale, before connecting the meter to the circuit.)

5. Replace the first video i-f tube, and tune in a station on the receiver. Turn the FINE TUNING control to obtain a slightly fuzzy picture, and retouch TC403 for minimum AM (noise), using the speaker output as an indication.

ADJUSTMENT OF 4.5-MC. TRAP

1. Tune in a strong station signal.

2. Turn the FINE TUNING control in the clockwise direction until a fine beat pattern appears in the picture.

3. Adjust TC301 until the beat disappears or is at a minimum. When correctly adjusted, the screw will be out from the chassis approximately % inch.

4. If more than one station is available, check the setting of TC301 on all stations.


MOST-OFTEN-NEEDED 1954 TELEVISION SERVICING INFORMATION PHILCO Circuit Diagram of R-F Chassis R-201 SECTION 5-RF С510 НС 0.59 ЦЦ F AGC (505 11 220 /號 125 1 245 V R508 ____]| C 508 1000 1 800 2 12AZ 6BZ7 RF AMPL R505 - C509 \$ R507 \$ 1,5MEG 15 125 V C522 V2B ςų R509 524 39 TAPERED LINE ASSEMBLY RANGE TC 50ws5000 WS \$00 D (F) ١Ę w550 A513 t W5500A (R) WS 500 D(R) 12 03 0 3 Q, 5 500 C (R. 220 SECTION 2-IF V 3 V 4 2₩0 ₩F 6C86 V 5 3RD VIF 6C86 V 6 4TH VIF 6C86 TUNER LIN TEST LUG (ON BI3) ≩≳ິ≈ Ī 1209 RFC • 125 V R207 220 R224 **₽**250 V C2248 C2 20 C224A 220 L C221 PL 20 Figure 40. R-F Chassis R-201, Schematic Diagram


108

OPTIONAL PILOT LIGHT CON

ECTION

PHILCO Circuit Diagram of R-F Chassis R-201





RCAVICTOR

TELEVISION RECEIVERS — MODELS 21-T-356 U, 21-T-363, 21-T-363 U, 21-T-364, 21-T-364 U, 21-T-365, 21-T-365 U, 21-T-372, 21-T-372 U, 21-T-373, 21-T-373 U, 21-T-374, 21-T-374 U, 21-T-375, 21-T-375 U

Chassis Nos. KCS83, KCS83B or KCS83E

The circuit on the next two pages, over, is exact for Chassis KCS-83B used in "U" models. KCS-83E used in 21T356U is identical but employs 21EP4A picture tube. Other models use Chassis KCS-83 which is practically identical to KCS-83B but has KRK-29 tuner unit for VHF only.

Chassis <u>KCS-83C</u> used in Models <u>21S354</u> and <u>21S362</u> with tuner KRK-29, and Chassis <u>KCS-83D</u> used in Models <u>21S354U</u> and <u>21S362U</u> with tuners KRK-29A and KRK-27 (UHF), are very similar to chassis listed above.

ION TRAP MAGNET ADJUSTMENT.—Set the ion trap magnet approximately in the position shown in Figure 2. Starting from this position immediately adjust the magnet by moving it forward or backward at the same time rotating it slightly around the neck of the kinescope for the brightest raster on the screen. Reduce the brightness control setting until the raster is slightly above average brilliance. Turn the focus control (shown in Figure 2) until the line structure of the raster is clearly visible. Readjust the ion trap magnet for maximum raster brilliance. The final touches of this adjustment should be made with the brightness control at the maximum clockwise position with which good line focus can be maintained.




Figure 2-Yoke and Focus Magnet Adjustments

DEFLECTION YOKE ADJUSTMENT.—If the lines of the raster are not horizontal or squared with the picture mask, rotate the deflection yoke until this condition is obtained. Tighten the knurled yoke adjustment nuts.

PICTURE ADJUSTMENTS. — It will now be necessary to obtain a test pattern picture in order to make further adjustments.

If the receiver is overloading, turn RI54 on the rear apron (see Figure 3) counter-clockwise until the set operates normally and the picture can be synced.

If the Horizontal Oscillator and AGC System are operating properly, it should be possible to sync the picture at this point. However, if the AGC control is misadjusted, and the receiver is overloading, it may be impossible to sync the picture.

CHECK OF HORIZONTAL OSCILLATOR ALIGN-MENT.—Turn the horizontal hold control to the extreme counter-clockwise position. The picture should remain in horizontal sync. Momentarily remove the signal by switching off channel then back. Normally the picture will be out of sync. Turn the control clockwise slowly. The number of diagonal black bars will be gradually reduced and when only 2 or 3 bars sloping downward to the left are obtained, the picture will pull into sync upon slight additional clockwise rotation of the control. Pull-in should occur before the control has been turned 120 degrees from the extreme counter-clockwise position. The picture should remain in sync for approximately 90 degrees of additional clockwise rotation of the control. At the extreme clockwise position, the picture should remain in sync and should not show a black bar in the picture.


ALIGNMENT OF HORIZONTAL OSCILLATOR.—If in the above check the receiver failed to hold sync with the hold control at the extreme counter-clockwise position or failed to hold sync over 90 degrees of clockwise rotation of the control from the pull-in point, it will be necessary to make the following adjustments.

Horizontal Frequency Adjustment. — Turn the horizontal hold control to the extreme clockwise position. Tune in a television station and adjust the T114 horizontal frequency adjustment at the rear of the chassis until the picture is just out of snync and the horizontal blanking appears as a vertical or diagonal black bar in the raster. Then turn the T114 core until the bar moves out of the picture leaving it in sync.

Horizontal Locking Range Adjustment.—Set the horizontal hold control to the full counter-clockwise position. Momentarily remove the signal by switching off channel then back. The picture may remain in sync. If so turn the T114 rear core slightly and momentarily switch off channel. Repeat until the picture falls out of sync with the diagonal lines sloping down to the left. Slowly turn the horizontal hold control clockwise and note the least number of diagonal bars obtained just before the picture pulls into sync.

If more than 3 bars are present just before the picture pulls into sync, adjust the horizontal locking range trimmer C174A slightly clockwise. If less than 2 bars are present, adjust C174A slightly counter-clockwise. Turn the horizontal hold control counter-clockwise, momentarily remove the signal and recheck the number of bars present at the pull-in point. Repeat this procedure until 2 or 3 bars are present.

Repeat the adjustments under "Horizontal Frequency Adjustment" and "Horizontal Locking Range Adjustment" until the conditions specified under each are fulfilled. When the horizontal hold operates as outlined under "Check of Horizontal Oscillator Alignment" the oscillator is properly adjusted.



RCA-Victor CIRCUIT SCHEMATIC DIAGRAM, KCS83B (KCS83E with 21EP4A Kinescope)

21-T-356 U, 21-T-363, 21-T-363 U, 21-T-364, 21-T-364 U, 21-T-365, 21-T-365 U, 21-T-372, 21-T-372 U, 21-T-373, 21-T-373 U, 21-T-374, 21-T-374 U, 21-T-375, 21-T-375 U


The schematic is shown in the latest condition at the time of printing. All resistance values in ohms. K = 1000.


Direction of arrows at controls indicates clockwise rotation.

All capacitance values less than l in FM and above l in MMF unless otherwise noted.

All voltages measured with "VoltOhmyst"

and with no signal input. Voltages should hold within $\pm 20\%$ with 117 v. a-c supply.





RCA-Victor (Continued)

ALIGNMENT PROCEDURE

21-T-363 to 21-T-375 incl. 21-T-356U to 21-T-375U incl.

PICTURE I-F TRANSFORMER ADJUSTMENTS .--

Models 21-T-363 to 21-T-375 incl.

Connect the i-f signal generator across the link circuit on terminals ${\bf A}$ and ${\bf B}$ of T104.

Connect the ``VoltOhmyst'' to the junction of R123 and C142. Turn the AGC control fully clockwise.

Obtain two 7.5 volt batteries capable of withstanding appreciable current drain and connect the ends of a 1,000 ohm potentiometer across each. Connect the battery positive terminal of one to the chassis and the potentiometer arm to the junction of R123 and C142. The second battery will be used later.

Set the bias to produce approximately $-5.0 \mbox{ volt of bias at}$ the junction of R123 and C142.

Connect the ''VoltOhmyst'' to junction of R135 and L102 and to ground.

Set the VHF signal generator to each of the following frequencies and peak the specified adjustment for maximum indication on the "VoltOhmyst". During alignment, reduce the input signal if necessary in order to produce 3.0 volts of d-c at R123 and L102 with -5.0 volts of i-f bias at the junction of R123 and C142.

44.5 mc.			 	T108
45.5 mc.	,		 	T 107
43.0 mc				T 106

Set the VHF signal generator to the following frequency and adjust the picture if trap for minimum d-c output at R135, L102. Use sufficient signal input to produce 3.0 volts of d-c on the meter when the adjustment is made.

47.25 mc. L118 Models 21.T.356U to 21.T.375U incl.

Connect the ''VoltOhmyst'' to the junction of R123 and C142. Turn the AGC control fully clockwise

Obtain a 7.5 volt battery capable of withstanding appre-ciable current drain and connect the ends of a 1,000 ohm to chasts current oran and connect the ends of a 1,000 offm potentiometer across it. Connect the battery positive terminal to chassis and the potentiometer arm to the junction R123 and C142. Adjust the potentiometer for -5.0 volts indication on the "VoltOhmyst".

Connect the ''VoltOhmyst'' to the junction of R135 and L102 and to ground.

Connect the output of the signal generator to the front terminal of the crystal mixer in series with a 1500 mmf. ceramic capacitor.

Set the VHF generator to each of the following frequencies and with a thin fiber screwdriver tune the specified adjustment for maximum indication on the "VoltOhmyst". In each instance the generator should be checked against a crystal calibrator to insure that the generator is on frequency.

During alignment, reduce the input signal if necessary in order to produce 3.0 volts of d-c at R135 and L102 with -5.0volts of i f bias at the junction of R123 and C142.

44.5 mc.

Set the signal generator to the following frequency and adjust the picture i.f trap for minimum d-c output at junction of R135 and L102. Use sufficient signal input to produce 3.0 volts of d-c on the meter when adjustment is made.

47.25 mc.

RATIO DETECTOR ALIGNMENT. - Set the signal generator at 4.5 mc. and connect it to the first sound i-f grid, pin 1 of V101.

As an alternate source of signal, the RCA WR39B or WR39C calibrator may be employed. In such a case, connect the calibrator to the grid of the third pix i-f amplifier, pin 1 of V108.

Set the frequency of the calibrator to 45.75 mc. (pix carrier) and modulate with 4.5 mc. crystal. The 4.5 mc. signal will be picked off at L103 and amplified through the sound i-f amplifier.

Connect the "VoltOhmyst" to pin 2 of V103.

Tune the ratio detector primary, T102 top core for maximum d-c output on the "VoltOhmyst". Adjust the signal level from the signal generator for 6 volts on the "VoltOhmyst" when finally peaked. This is approximately the operating level of the ratio detector for average signals.

Connect the "VoltOhmyst" to the junction of R108 and C109.

Tune the ratio detector secondary T102 bottom core for zero d-c on the ''VoltOhmyst''.

Repeat adjustments of T102 top for maximum d-c at pin 2 of VIO3 and TIO2 bottom for zero d-c at the junction of RIO8 and C109. Make the final adjustments with the signal input level adjusted to produce 6 volts d-c on the "VoltOhmyst" pin 2 of V103.

SOUND I-F ALIGNMENT.-Connect the signal generator to the first sound i-f amplifier grid, pin 1 of V101.

As an alternate source of signal, the RCA WR39B or WR39C calibrator may be employed as above.

Connect the "VoltOhmyst" to pin 2 of V103.

Tune the TIOI top core for maximum d-c on the "Volt-Ohmyst''.

The output from the signal generator should be set to produce approximately 6.0 volts on the "VoltOhmyst" when the final touches on the above adjustment are made.


4.5 MC. TRAP ADJUSTMENT.-Connect the signal generator in series with a 100 ohm resistor to pin 2 of V109. Set the generator to 4.5 mc. and modulate it 30% with 400 cycles. Set the output to approximately 0.5 volt.

Short the third pix i f grid to ground, pin 1, V108, to prevent noise from masking the output indication.

Connect the crystal diode probe of an oscilloscope to the plate of the viedo amplifier, pin 9 of V110.

Adjust the core of L104 for minimum output on the oscillo-SCODE.

Remove the short from pin 1, V108 to ground.



T108



RCAVICTOR


Models <u>17S349</u>, <u>17S350</u>, <u>17S351</u>, <u>17S360</u>, <u>17T361</u>, use Chassis <u>KCS-78F</u> that has its exact circuit printed on the next two pages, over. Models <u>17S350U</u>, <u>17S351U</u>, <u>17S360U</u>, use Chassis <u>KCS-78H</u> which is practically identical to the KCS-78F, but employs VHF tuner unit KRK-29A and UHF tuner KRK-27, to permit reception of any UHF channels. Models <u>17T352U</u> and <u>17T361U</u> use Chassis <u>KCS-78J</u> which is also almost identical to KCS-78F, but uses a combination VHF and UHF tuner unit KRK-12B.

Models <u>17T301</u>, <u>17T302</u>, <u>17T310</u>, use Chassis <u>KCS-78</u> with tuner KRK-11B for VHF reception, and Models <u>17T301U</u>, <u>17T302U</u>, <u>17T310U</u>, use Chassis <u>KCS-78B</u> with tuner KRK-12 to provide both VHF and UHF reception. These chassis KCS-78 and KCS-78B use a circuit similar to KCS-78F shown on the next two pages, but differ in tuner type and in that some other (but technically similar) types of tubes are employed in some of the sections. The use of these different tubes will change some of the voltage values shown in the diagram.


Models <u>21T303</u>, <u>21T313</u>, <u>21T314</u>, <u>21T315</u>, <u>21T316</u>, <u>21T322</u>, <u>21T323</u>, <u>21T324</u>, use Chassis <u>KCS-82</u> employing tuner KRK-11B and 21AP4 picture tube, but otherwise practically identical to the circuit of KCS-78F shown on the next two pages. Models <u>21T303U</u>, <u>21T313U</u>, <u>21T314U</u>, <u>21T315U</u>, <u>21T316U</u>, <u>21T322U</u>, <u>21T323U</u>, <u>21T324U</u>, use Chassis <u>KCS-82B</u> which uses tuner KRK-12 to provide VHF and UHF reception, but otherwise is the same as KCS-82, and therefore is practically identical to KCS-78F.


The alignment information and service notes below and on the next five pages are applicable to all these chassis. Notice that parts of the alignment procedure differ for VHF and VHF-UHF models and are so marked.


ION TRAP MAGNET ADJUSTMENT.—Set the ion frap magnet approximately in the position shown in figure 2. Starting from this position immediately adjust the magnet by moving it forward or backward at the same time rotating it slightly around the neck of the kinescope for the brightest raster on the screen. Reduce the brightness control setting until the raster is slightly above average brilliance. Turn the focus control (shown in figure 2) until the line structure of the raster is clearly visible. Readjust the ion trap magnet for maximum raster brilliance.



CHECK OF HORIZONTAL OSCILLATOR ALIGNMENT.— Turn the horizontal hold control to the extreme counter-clockwise position. The picture should remain in horizontal sync. Momentarily remove the signal by switching off channel then back. Normally the picture will be out of sync. Turn the control clockwise slowly. The number of diagonal black bars will be gradually reduced and when only 2 or 3 bars sloping downward to the left are obtained, the picture will pull into sync upon slight additional clockwise rotation of the control. Pull-in should occur before the control has been turned 120 degrees from the extreme counter-clockwise position. The picture should remain in sync for approximately 90 degrees of additional clockwise rotation of the control. At the extreme clockwise position, the picture should remain in sync and should not show a black bar in the picture.







RCA-Victor Chassis KCS-78, KCS-78B, KCS-78F, KCS-78H, and KCS-78J

ALIGNMENT PROCEDURE

PICTURE I-F TRANSFORMER ADJUSTMENTS.— VHF Models

Connect the i-f signal generator across the link circuit on terminals A and B of T104.

Connect the ``VoltOhmyst'' to the junction of R147 and R148 and to ground.

Obtain a 7.5 volt battery capable of withstanding appreciable current drain and connect the ends of a 1,000 ohm potentiometer across it. Connect the battery positive terminal to chassis and the potentiometer arm to the junction of R147 and R148.

Set the bias to produce approximately -5.0 volt of bias at the junction of R147 and R148.

Connect the "VoltOhmyst" to the juncture of R138 and L105 and to ground.

Set the VHF signal generator to each of the following frequencies and peak the specified adjustment for maximum indication on the "VoltOhmyst". During alignment, reduce the input signal if necessary in order to produce 3.0 volts of d-c at R138, L105 with minus 5.0 volts of i-f bias at the junction of R147 and R148.

44.5 mc.			T108
45.5 mc.			
43.0 mc.	 		T106

Set the VHF signal generator to the following frequency and adjust the picture i-f trap for minimum d-c output at R138, L105. Use sufficient signal input to produce 3.0 volts of d-c on the meter when the adjustment is made.

VHF-UHF Models

Connect the "VoltOhmyst" to the junction of R147 and R148 and to ground.

Turn the AGC control fully clockwise.

Obtain a 7.5 volt battery capable of withstanding appreciable current drain and connect the ends of a 1,000 ohm potentiometer across it. Connect the battery positive terminal to chassis and the potentiometer arm to the junction R147 and R148. Adjust the potentiometer for -5.0 volts indication on the "VoltOhmyst".

Connect the "VoltOhmyst" to the junction of R138 and L105 and to ground.

Connect the output of the signal generator to the front terminal of the crystal mixer in series with a 1500 mmf ceramic capacitor.

Set the VHF generator to each of the following frequencies and with a thin fiber screwdriver tune the specified adjustment for maximum indication on the "VoltOhmyst". In each instance the generator should be checked against a crystal calibrator to insure that the generator is on frequency.

During alignment, reduce the input signal if necessary in order to produce 3.0 volts of d-c at R138, L105 with —5.0 volts of i-f bias at the junction of R147 and R148.

44.5	mc.		T108
45.5			T107
43.0	mc.		 T106

Set the signal generator to the following frequency and adjust the picture i-f trap for minimum d-c output at R138, L105. Use sufficient signal input to produce 3.0 volts of d-c on the meter when the adjustment is made.

47.25 mc.

... T104 top core

SWEEP ALIGNMENT OF PIX 1-F.— VHF Models

To align T2 and T104, connect the sweep generator to the mixer grid test point TP2, in series with a 1500 mmf ceramic capacitor. Use the shortest leads possible, with not more than one inch of unshielded lead at the end of the sweep cable. Connect the sweep ground lead to the r-f unit outer shield.

Set the channel selector switch to channel 4.

Clip 330 ohm resistors across terminals A and B of T107 and T108.

Preset Cl19 to minimum capacity.

Adjust the bias box potentiometer to obtain —5.0 volts of bias as measured by a "VoltOhmyst" at the junction of R147 and R148. Set the AGC control fully clockwise.

Connect a 180 ohm composition resistor from pin 5 of V106 to terminal A of T106. Connect the oscilloscope diode probe to pin 5 of V106 and to ground.

Couple the signal generator loosely to the diode probe in order to obtain markers.

Adjust T2 (top) and T104 (bottom) for maximum gain and with 45.75 mc. at 70% of maximum response.

Set the sweep output to give 0.3 volt peak-to-peak on the oscilloscope when making the final touch on the above adjustment.

Adjust C119 until 42.5 mc. is at 70% response with respect to the low frequency shoulder of the curve as shown in Figure 22.

Disconnect the diode probe, the 180 ohm and two 330 ohm resistors.

Connect the oscilloscope to the junction of R138 and L105. Leave the sweep generator connected to the mixer grid test point TP2 with the shortest leads possible.

Adjust the output of the sweep generator to obtain 3.0 volts peak-to-peak on the oscilloscope.

Couple the signal generator loosely to the grid of the first pix i-f amplifier. Adjust the output of the signal generator to produce small markers on the response curve.

Retouch T106, T107 and T108 to obtain the response shown in figure 23.

VHF-UHF Models

To align the crystal mixer plate circuit, T2 and T104 connect the VHF sweep generator to the front terminal of the 1N82 crystal holder in series with a 1500 mmf ceramic capacitor. Use the shortest leads possible, grounding the sweep generator to the tuner case.

Clip 330 ohm resistors across terminals A and B of T107 and T108.

Set the channel selector to channel 5.

Connect a 180 ohm composition resistor from pin 5 of V106 to terminal A of T106. Connect the oscilloscope diode probe to pin 5 of V106 and to ground.

Couple the signal generator loosely to the diode probe in order to obtain markers.

The shunt trimmer C119 across terminals A and B of T104 is variable and is provided as a bandwidth adjustment. Preset the shunt trimmer to minimum capacity. Adjust T2 (top) and T104 (bottom) for maximum gain at 43.5 mc, and with 45.75 mc. at 70% of maximum response.

Adjust T1 for maximum gain. Readjust T2 and T104 if necessary to obtain proper wave shape, see Fig. 13.

Disconnect the diode probe, the 180 chm and the two 330 ohm resistors.

Connect the oscilloscope to the junction of R138 and L105.

Adjust the bias potentiometer to obtain —5.0 volts of bias as measured by a "VoltOhmyst" at the junction of R147 and R148.

Leave the sweep generator connected to the front terminal of the 1N82 crystal holder with the shortest leads possible and with not more than one inch of unshielded lead at the end of the sweep cable. If these precautions are not observed, the receiver may be unstable and the response curves obtained may be unreliable.

Adjust the output of the sweep generator to obtain 3.0 to 5.0 volts peak-to-peak on the oscilloscope.

Couple the signal generator loosely to the grid of the first pix i-f amplifier. Adjust the output of the signal generator to produce small markers on the response curve.

Retouch T106, T107 and T108 to obtain the response shown in Figure 14.

Remove the oscilloscope, sweep and signal generator connections.



RCA-Victor Chassis KCS-78, -78B, -78F, -78H, -78J, continued

ALIGNMENT PROCEDURE

RATIO DETECTOR ALIGNMENT.—Set the signal generator at 4.5 mc. and connect it to the first sound i-f grid, pin 1 of V101.

As an alternate source of signal, the RCA WR39B or WR39C calibrator may be employed. In such a case, connect the calibrator to the grid of the third pix i-f amplifier, pin 1 of V108.

Set the frequency of the calibrator to 45.75 mc. (pix carrier) and modulate with 4.5 mc. crystal. The 4.5 mc. signal will be picked off at L104 and amplified through the sound i-f amplifier.

Connect the "VoltOhmyst" to pin 2 of V103.

Tune the ratio detector primary, T102 top core for maximum d-c output on the "VoltOhmyst." Adjust the signal level from the signal generator for 6 volts on the "VoltOhmyst" when finally peaked. This is approximately the operating level of the ratio detector for average signals.

Connect the "VoltOhmyst" to the junction of R106 and C108. Tune the ratio detector secondary T102 bottom core for zero

d-c on the "VoltOhmyst."

Repeat adjustments of T102 top for maximum d-c at pin 2 of V103 and T102 bottom for zero d-c at the junction of R106 and C108. Make the final adjustments with the signal input level adjusted to produce 6 volts d-c on the "VoltOhmyst" at pin 2 of V103.

SOUND I-F ALIGNMENT.—Connect the signal generator to the first sound i-f amplifier grid, pin 1 of V101.

As an alternate source of signal, the RCA WR39B or WR39C calibrator may be employed as above.

Connect the "VoltOhmyst" to pin 2 of V103.

Tune the T101 top core for maximum d-c on the "Volt-Ohmyst."

The output from the signal generator should be set to produce approximately 6.0 volts on the "VoltOhmyst" when the final touches on the above adjustment are made.

4.5 MC. TRAP ADJUSTMENT.—Connect the signal generator in series with a 1,000 ohm resistor to pin 2 of V109. Set the generator to 4.5 mc. and modulate it 30% with 400 cycles. Set the output to approximately 0.5 volts.

Short the third pix i-f grid to ground, pin 1, V108, to prevent noise from masking the output indication.

Connect the crystal diode probe of an oscilloscope to the plate of the video amplifier, pin 6 of V110.

Adjust the core of L105 for minimum output on the oscilloscope.

Remove the short from pin 1, V108 to ground.

As an alternate method, this step may be omitted at this point in the alignment procedure and the adjustment made "on the air" after the alignment is completed.

If this is done, tune in a station and observe the picture on the kinescope. If no 4.5 mc. beat is present in the picture, when the fine tuning control is set for proper oscillator-frequency, then L105 requires no adjustment. If a 4.5 mc. beat is present, turn the fine tuning control slightly clockwise so as to exaggerate the beat and then adjust L105 for minimum beat.


AGC CONTROL ADJUSTMENT.—Disconnect all test equipment except the oscilloscope which should be connected to pin 6 of V110.

Connect an antenna to the receiver antenna terminals.

Turn the AGC control fully counter-clockwise.

Tune in a strong signal and adjust the oscilloscope to see the video waveform.

Turn the AGC control clockwise until the tips of sync begin to be compressed, then counter-clockwise until no compression is obtained.



RCA-Victor Chassis KCS-78, -78B, -78F, -78H, -78J, continued

ALIGNMENT PROCEDURE

HORIZONTAL OSCILLATOR ADJUSTMENT. - Normally the adjustment of the horizontal oscillator is not considered to be a part of the alignment procedure, but since the oscillator waveform adjustment may require the use of an oscilloscope, it cannot be done conveniently in the field. The waveform adjustment is made at the factory and normally should not require readjustment in the field. However, the waveform adjustment should be checked whenever the receiver is aligned or whenever the horizontal oscillator operation is improper.

Horizontal Frequency Adjustment.-Tune in a station and sync the picture. If the picture cannot be synchronized with the horizontal hold control R200, then adjust the T114 frequency core on the rear apron until the picture will synchronize. If the picture still will not sync, turn the T114 waveform adjustment core (under the chassis) out of the coil several turns from its original position and readjust the T114 frequency core until the picture is synchronized.

Examine the width and linearity of the picture. If picture width or linearity is incorrect, adjust the horizontal drive control C174B, the width control L109 and the linearity control L111 until the picture is correct.

Horizontal Oscillator Waveform Adjustment.-The horizontal oscillator waveform may be adjusted by either of two methods. The method outlined in paragraph A below may be employed in the field when an oscilloscope is not available. The service shop method outlined in paragraph B below requires the use of an oscilloscope.

A.-Turn the horizontal hold control completely clockwise. Place adjustment tools on both cores of T114 and be prepared to make simultaneous adjustments while watching the picture on the screen. First, turn the T114 frequency core (on the rear apron) until the picture falls out of sync and three or four diagonal black bars sloping down to the right appear on the screen. Then, turn the waveform adjustment core (under the chassis) into the coil while at the same time adjusting the frequency core so as to maintain three or four diagonal black bars on the screen. Continue this procedure until the oscillator begins to motorboat, then turn the waveform adjustment core out until the motorboating just stops. As a check, turn the T114 frequency core until the picture is synchronized then reverse the direction of rotation of the core until the picture falls out of sync with the diagonal bars sloping down to the right. Continue to turn the frequency core in the same direction. No more than three or four bars should appear on the screen. Instead, the horizontal oscillator should begin to

motorboat. Retouch the adjustment of the T114 waveform adjustment core if necessary until this condition is obtained.

B.—Connect the low capacity probe of an oscilloscope to terminal C of T114. Turn the horizontal hold control onequarter turn from the clockwise position so that the picture is in sync. The pattern on the oscilloscope should be as shown in Figure 24. Adjust the waveform adjustment core of T114 until the two peaks are at the same height. During this adjustment, the picture must be kept in sync by readjusting the hold control if necessary.


This adjustment is very important for correct operation, of the circuit. If the broad peak of the wave on the oscilloscope is lower than the sharp peak, the noise immunity becomes poorer, the stabilizing effect of the tuned circuit is reduced and drift of the oscillator becomes more serious. On the other hand, if the broad peak is higher than the sharp peak, the oscillator is overstabilized, the pull-in range becomes inadequate and the broad peak can cause double triggering of the oscillator when the hold control approaches the clockwise position.

Remove the oscilloscope upon completion of this adjustment.

Horizontal Locking Range Adjustment.—Set the horizontal hold control to the full counterclockwise position. Momentarily remove the signal by switching off channel then back. The picture may remain in sync. If so turn the T114 frequency core slightly and momentarily switch off channel. Repeat until the picture falls out of sync with the diagonal lines sloping down to the left. Slowly turn the horizontal hold control clockwise and note the least number of diagonal bars obtained just before the picture pulls into sync.

If more than 3 bars are present just before the picture pulls into sync, adjust the horizontal locking range trimmer C174A slightly clockwise. If less than 2 bars are present, adjust C174A, slightly counter-clockwise. Turn the horizontal hold control counter-clockwise, momentarily remove the signal and recheck the number of bars present at the pull-in point. Repeat this procedure until 2 or 3 bars are present.

Turn the horizontal hold control to the maximum clockwise position. Adjust the T114 frequency core so that the diagonal bar sloping down to the right appears on the screen and then reverse the direction of adjustment so that bar just moves to the left side of the screen leaving the picture in synchronization.



20

Top Chassis Adjustments



RCAVICTOR

Models <u>21D358U</u>, <u>21D368U</u>, <u>21D376U</u>, <u>21D377U</u>, <u>21D378U</u>, <u>21D379U</u>, <u>21D380U</u>, use Chassis <u>KCS-81J</u> that has its exact circuit printed on the next two pages, over. Models <u>21D358</u>, <u>21D368</u>, <u>21D376</u>, <u>21D377</u>, <u>21D378</u>, <u>21D379</u>, <u>21D380</u>, use Chassis <u>KCS-81F</u> which is practically identical to the KCS-81J, but is intended for VHF reception only and uses tuner unit KRK-29.

Models <u>21D305</u>, <u>21D317</u>, <u>21D326</u>, <u>21D327</u>, <u>21D328</u>, <u>21D329</u>, <u>21D330</u>, use Chassis <u>KCS-81</u> with tuner unit KRK-11B for VHF reception only, while Models <u>21D305U</u>, <u>21D317U</u>, <u>21D326U</u>, <u>21D327U</u>, <u>21D328U</u>, <u>21D329U</u>, <u>21D330U</u>, employ Chassis <u>KCS-81B</u> which has tuner unit KRK-12 for both VHF and UHF reception. Outside of different tuners, these chassis are practically the same as KCS-81J and the circuit of this chassis on the next two pages should be used for these additional models.

Model <u>21D346</u> uses Chassis <u>KCS-81D</u> with tuner unit KRK-22A for VHF reception only, and Model <u>21D346U</u> uses Chassis <u>KCS-81E</u> with tuner unit KRK-12 for reception of both VHF and UHF. Both of these chassis are used in combination sets with separate radio chassis, audio amplifier, and record changer. Outside of tuner differences and provisions for switching and connecting the radio chassis which has the audio output tube and speaker, these chassis are very similar to other chassis covered by service material on this and the next five pages.

WIDTH. DRIVE AND HORIZONTAL LINEARITY ADJUST-MENTS. — Adjustment of the horizontal drive control affects the high voltage applied to the kinescope. In order to obtain the highest possible voltage hence the brightest and best focused picture, adjust horizontal drive trimmer C186B for maximum drive (minimum capacity) consistent with a linear raster. Compression of the raster due to excessive drive can be seen as a white vertical bar or bars in the right half of the picture. Besides compression caused by excessive drive, another item to watch for is the change in linearity at the extreme left with changes of brightness control setting. By proper adjustment of the linearity coil, the changes in linearity with changes in brightness can be made negligible. In general, to achieve this condition, the linearity coil should be set slightly on the high inductance side (core slightly clockwise) of the optimum position.

Preset the following adjustments as directed:

A.—Place the width plug Pl03 in the minimum width position (top).

 $B.{\longrightarrow}Set$ the width control coil L109 in approximately midposition.

C.—Set the linearity control coil L111 near minimum inductance (counter-clockwise).

D.—Set the drive capacitor C186B in the maximum drive position (counter-clockwise).

If the raster is cramped or shows compression bars on the right half of the picture turn C186B clockwise until this condition is just eliminated.

Adjust the linearity control coil L111 clockwise until best linearity and maximum deflection or best compromise are obtained, then turn one quarter turn clockwise from this position.


Retouch the drive trimmer C186B if necessary to obtain best linearity and maximum width.

Check the horizontal linearity at various settings of the brightness control R114A. There should be no compression of the right half and no appreciable change of linearity especially at the extreme left of the picture. If objectionable change does occur, turn linearity coil L111 slightly clockwise and repeat the test.

Adjust the width control L109 to fill the mask.

If the line voltage is low and it becomes impossible to fill the mask, remove the width plug P103 to the bottom position. HEIGHT AND VERTICAL LINEARITY ADJUSTMENTS. — Adjust the height control (R190 behind front control panel) until the picture fills the mask vertically. Adjust vertical linearity (R197 behind front control panel), until the test pattern is symmetrical from top to bottom. Adjustment of either control will require a readjustment of the other.

ION TRAP MAGNET ADJUSTMENT. — Set the ion trap magnet approximately in the position shown in Figure 2. Starting from this position immediately adjust the magnet by moving it forward or backward at the same time rotating it slightly around the neck of the kinescope for the brightest raster on the screen. Reduce the brightness control setting until the raster is slightly above average brilliance. Turn the focus control (shown in Figure 2) until the line structure of the raster is clearly visible. Readjust the ion trap magnet for maximum raster brilliance. The final touches of this adjustment should be made with the brightness control at the maximum clockwise position with which good line focus can be maintained.



KCS81J CIRCUIT SCHEMATIC DIAGRAM



The schematic is shown in the latest condition at the time of printing. All resistance values in ohms. K = 1000.

All capacitance values less than 1 in MF and above 1 in MMF unless otherwise noted.


Direction of arrows at controls indicates clockwise rotation.

AGC THRESHOLD CONTROL.

To check the adjustment of the AGC Threshold Control, tune in a strong signal and sync the picture. Momentarily remove the signal by switching off channel and then back. If the picture reappears immediately, the receiver is not over-loading due to improper setting of R180. If the picture requires an appreciable portion of a second to reappear, or bends excessively, R180 should be readjusted.

Turn R180 fully counter-clockwise. The raster may be bent slightly. This should be disregarded. Turn R180 clockwise until there is a very, very slight bend or change of bend in the picture. Then turn R180 counter-clockwise just sufficiently to remove this bend or change of bend.

If the signal is weak, the above method may not work as it may be impossible to get the picture to bend. In this case, turn R180 clockwise until the snow in the picture becomes more pronounced, then counterclockwise until the best signal to noise ratio is obtained.







Figure 4—KRK29 R-F Oscillator Adjustments



All voltages measured with "Volt-Ohmyst" and with no signal input. Voltages should hold within $\pm 20\%$ with 117 v. a-c supply.

CHECK OF R.F OSCILLATOR ADJUSTMENTS Models 21-D-358 to 21-D-380 incl. with KRK29 Tuner

Tune in all available stations to see if the receiver rf oscillator is adjusted to the proper frequency on all channels. If adjustments are required, these should be made by the method outlined in the alignment procedure on page 11. The adjustments for channels 2 through 12 are available from the front of the cabinet by removing the station selector escutcheon as shown in Figure 4. Adjustment for channel 13 is on top of the chassis.

Models 21-D-358U to 21-D-380U incl. with KRK12B Tuner

Tune in all available UHF and VHF stations to see if the receiver r-f oscillator is adjusted to the proper frequency on all channels. Set the fine tuning control to the center of its range. Adjust the oscillator core for each channel to obtain maximum audio output without distortion. The location of the adjustment is the same for all channels (see Figure 5).





Figure 5—KRK12B Oscillator Adjustment



Circuit Schematic Diagram, KCS811

Continued on the

next three pages.

123

RCA-Victor Chassis KCS-81, -81B, -81D, -81E, -81F, -81J, continued

ALIGNMENT PROCEDURE

PICTURE I.F TRAP ADJUSTMENT. — Connect the i.f signal generator across the link circuit on terminals A and B of T104.

Connect the "VoltOhmyst" to the junction of R133 and C133B.

Obtain two 7.5 volt batteries capable of withstanding appreciable current drain and connect the ends of a 1,000 ohm potentiometer across each. Connect the positive terminal of one battery to chassis and the potentiometer arm to the junction of R133 and C133B.

Set the bias to produce approximately -1.0 volt of bias at the junction of R133 and C133B.

Connect the "VoltOhmyst" to pin 9 of V110, the 6CL6 video amplifier.

Set the signal generator to each of the following frequencies and adjust the corresponding circuit for minimum d-c output at pin 9 of V110. Use sufficient signal input to produce 1.0 volt of d-c on the meter when the final adjustment is made.

39.25 mc		top core
41.25 mc	T105	bottom core
47.25 mc		hottom core

Set the signal generator to each of the following frequencies and peak the specified adjustment for maximum indication on the "VoltOhmyst." During alignment, reduce the input signal if necessary in order to produce 1.0 volt of d-c at pin 9 of V110 with -1.0 volt of i-f bias at the junction of R133 and C133B.

43.7 mc	T 109
45.5 mc	T108
41.8 mc	T107

To align T105 and T106, connect the sweep generator to the first picture i-f grid, pin 1 of V106 through a 1,000 mmf. ceramic capacitor. Shunt R137, R141 and terminals "A" and "F" of T109 with 330 ohm composition resistors. Set the i-f bias to -1.0 volt at the junction of R133 and C133B.

Connect the oscilloscope to pin 9 of V110.

Adjust T105 and T106 top cores for maximum gain and curve shape as shown in Figure 22. For final adjustment set the output of the sweep generator to produce 0.5 volt peak-to-peak at the oscilloscope terminals.

To align T2 and T104, connect the sweep generator to the mixer grid test point TP2. Use the shortest leads possible, with not more than one inch of unshielded lead at the end of the sweep cable.

Adjust C121 until 41.25 mc. is at 85% response with respect to the low frequency shoulder at approximately 41.9 mc. as shown in Figure 23.

Disconnect the diode probe, the 180 ohm and three 330 ohm resistors.

VHF-UHF Models

Set the signal generator to each of the following frequencies and peak the specified adjustment for maximum indication on the "VoltOhmyst." During alignment, reduce the input signal it necessary in order to produce 1.0 volt of d-c at pin 9 of V110 with -1.0 volt of i-f bias at the junction of R133 and C133B.

43.7 mc	 	
45.5 mc	 	 T108
41.8 mc	 • • • • • • •	 T107

To align T105 and T106, connect the sweep generator to the first picture if grid, pin 1 of V106 through a 1,000 mmf. ceramic capacitor. Shunt R137, R141 and terminals "A" and "F" of T109 with 330 ohm composition resistors. Set the if bias to -1.0 volt at the junction of R133 and C133B.

Connect the oscilloscope to pin 9 of V110, the $6CL6\ video\ amplifier.$



Adjust T105 and T106 top cores for maximum gain and curve shape as shown in Figure 22. For final adjustment set the output of the VHF sweep generator to produce 0.5 volt peak-to-peak at the oscilloscope terminals.

To align the crystal mixer and T2 and T104, connect the VHF sweep generator to the front terminal of the 1N82 crystal holder in series with a 1,500 mmf. ceramic capacitor. Use the shortest leads possible, grounding the sweep generator to the tuner case.


Set the channel selector to channel 5.

Connect a 180 ohm composition resistor between terminal "B" of T105 and the junction of R131 and C133A.

Connect the oscilloscope diode probe to terminal "B" of T105 and ground. Couple the signal generator loosely to the diode probe in order to obtain markers.

The shunt trimmer C121 across terminals "A" and "B" of T104 is variable and is provided as a bandwidth adjustment. Preset the shunt trimmer to minimum capacity. Adjust T2 (top) and T104 (bottom) for maximum gain at 43.5 mc. and with 45.75 mc. at 70% of maximum response.

Adjust the shunt trimmer C121 until 41.25 mc. is at 85% response with respect to the low frequency shoulder at approximately 41.9 mc. as shown in Figure 13. Adjust T1 for



RCA-Victor Chassis KCS-81, -81B, -81D, -81E, -81F, -81J, continued

ALIGNMENT PROCEDURE

maximum gain. Readjust T2 and T104 if necessary to obtain proper wave shape, see Figure 13.

Disconnect the diode probe, the 180 ohm and the three 330 ohm resistors.

SWEEP ALIGNMENT OF PICTURE I-F .---

Connect the oscilloscope to pin 9 of V110.


Adjust the bias potentiometer to obtain -6.0 volts of bias as measured by a "VoltOhmyst" at the junction of R133 and C133B.

Leave the sweep generator connected to the mixer grid test point TP2 on KRK29 Tuner or to the front terminal of the 1N82 crystal holder on KRK12B Tuner. Use the shortest leads possible with not more than one inch of unshielded lead at the end of the sweep cable. If these precautions are not observed, the receiver may be unstable and the response curves obtained may be unreliable. Adjust the output of the sweep generator to obtain 3.0 volts peak-to-peak on the oscilloscope.

Couple the signal generator loosely to the grid of the first pix i-f amplifier. Adjust the output of the signal generator to produce small markers on the response curve.

Retouch T108 and T109 to obtain the response shown in Figure 14. Do not adjust T107 unless absolutely necessary. If T107 is adjusted too low in frequency it will raise the level of the 41.25 mc. sound if carrier and may create interference in the picture. It will also cause poor adjacent channel picture rejection. If T107 is tuned too high in frequency, the level of the 41.25 mc. sound if carrier will be too low and may produce noisy sound in weak signal areas.

Remove the oscilloscope, sweep and signal generator connections.



RCA-Victor Chassis KCS-81, -81B, -81D, -81E, -81F, -81J, continued

ALIGNMENT PROCEDURE

RATIO DETECTOR ALIGNMENT. — In order to obtain good ratio detector alignment an AM modulated signal generator that is exceptionally free from FM modulation must be employed. Set the signal generator at 4.5 mc. and connect it to the second sound i-f grid, pin 1 of V102. Set the generator for 30% 400 cycle modulation.

As an alternate source of signal, the RCA WR39B or WR39C calibrator may be employed. If used, connect it to the grid of the 4th pix i-f amplitier, pin 1, V109. Set the frequency of the calibrator to 45.75 (pix carrier) and modulate with 4.5 mc. crystal. Also turn on the internal AM audio modulation. The 4.5 mc. signal will be picked off at T110A and amplified through the sound i-f amplifier.

Connect the "VoltOhmyst" to the junction of R111 and C111.

Connect the oscilloscope across the speaker voice coil and turn the volume control for maximum output.

Tune the ratio detector primary, T102 top core for maximum DC output on the "VoltOhmyst." Adjust the signal level from the signal generator for -10 volts on the "VoltOhmyst" when finally peaked. This is approximately the operating level of the ratio detector for average signals.

Connect the "VoltOhmyst" to the junction of R110 and C110.

Adjust the T102 bottom core for zero d-c on the meter. Then, turn the core to the nearest minimum AM output on the oscilloscope.

Repeat adjustments of T102 top for maximum DC and T102 bottom for minimum output on the oscilloscope making final adjustment with the 4.5 mc, input level adjusted to produce 10 volts d-c on the "VoltOhmyst" at the junction of R111 and C111.

Connect the "VoltOhmyst" to the junction of R110 and C110 and note the amount of d-c present. If this voltage exceeds ± 1.5 volts, adjust R108 by turning it in until zero d-c is obtained. Readjust the T102 bottom core for minimum output on the oscilloscope. Repeat adjustments of R108 and T102 bottom core until the voltage at R110 and C110 is less than ± 1.5 volts when T102 bottom core is set for minimum output on the oscilloscope.

Connect the "VoltOhmyst" to the junction of R111 and C111 and repeak T102 top core for maximum d-c on the meter and again reset the generator so as to have -10 volts on the meter.

Repeat the adjustments in the above two paragraphs until the voltage at R110 and C110 is less than \pm 1.5 volts when the T102 top core is set for maximum d-c at the junction of R111 and C111 and the T102 bottom core is set for minimum indication on the oscilloscope.

SOUND 1-F ALIGNMENT. — Connect the sweep generator to the first sound i-f amplifier grid, pin 1 of V101. Adjust the generator for a sweep width of 1 mc. at a center frequency of 4.5 mc.

Insert a 4.5 mc. marker signal from the signal generator into the first sound i-f grid. With the WR39B or WR39C calibrators the 4.5 mc. crystal signal may be obtained at the R-F out terminal by turning the variable osc. switch off, the calibrate switch to 4.5 mc. and the volume control with mod. off.

Connect the oscilloscope in series with a 10,000 ohm resistor to terminal $\bf A$ of T101.

Adjust T101 top and bottom cores for maximum gain and symmetry about the 4.5 mc. marker on the if response. The pattern obtained should be similar to that shown in Figure 20.

The output level from the sweep should be set to produce approximately 2.0 volt peak-to-peak at terminal A of T101 when the final touches on the above adjustment are made. It is necessary that the sweep output voltage should not exceed the specified values otherwise the response curve will be broadened, permitting slight misadjustment to pass unnoticed and possibly causing distortion on weak signals.



Connect the oscilloscope to the junction of R110 and C110 and check the linearity of the response. The pattern obtained should be similar to that shown in Figure 21.

SOUND TAKE-OFF ALIGNMENT. — Connect the 4.5 mc. generator in series with a 1,000 ohm resistor to terminal "C" of T110. The input signal should be approximately 0.5 volt.

Short the fourth pix i-f grid to ground, pin 1, V109, to prevent noise from masking the output indication.

As an alternate source of signal the RCA WR39B or WR39C calibrator may be used. In such a case, disregard the above two paragraphs. Connect calibrator across link circuit, T104 A. B, and modulate 45.75 with 4.5 mc. crystal.

Connect the crystal diode probe of a "VoltOhmyst" to the plate of the video amplifier, pin 6 of V110.

Adjust the core of T110 for minimum output on the meter.

Remove the short from pin 1 V109 to ground, if used.

HORIZONTAL OSCILLATOR ADJUSTMENT. — Normally the adjustment of the horizontal oscillator is not considered to be a part of the alignment procedure, but since the oscillator waveform adjustment may require the use of an oscilloscope, it can not be done conveniently in the field. The waveform adjustment is made at the factory and normally should not require readjustment in the field. However, the waveform adjustment should be checked whenever the receiver is aligned or whenever the horizontal oscillator operation is improper.

Horizontal Frequency Adjustment. — Tune in a station and sync the picture. If the picture cannot be synchronized with the horizontal hold control R210, then adjust the T114 frequency core on the rear apron until the picture will synchronize. If the picture still will not sync, turn the T114 waveform adjustment core (under the chassis) out of the coil several turns from its original position and readjust the T114 frequency core until the picture is synchronized.

Examine the width and linearity of the picture. If picture width or linearity is incorrect, adjust the horizontal drive control C186B, the width control L109 and the linearity control L111 until the picture is correct.

Horizontal Locking Range Adjustment. — Set the horizontal hold control to the full counter-clockwise position. Momentarily remove the signal by switching off channel then back. The picture may remain in sync. If so turn the T114 frequency core slightly and momentarily switch off channel. Repeat until the picture falls out of sync with the diagonal lines sloping down to the left. Slowly turn the horizontal hold control clockwise and note the least number of diagonal bars obtained just before the picture pulls into sync.

If more than 3 bars are present just before the picture pulls into sync, adjust the horizontal locking range trimmer C186A slightly clockwise. It less than 2 bars are present, adjust C186A slightly counter-clockwise. Turn the horizontal hold control counter-clockwise, momentarily remove the signal and recheck the number of bars present at the pull-in point. Repeat this procedure until 2 or 3 bars are present.

Turn the horizontal hold control to the maximum clockwise position. Adjust the T114 frequency core so that the diagonal bar sloping down to the right appears on the screen and then reverse the direction of adjustment so that bar just moves off the screen leaving the picture in synchronization.

SENSITIVITY CHECK. — A comparative sensitivity check can be made by operating the receiver on a weak signal from a television station and comparing the picture and sound obtained to that obtained on other receivers under the same conditions.




RAYTHEON MANUFACTURING COMPANY TELEVISION AND RADIO DIVISION

21T8 CHASSIS

MODELS UM-2133A, UM-2134A, UM-2135A, UM-2136A, UC-2139A, UC-2141A, UC-2142A, UC-2144A and UC-2145A

24T2 CHASSIS

MODELS UC-2403A, UC-2404A, UC-2405A, and UC-2406A



★ MARKER FREQUENCIES

VIDEO TRAP COIL (L403) ADJUSTMENT

- (a) Tune in station.
- (b) Adjust tuner until sound bars just appear.
- (c) Turn L-403 Slug all the way out (counter-clockwise).
- (d) Turn the slug in (clockwise) until the horizontal
- scanning lines are smooth and continuous.

ALIGNMENT PLUG

For ease of alignment and to reduce the possibility of regeneration, it is suggested that a simple generator alignment plug be made and used during the alignment.

Raytheon Manufacturing Company, Chassis 21T8 and 24T2, continued

VIDEO IF ALIGNMENT

NOTE: (a) Preheat the unit for at least five minutes.

(b) Set VHF tuner to approximately Channel 7.
 (c) Use 10K ohm resistor (isolation) in series with VTVM and scope for the following steps.


Step No.	Signal Generator Freq. (mc.)	Sweep Generator Freq (mc.)	Signal Input Point	Output Point	Remarks	Adjust	Response
1	43.7			VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	T-301	Maximum Reading
2	41.4		IF Alignment Input "A"	VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	L-323A (Top)*	Minimum Reading
3	45.15		IF Alignment Input "A"	VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	L-323B (Bottom)*	Maximum Reading
4	42.1		IF Alignment Input ''A''	VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	L-319	Maximum Reading
5	41.25		IF Alignment Input "A"	VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	L-313 (Bottom)	Minimum Reading
6	47.25		IF Alignment Input "A"	VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	L-314 (Bottom)	Minimum Reading
7	41.4		IF Alignment Input "A"	VTVM at IF Detector Output	Adjust generator for output of approx. 2 volts DC on VTVM	Т-300А (Тор)*	Minimum Reading
8		VTVM from one volt per		put and subs	titute an oscilloscope in its	place. Calibrate	scope for sensi-
9	42.0 46.0	40	IF Alignment Input "B"	Scope at IF Detector Output	Adjust wave form for approx. 20 divisions on scope with sweep gen.	L-311 (Bottom) L-312 (Bottom) Adjust for maximum amplitude with proper bandwidth	42 OMC 46 OMC
10	42.0 45.6	40	IF Alignment Input "A"	Scope at IF Detector Output	Adjust wave form for approx. 20 divisions on scope with sweep gen.	T-200 T-300B (Bottom)* C-305 Adjust for maximum amplitude with proper bandwidth	42 OMC 45 6MC


* NOTE: Two Peaks can be obtained. Use Peak with core furthest out of coil form.


SOUND IF ALIGNMENT

NOTE: Short antenna to ground.

Step No.	Signal Generator Freq. (mc.)	Sweep Generator Freq (mc.)	Signal Input Point	Output Point	Remarks	Adjust	Response
1	4.5		IF Detector Output	VTVM across C-416		T400 Primary (Bottom of can)	Maximum Reading on V.T.V.M.
2		4.5	IF Detector Output	Scope across C-416	Sweep approx. ± 100 KC. Adjust for maximum Linearity	T400 Secondary (Top of can)	
3		4.5	IF Detector Output	Scope across C-416	Sweep approx. ± 100 KC. Adjust for symmetry of peaks	T400 Primary (Bottom of can)	









Raytheon Manufacturing Co. Circuit Diagram Chassis 21T8 CAPACITORS CAPACITOR VALUES ARE REPRESENTED IN MICRO-LARAD. D. ICHA RESISTOR WATTAGE IS REPRESENTED IN 1/2 WATT UN-THERWISE IN CATED. NO DENOTES X 1,000 B M DENOTES X1,000,000. ALL SWITCHES ARE SHOWN IN THE POSITION FOR VHF IZ AUT PILOT LIGHT SAUS V-16 68E6 0413 V-17 V-14 2505 V-9 2505 6ALC V-18 12 AU7 6C86 V-19 V-20 0C56 V-3 6U8 V-21 183 6827 V-7 6CB6 UHF H. YOKE H S 6C86 6AF4 V. LIN TUNING V. SIZE VOLUME STABIL PICTURE V HOLD H. HOLD BRIGHT

131






Raytheon Manufacturing Co. Circuit Diagram Chassis 24T2 CAPACITORS CAPACITOR VALUES ARE REPRESENTED IN MICRO-MICROFARAD (MMF) UNLESS OTHERWISE INDICATED "MF" DENOTES MICRO-FARAD RESISTORS WATTAGE IS REPRESENTED IN 1/2 WATT UN-IERWISE INDICATED & DENOTES X 1,000,000 ALL SWITCHES ARE SHOWN IN THE POSITION FOR VHF OPERATION <u>VOLTAGE READINGS</u> THE VOLTAGE READINGS INDICATED AT THE VARIOUS TUBE SOCKET PINS WERE UNEASURED WITH A 20000 CHIM PER VOLT VOLTMETER NORMAL OPERATION, NO SCIANAL INPUT AND LINE VOLTAGE AT 193 AC WHERE CONTROL, SETTINGS AFFECT VOLTAGE HEADINGS THE MINIMUM AND MAXIMUM ENDERSTOND AFTER TOLING ALLER TOLERS OF THE 183 HIGH VOLTAGE ENDERSTOND HIGH VOLTAGE ON PLATE CAPS OF THE 183 HIGH VOLTAGE TTIFIER AND 25CD6 HORIZONTAL PULSE AMPLIFIER DO NOT MEASURE THIS TAGE LC RESISTANCE ITHE OC RESISTANCE MEADING INDICATED NEAR THE ANSYGNAMES AND COULS HAVE BEEN TAKEN WITH AN OHMMETER DIRECTLY ROSS THE COUL BEING MEASURED COILS SHOWN WITHOUT A RESISTANCE ADING HAVE A DC RESISTANCE OF LESS THAN ONE OHM A TOLERANCE + OR-S \pm 15 PR MINSIBLE OF + DK-5 % IS FERMINISULE TEREVISED REMOVED REMOVING HE LABINE TIME CABINET BACK MAST INTERCO. REMOVED REMOVING HE LABINE TIME OF DEKNOMES IN SAFET I MITERCO. DER MOST REMOVING HE LABINE TIME OF DEKNOMES IN SAFET I MITH OF ATTEMPT TO DEFEAT THE PURPOSE OF THE SAFETY INTERLOCK AS SEVERE SHORT MAY RESULT DO NOT REMOVE TURES WHILE THE REGETIVER IS IN OPERATION AS OVERLOADING OR COMPONET FAILURE MAY RESULT OF THE PICTURE TUBE CARE SHOLLD BE USED WHEN HANDLING THE CHASSES OUTSIDE THE CABINET DO NOT SUBJECT THE TURE TO EXCESSIVE PRESSURE OR ROUGH HANDLING AS AN IMPLUSION MAY RESULT CAUSING SERIOLS OF SECOND OR ROUGH ANDLING AS AN INFLUSION MAY RESULT CAUSING SERIOUS PERSONAL INJURY WARNING AT ALL TIMES DURING OPERATION THE CHASSIS IS AT 125 WOLTS DC MARNING AT ALL TIMES DURING OPERATION THE CHASSIS IS AT 125 WOLTS DC POTENTIAL ABOVE GROUND AND IT ALSO MAY BE AT THE LINE VOLTAGE POTENTIAL ABOVE GROUND AND IT ALSO MAY BE AT THE LINE VOLTAGE POTENTIAL ABOVE GROUND AND IT ALSO MAY BE AT THE LINE VOLTAGE EXTERME CAUTION MUST BE OBS.RVED WHEN WORKING WITH THE CHASSIS OUTSIDE THE CABINET TAND WHEN POWER IS APPLIED TO THE RECEIVER WITH THE CABINET BACK REMOVED SEVER SHOLE SHOLE MAY RESULT FROM CONTACT WITH CHASSIS BE USED WHEN SERVED BE WEEN THE LINE CORD PLUG AND POWER RECEPTAGLE MIST BE USED WHEN SERVICE DAWNE OF MAY RESULT THE RECEIVER WITH CHASSIS BE USED WHEN SERVED BE WEEN THE LINE CORD PLUG AND POWER RECEPTAGLE MUST BE USED WHEN SERVICE ATUS ONE MOVES ALL SHOCK HAZARDS AND IS THE ONLY SAFEGUARD DAMAGE TO THE RECEIVER AND TEST EQUIPEMENT MAY RESULT WITHOUT THE USE OF AN ISOLATION THANSFORMER 0-17 68F6 6AU6 6AL5 6AU6 08E6 6S4 EAV6 AH6V V-14. 50C5 V-13 6AV6 12 AU7 6CBE V-20 25CD6 6086 V-19 5 Y 3 V-24 1B3 12AX4 6UB CONTROL UH H YOKE 6BZ7 6CB6 V-C V 14 V 18, V 22 and V 23 FILAMENTS IN SERIES 6AF4 V SIZE TUNING V SIZE Õ Ô 6 0 ΡН 'τν ON-OFF BRIGHT H. HOLD TONE PICTURE V HOLD YOKE WING NUT ANTI PIN CUSHION DEFLECTION YOK ADJUSTING SCREW ION TRAP MAGNET CENTERING MAGNET


		Raythe	on Manufac	turing Co	mpany, Chassis 21	T8 and $24T2$, continued
V—V S—S		LOW	BAND H	RF ALIO	SNMENT (Turn Tune	r to Channel 6)	
Step No.	Signal Generator Freq. (mc.)	Sweep Generator Freq (mc.)	Signal Input Point	Output Point	Remarks	Adjust	Response
1	V - 83.25 S - 87.75	Channel 6	VHF Antenna Terminals	RF Test Point	Adjust for max. gain and Flat Response	C208 & C213	Ň
2	V - 83.25 S - 87.75	Channel 6	VHF Antenna Terminals	RF Test Point	Adjust for max. gain between markers	C204	Ň
3	V - 83.25	Channel 6 Note: 1	VHF Antenna Terminals	IF Detector Output	Adjust osc. trimmer until marker is 50% down on video side of curve.	C230	50%
4	V - 83.25 S - 87.75	Channel 6	VHF Antenna Terminals	RF Test Point	Re-adjust for max. gain and flat response	C208 & C213	Ň
5	V - 55.25	Channel 2 Note: 2	VHF Antenna Terminals	IF Detector Output	Adjust osc. core until marker is 50% down on video side of curve.	L-213 (Repeat step 3)	50%
6	42.0 45.5	40 Note: 3	Antenna Input	IF Detector Output	Check over all IF response	C-204	A
	V - 77.25 S - 81.75 V - 67.25	Channel 5		-			\sim
7	S - 71.75 V - 61.25 S - 65.75	Channel 4 Channel 3	VHF Antenna Terminals	IF Detector Output	Adjust tuner until response curve appears.	Check Point Only	ff


HIGH BAND RF ALIGNMEN'T (Turn to Channel 13)

	V - 211.25 S - 215.75	Channel 13	VHF Antenna Terminals	RF Test Point	Adjust for maximum gain and flat response	C-211 & C-217	\bigwedge
2	V - 211.25 S - 215.75	Channel 13	VHF Antenna Terminals	RF Test Point	Adjust for maximum gain between markers	C-205	<u> </u>
3	V - 211.25	Channel 13 Note 1	VHF Antenna Terminals	IF Detector Output	Adjust osc. trimmer until marker is 50% down on video side of curve	C-231	50%
4	V - 211.25 S - 215.75	Channel 13	VHF Antenna Terminals	RF Test Point	Re-adjust for maximum gain and flat response	C-211 & C-217	, init
5	V - 175.25	Channel 7 Note 4	VHF Antenna Terminals	IF Detector Output	Adjust osc. core until marker is 50% down on video side of curve	L-214 (Repeat Step 3)	Son
6	V - 205.25 S - 209.75 V - 199.25 S - 203.75 V - 193.25 S - 197.75 V - 187.25 S - 191.75 V - 181.25 S - 185.75 V - 185.25 S - 175.25 S - 179.75	Channel 12 Channel 11 Channel 10 Channel 9 Channel 8 Channel 7	VHF Antenna Terminals	IF Detector Output	Adjust tuner until response curve appears on scope (See page 129 f	Check point only or reference	figures)



. _ . _





SENTINEL

RATIO DETECTOR AND SOUND ALIGNMENT

Step No.	Connect Signal Generator to	Sig. Gen. Freq.	Connect Voltmeter to	Miscellaneous Instructions	Adjust
I	In series with .001 Mfd. Cond. to junction of C-97 and L-13 terminal 3 of 4th I.F. See fig. 5	4.5 MC.	In series with 47,000 ohm res. across C-23 a 10 Mfd. cond. See fig. 5	Maintain reading on 10 volt scale contrast at maximum. Remove 3rd video IF tube 6CB6.	T-7 (top) and T-8 (bottom) for max. reading. See fig. 4 & 5
2	In series with .001 Mfd. Cond. to junction of C-97 and L-13 terminal 3 of 4th 1.F. See fig. 5	4.5 MC.	In series with 47,000 ohm res. to junction of R-30 and C-44. See fig. 5	Maintain reading on 10 volt scale contrast at maximum. Remove 3rd video IF tube 6CB6.	T-8 (top) for zero reading. See fig. 4
3	In series with .001 Mfd. Cond. to cathode of picture tube yellow lead. See fig 5	4.5 MC.	In series with 47,00 ohm res. across C-23 a 10 Mfd. cond. See fig. 5	Maintain reading on low volt scale. Remove 3rd video IF tube 6CB6.	T-6 (top) for mini- mum reading. See fig. 4

PICTURE I-F ALIGNMENT

4	Ungrounded converter tube (6J6) shield	44.0 MC.	In series with 47,000 ohm res. to junction of R-37 and L-7. See fig. 5	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5	T-5 (top) for maximum reading. See fig. 4
5	Ungrounded converter tube (6J6) shield	43.0 MC.	In series with 47,000 ohm res. to junction of R-37 and L-7. See fig. 5	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5	T-4 (top) for maximum reading. See fig. 4
6	Ungrounded converter tube (6J6) shield	41.25 MC.	In series with 47,000 ohm res. to junction of R-37 and L-7. See fig. 5	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5 Repeat Steps 5 & 6	T-4 (bottom) for minimum reading. See fig. 5
7	Ungrounded converter tube (6J6) shield	45.4 MC.	In series with 47,000 ohm res. to junction of R-37 and L-7. See fig. 5	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5	T-3 (top) for maximum reading. See fig. 4
8	Ungrounded converter tube (6J6) shield	47.25 MC.	In series with 47,000 chm res. to junction of R-37 and L-7. See fig. 5	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5 Repeat Steps 7 & 8	T-3 (bottom) for minimum reading. See fig. 5
9	Ungrounded converter tube (6J6) shield	44.6 MC.	In series with 47,000 ohm res. to junction of R-37 and L-7. See fig. 5 NOTE: Detune T-2 by turning slug out as far as possible.	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5	T-I (top) for maximum reading. See fig. 4
10	Ungrounded converter tube (6J6) shield	45.75MC.	In series with 47,000 ohm res. to junction of R-37 and L-7. See fig. 5	Tuner on channel 3, 3 volts bias across C-51 positive side to ground. Locality switch in strong position. See fig. 5	T-2 (top) for maximum reading. See fig. 4

NOTE 1: For minimum buzz always adjust T-8 (top) with the sound carrier of a TV station.

NOTE 2: Alternate 4.5 MC. trap alignment: Adjust T-6 (top) for minimum 4.5 MC. beat on picture with a strong station signal.

NOTE 3: For visual check of IF response curve (see fig. 2) connect signal and sweep generator to ungrounded converter tube shield (6J6). Connect oscilloscope in series with 47,000 ohm resistor to junction of R-37 and L-7.

TUNER R.F. ALIGNMENT

Step	Connect Marker	Marker	Connect Sweep	Sweep	Connect	Miscellaneous	Adjust
No.	Generator to	Gen. Freq.	Gen. to	Gen. Chan.	Oscilloscope to	Connections	
11	Loosely couple to sweep gen. leads.	205.25 MC. and 209.75 MC.	300 ohm an- tenna terminals.	12	Lead extending from top of tuner. See fig. 4	3 volt bias to junc- tion of C-51 locality	C-3, C7 and C-12 fo max. response havin linear peaks with pic ture and sound mark ers at 90% maximur response. See fig. 3

A SLIGHT COMPROMISE SHOULD BE MADE WITH C-3, C-7 and C-12 IF MARKERS ARE BELOW 70%.

NOTE 5: FOR RF OSCILLATOR ALIGNMENT, SET FINE TUNING CONTROL IN CENTER POSITION. ADJUST INDIVIDUAL CHANNEL TRIMMERS FOR BEST PICTURE DETAIL WITH THE PATTERNS OF A TV STATION.



OTE 6: C-18 (See fig. 4) part of a 40 MC. tuned trap need only be adjusted when local interferences from 40 thru 45 MC. affect the picture. Adjust C-18 for minimum 40 MC. beat on picture with a station signal. Not used in Models with UHF Tuner.

SPARTON TELEVISION

BIVISION OF The Sparks-Withington Company - Jackson, Michigan

Chassis 21S173A, used in Models 58112 and 58114 21S214, used in Models 31322, 32324, 35342, 35343, 11322A, 11324A, 15312A, and 15314A 24U174, used in Models 58112 and 58114 24U213, used in Models 20312, 20313, 21322, 21324 24U214, used in Models 21322A, 33322, 34324, 36342, 36343, 50312, and 50314.

The chassis listed above are practically identical except for minor circuit differences, different size and type of picture tubes, and the incorpotation of the Kingston UHF converter. The circuit diagram on the next two pages (over) is exact for Chassis 24U214.

MISCELLANEOUS SERVICE HINTS

Horizontal Drive Adjustments:

With 125V.A.C. line adjust vertical deflection for 10% over-scan with best linearity then adjust horizontal linearity control for best linearity and follow with adjustment of horizontal width control for maximum width. Adjust horizontal hold control to its maximum counter-clockwise position. Decrease horizontal drive control resistance until the compression near the center of the picture disappears. Reset horizontal hold control to its midposition.

With 117 A.C. line volts, the cathode current of the 6BQ6 must not exceed 110 Ma. with zero beam current.

Horizontal Oscillator Adjustment:


With 117 A.C. line volts and the horizontal hold control set at the mid-point of its range, adjust L-36 for synchronization with approx. zero volts from Pin #1 of V-17 to ground as measured with a vacuum tube or other high impedance voltmeter.


Adjustment of Anti-Pin Cushion Corrector Magnets:

These magnets are mounted on the deflection coil mounting bracket and can be moved in and out by first loosening the mounting screws. Under certain conditions it may be necessary to form, or bend the flexible arms which support the magnets. The above adjustment is made at the factory and should not require re-adjustment unless the original position of the magnets is accidently disturbed. Adjustment can be made in the following manner:

- With the size controls reduce the size of the raster until the sides are 1. visible.
- Adjust the corrector magnets for straightest possible raster edges. 2. Restore the picture to normal size.

Misadjustment of the corrector magnets may cause barreling, keystoning and/or poor linearity.








MOST-OFTEN-	NEEDED 1954 TELEV	/ISION SERVICING	INFORMATION
, continued. and adjust oscillator coll for best viewed in the area. GENERATOR	ALIGNMENT CHECK USING SWEEP GENERATOR, A GENERATOR, AND OSCILLOSCOPE. to normal operating position. Connect the sweep generator to the grid nnect a 4.5 volt bias battery between point G and ground. (Positive to chassis ground.) to chassis ground.) scope across R32 (point C) by means of the shielded cable and filter to chassis ground.) Scilloscope A 7K Decilloscope A 7K C Point (C) C POINT C POI		I.F. colls L11, L13, L14, L15, until the picture I.F. response shown is obtained. The solid curve depicts the ideal I.F. response while the dotted curves show permissable variations.
	ALIGNMENT PROCEDURE UNMODULATED (CW) GENERATOR METHOD Bisp One: SOUND TRAP ALIGNMENT A. Addust all controls to normal operating position. Connect the R.F. Bignal Generator to the grid of V-2 (Point A.) I.F. input adapter, as shown below. R. F. Generator Output Output 0 output 0	 B. Connect VTVM across R32 (Point C.) Use low volts D. C. Scale. C. Connect a 4.5 wolt bias battery between Point G and ground. (Positive terminal of battery to chassis ground.) D. Set R.F. Tuner to channel which gives minimum indication on voltmeter. E. Adjust L12 for minimum indication on voltmeter at the specified frequency: L12 = 21.75 mc Step Two: PIX IF ALIGNMENT A. Adjust L11, L13, L14, L15, for maximum indication on voltmeter at the specified frequency: frequency: L11 22.5 mc L13 23.5 mc L14 23.6 mc L15 26.0 mc L15 26.0 mc L15 26.0 mc 	 Step Three: SOUND IF ALIGNMENT A. Connect the R.F. Signal Generator to Point C. B. Inject the 4.5 mc signal. (Frequency accuracy important.) C. Connect VTVM from Point E to ground. Use - 10 voit DC Scale. D. Adjust L25 and T1 primary for maximum indication on voltmeter. E. Connect VTVM from Point E to ground. Use lowest D. C. Scale. Adjust accondary of T1 Connect WTVM from Point E to ground. Use lowest D. C. Scale. Adjust taccondary of T1 connect VTVM from Point E to ground. Use lowest D. C. Scale. Adjust secondary of T1 connect VTVM from Point E to ground. Use lowest D. C. Scale. Adjust secondary of T1 connect VTVM with detector probe from positive to negative to negative to negative to repeat alignment of primary and secondary until no improvement seriously misaligned repeat alignment of primary and secondary until no improvement can be made.) F. Connect L18 for minimum indication on voltmeter.

STEWART-WARNER TELEVISION RECEIVER MODELS 21T-9300A, 21T-9300AA, 21T-9300B, 21T-9300D, 21C-9300E, 21C-9300F, 21C-9300G, 21T-9300H, 21T-9300HA, 21C-9300K, 21C-9300KB, 21C-9300L, 21C-9300LB, 21C-9300M, 21C-9300MB, 21C-9300P, 21T-9300R, 21T-9300RB, 21T-9300S & 21T-9300T.

Series 9300 service material applicable to the above listed models is presented on pages 143 to 152 inclusive. The main circuit diagram is on pages 144-145. Models <u>24C-9360</u>, <u>24C-9370</u>, <u>27C-9310</u>, <u>27C-9350</u>, use very similar circuits.







MOST-OFTEN-NEEDED 1954 TELEVISION SERVICING INFORMATION Stewart-Warner Television Receivers LETTER DESCRIPTION OF CHANGE Series 21C9300 and 21T9300, continued DESIGNATION If the following changes were incorporated to pravide for the use of an alternate type tube. Change V4 (Video Amp.) from a type 6CL6 to a type 128Y7 tube. The circuit for tube V4-6CL6 (Video Amp.) is shown at the right: ----..... - 12 **PRODUCTION CHANGES** 6CL6 The following tabulatian furnishes complete details an changes which occurred during receiver production. The receivers incorporating these changes are identified by coding stamped on rear surface of chassis. The coding consists of one or mare letters following the word SERIES, as SERIES B, SERIES AC, etc., and corresponds to similarly lettered changes shown below. Chassis incorporate only that change indicated by letter designation; i.e., chassis stamped "SERIES BE". does not include changes "A" or "C" or "D". VIDED AND Amp.) is shown at the right: POWER BOOSTER The circuit shown on this page applies to "SERIES ABCDEFGHJKLMPQRST" chassis. The following change was incorporated to improve facus. 1. Disconnect pin 6, focusing grid af V17 (Picture tube), fram ground and connect to 270 volt supply. "<u>L"</u> A letter following the component circuit diagram number thus—201 ^, indicates that this particular item was affected by a circuit change. The letter corresponds ta the series code letter listed in the production change column, from which complete change information can be becaused. The following changes were incorporated to meet an U.L. requirement. 1. Remove condensers 73 and 74 (.01 Mfd.) from each leg of the A.C. input. 2. Add resistor 201 (150,000 Ohms) to the switch leg of the A.C. input. "M" obtained. LETTER DESCRIPTION OF CHANGE Chassis having this change do not incorporate a Phono Switch (66-A, B) nor a Phono Input Socket. DESIGNATION "N" INITIAL PRODUCTION UNCODED The following changes were incorporated to improve the picture quality. 1. Change resistor 30 in plate circuit of tube V2 (2nd I.F.) from 15,000 Ohms to 5600 Ohms. The following change was incorporated to maintain a better balance af filament voltage on the tubes connected across the 12.6 volt transformer filament winding in the event of tube failure or removal from the socket. 1. The center tap af the 12.6 filament winding an power transformer 76 is connected to ground through the common red and yellaw lead. Trans-formers not having this modification have a red identification dot on the bottom side. //D// ·· Δ'' Alignment frequencies of the I.F. system ore as follows: 2. Converter Plote coil: 23.5 Mc. 1st I.F. coil: 23.5 Mc. 2nd I.F. coil: 25.9 Mc. 3rd I.F. coil: 25.9 Mc. the bottom side. The following changes were incorporated to extend the useful range of the Horizontal Hold control. "Q" The following changes were incorporated to improve focus at high bright-"B" Change Harizontal Range 108-A control in the grid circuit of V8A (Horizontal A.F.C.) from a variable condenser (10-160 Mmfd.) to a fixed condenser 218 (47 Mmfd.). The tollowing change interpret of the second seco Change resistor 113 in grid circuit of tube V8A (Horizontal A.F.C.) from 150,000 Ohms to 220,000 Ohms. 2. Loy, our Ohms to 220, our Ohms. Change resistor 114 in grid circuit of tube V8A (Harizontal A.F.C.) from 330,000 Ohms to 1 Meg. Add resistor 212 (150,000 Ohms) from the junction of condenser 109 (47 Mmfd.) and resistor 114 (1 Meg.) to chassis ground. Remove resistor 133 (10,000 Ohms) in grid circuit of tube V9 (Horizontal Scanning Output) and replace with condenser 133 (270 Mmfd.). 3. Disconnect phono terminal of switch 66A from the 320 volt supply and connect to the 120 volt supply. connect to the 120 volt supply. The following changes were incorporated to increase harizontal sync. stability on strong signal levels. 1. Change connection of candenser 107 (100 Mmfd.) in grid circuit af V8A (Hariz: A.F.C.) from junction of resistors 105 and 106 to the plate (pin 6) of V7A (12A17—Sync. Amplifier). 2. Change resistor 124 in plate circuit of V8A (Horiz. A.F.C.) from 100,000 Ohms to 120,000 Ohms. 3. Change resistor 97 in grid circuit of V6 (Gated Sync. Separator) from 1.2 Meg. to 820,000 Ohms. "C" Scanning Output) and replace with condenser 133 (270 Mmfd.). Change resistor 97 in grid circuit of tube V6 (Gated Svnc. Separator) from 820,000 Ohms to 1.5 Meg. The plate load resistor of tube V7A (Sync. Amp.) differs with various series type chassis. Before undertaking the change listed belaw, check the series type chassis and incorporate only the applicable portion. a. On chassis that incorporate a letter "J" in the series designation, change resistor 106 fram 10,000 Ohms to 4700 Ohms and add resistor 105 (4700 Ohms) remains connected to the plate of tube V7A. Resistor 182 (18,000 Ohms) remains connected to the plate of tube V7A. - 12AU7 while condenser 107 (100 Mmfd.) is reconnected to the junction of resistors 105 and 106. b. On chassis that incorporate a letter "F" but does not include the letter The following changes were incorporated to extend range of width control. 1. Change resistor 84 at output of V12 (Rectifier) from 100 Ohms to 50 Ohms. "D" 2. Add resistor 138 (47,000 Ohms) in parallel with resistor 139 (12,000 Ohms) located in screen circuit of V9 (Horiz, Scanning Output). The following change was incorporated to facilitate production techniques. 1. Two interconnecting sackets and plugs were added in the chassis. iunction of resistors 105 and 106. b. On chassis that incorporate a letter "F" but does not include the letter ""in the series designation, change resistor 106 from 6800 Ohms ta 3300 Ohms and add resistor 105 (3300 Ohms) in series with resistor 106 and plate of tube V7A.-12A17 while condenser 107 (100 Mmfd.) is still connected to the junction of resistor 105 and 106. c. On chassis that do nat incorporate letters "F" and "J" this step (#7) need not be undertaken when incorporating the "Q" change. ln addition to the above changes the Syncroguide transformer must be readjusted in accardance with the pracedure (for a Series "Q" chassis) given in the service data section of the manual. "E" two interconnecting sackers and plogs were added in the chasts: The following change was incorporated to minimize the possibility of critical horizontal holding action when changing channels. Add condenser 45 (5000 Mmfd.) between resistor 44 (47,000 Ohms) and pin 1 of tube V6 (Gated Sync, Separator). NOTE: When undertaking this modification be sure that the SERIES "C" is also incorporated. The following changes were incorporated to minimize hum and buzz in audia system. ''F'' this modification be sure that the SERIES "C" is also incorporated. The following changes were incorporated to minimize hum and buzz in audia system. Add resistar 92 (1500 Ohms) and resistor 93 (15,000 Ohms) in series between the 120 volt supply and the 270 volt supply. The junction of these two resistors, 92 and 93, provides the 135 volt supply. Relocate condenser 85C (40 Mid.) from the 270 volt supply to the 135 volt supply and add condenser 91 (4 Mid.) to the 270 volt supply to the 135 volt supply and add condenser 91 (4 Mid.) to the 270 volt supply to the 135 volt supply and concert to the 135 volt supply. Disconnect pins 2 and 7 of tube V5 (Keyer-A.G.C.) from the 120 volt supply and connect to the 135 volt supply. Disconnect resistor 97 (820,000 Ohms) in grid circuit of V6 (Gated Sync. Separator) from the 120 volt supply and connect to the 135 volt supply. Disconnect pins 2 and 7 of tube V5 (Keyer-A.G.C.) from the 120 volt supply and connect to the 135 volt supply. Disconnect resistor 104 (1 Meg.) in grid circuit of V7A (12A17-Sync. Amplifier) from the 120 volt supply and connect to the 135 volt supply. Disconnect pins 6, cathode of V7A (12A17-Sync. Amplifier) from the 120 volt supply and connect to the 285 volt supply. Disconnect pins 5 (3300 Ohms) in plate circuit of tube V7A (12A17-Sync. Amplifier) and change resistor 106 from 3300 Ohms to 6800 Ohms. The following changes were incorporated to meet an U.L. requirement. Add resistor 13 (1 Meg.) in high voltage supply to the picture tube. This resistor is located in the shield of the 183GT socket. The following changes were incorporated to reduce the amount of undesired video signal present in the sync. pulse. Change resistor 100 in plate circuit of V6 (Gated Sync. Separator) from 330,000 Ohms to 6200 Ohms. Change resistor 100 in plate circuit of V6 (Gated Sync. Separator) from 12,000 Ohms to 6800 Ohms. Change resistor 100 The following changes were incorporated to imprave the blanking during horizantal retrace interval. Add resistar 213 (150,000 Ohms) between cathode of tube V9 (Horizontal Scanning Output) and the grid circuit of tube V17 (Picture Tube). Add resistor 214 (1 Meg.) between pin 1 of the horizontal output trans-former and grid circuit of tube V17 (Picture Tube). Add resistor 215 (56,000 Ohms) from the junction of resistors 213 and 214 to chassis ground. Add condenser 216 (100 Mmfd.) from the junction of resistors 213 and 214 to the grid of tube V17 (Picture Tube). 4. The following change was incorporated to reduce illumination of picture tube with minimum setting of the Brightness Control. 1. Change resistor 68 in the brightness circuit from 470,000 Ohms to 330,000 Ohms. The following change was incorporated to prevent the A.G.C. voltage from going positive. 1. Add V14B (678—A.G.C. Clamp) by connecting diode plate pin 6 of tube V14—678 to A.G.C. system. The following change was incorporated to minimize frequency drift in the syncroguide circuit. "R" Change condenser 130 from a .01 Mfd. to a .01 Mfd. (Special charac-teristic) Stewart-Warner part 512311 only. The following change was incorporated to improve the shape of the sync. The fallowing changes were incorpor-ated to improve the useful ronge of the Power Booster control. 1. Change connection of Brightness control 67A associated circuit from cothode of tube V17 (Picture tube) to grid of the same tube. The Brightness circuit for chassis that do not incorporate the letter "S" is shown at the right: 2. Add resistor 219 (470 000 Ohms) "G" In the series and the series designation were produced with a 12,000 Ohm. "S" 84 -00resistor. 100 resistor. The following change was incorporated to minimize harizontal oscillator drift thus improving Harizontal Hold action: 1. Change condenser 131 in plate circuit of V88 (Harz. Blacking Osc.) from a ceramic type, 820 Mmfd. ±10%, 400 volt ta a mica type, 820 Mmfd. ±5%, 500 volt. **]**# "H" <u>ش</u> Add resistor 219 (470,000 Ohms) in parallel with condenser 62 (.1 Mfd.) located in cathode circuit of tube V17 (Picture tube). 2. ₩, 13 VERI STAC BRIGHTINESS <u>٬٬٫٬٬</u>

The following changes were incorporated to provide for the use of an alternate type tube. 1. Change V7A (Sync. Amp.) and V7B (Vert. Blocking Oscillator) from a type 12A17 to a type 12AU7 tube. Change condenser 71 in grid circuit of tube V17 from 5000 Mmfd. to 03 Mfd.

of tube V1/ (ricture tube). 3. Change resistor 70 in plate circuit of tube V78 (Vert. Blocking Osc.) from 100,000 Ohms to 47,000 Ohms and add condenser 210 (.1 Mfd.) in series with resistor 70. Cannect other end of condenser 210 to the junction of condenser 190 (.047 Mfd.) and resistor 191 (8200 Ohms).

Stewart-Warner Series 21C9300 and 21T9300 Receivers, continued

ALIGNMENT PROCEDURE

The receiver chassis must be removed from the cabinet in order to accomplish alignment of all tuned circuits.

Alignment of all RF and IF tuned circuits in this receiver may be accomplished by utilizing the procedures described in the following charts.

These procedures should preferably be applied in the order in which they are presented. Alignment of Sound Channel of IF Channel may be accomplished individually if desired.

The RF Amplifier and Mixer alignment may also be accomplished independent of Sound or IF Channel alignment, but oscillator calibration can only be done after IF Channel has been correctly aligned.

CAUTION

The picture tube is highly evacuated and if broken fragments will be violently expelled. Handle with care. Avoid contact with metal shell of picture tube as this is part of the high voltage circuit.

INSTRUMENTS: The following instruments will be required as signal sources and output indicators during the alignment process. Since accurate alignment of a television receiver is heavily dependent upon the performance of your instruments, it is imperative that they meet the essential specifications described here.

- STANDARD SIGNAL GENERATOR to provide unmodulated (pure RF) signals at the following frequencies. Maximum output on all ranges should be at least .1 volt with provision for attenuation as desired. This instrument must have good frequency stability and be accurately calibrated.
 - a. IF Frequencies: 4.5 Mc. Sound Channel 21.5 Mc. to 26.6 Mc. IF Channel
 - b. RF Frequencies: 54 to 88 Mc.
 - 174 to 216 Mc.
- 2. VACUUM TUBE VOLTMETER. The lowest voltage range of this instrument should preferably permit a 1.0 volt reading to be indicated at not less than one third of full scole deflection.
- RF SWEEP GENERATOR to provide frequency modulated signal for observing the over-all bandpass characteristic and RF Channel alignment at the following frequencies:
 - 20 to 30 Mc. with 10 Mc. sweep width.
 - 54 to 88 Mc. with 10 Mc. sweep width.
 - 174 to 216 Mc. with 10 Mc. sweep width.
- 4. CATHODE RAY OSCILLOSCOPE, preferobly a unit with vertical amplifier having wide range frequency response and low capacity pick-up probe. This instrument is used for observing the over-all bandpass characteristic and for RF Channel alignment.


SOUND CHANNEL ALIGNMENT PROCEDURE

- 1. Short antenna terminals together with a jumper wire,
- Set receiver Channel Selector to any inactive television channel and Power Booster cantrol to its maximum counter-clockwise position; other controls may be left at any desired setting.
- A small screwdriver (preferably non-metallic) can be used for alignment of Sound IF. The blade of this tool will fit the slot in the core

of the transformer.

STANDARD SIGNAL GENERATOR		VTVM	MISCELLANEOUS	TRIMMER	TYPE OF ADJUSTMENT		
CONNEC- TIONS	FREQUENCY	CONNECTIONS	ONNECTIONS INSTRUCTIONS		AND OUTPUT INDICATION		
Connect os shown in Fig. 1.	4.5 MC. unmodulated IMPORTANT This signal must be occurate with- in 1/4 of 1% of 4.5 Mc. Check generator calibro- tion against a crystal controlled signal source by "zero beating" (heterodyning) with harmonics of the crystal fre- quency.	Connect as shown in Fig. 2.	 Set Power Booster control to its maximum clackwise position. A special detector must be utilized when aligning the 4.5 Mc. Sound Trep Coil. This unit can be constructed in accordance with the information contained in Fig. 3. If a VTVM containing a high frequency A.C. probe is available, this probe can be utilized in place of the crystal detector shown in Fig. 2. During this adjustment only, remove one of the three 6CB6 IF amplifier tubes (V1, V2 or V3). This will prevent noise in the RF stages from effecting the voltage reading while adjusting the sound trap. 	#1 4.5 MC Sound Trap (See Fig. 10)	Adjust for minimum reading on VTVM.		
			A "swishing" sound may be heard in the	# 2 Discriminator Secandary (See Fig. 10)	Adjust for maximum reading on VTVM.		
Same as above	Same as above.	Connect as shawn in Fig. 4.	speaker during Sound Channel Alignment. This spurious oscillation is caused by hori- zantal sweep voltage being picked up in the audio system thru stray coupling of instrument leads; it should be distegarded as it will have no effect on alignment of	# 3 Discriminator Primary (See Fig. 11)	Adjust for maximum reading on VTVM.		
			the sound channel.	# 4 Sound IF Transform e r (See Fig. 10)	Adjust for maximum reading on VTVM.		
Same as above.	Same as above.	Connect as shown in Fig. 5,	To obtain zero balance of the discriminator circuit, two 68,000 ohm resistors will be required. These resistors must be matched so that their respective resistances do not differ by more than 1%—the accu- racy of the total resistance is not critical. Connect the two resistors in series from pin 2 of the 678 tube to chassis ground as shown in Fig. 5.	# 2 Discriminator Secondary (See Fig. 10)	Note that as slug #2 is rotated a point will be found where th voltmeter will swing rother sharp ly from a positive to a negativ reading or vice versa. The co rect setting of slug #2 is obtaine when the meter reads zero c the slug is moved thru this poin		

Replace the type 6CB6 tube previously removed in the above procedure and turn set on. Tune in to a local channel and should there be an us amount of "Intercarrier Buzz" refer to procedure on adjoining page to remove this aforementioned fault.



Stewart-Warner

IF CHANNEL ALIGNMENT PROCEDURE

(Continued)

- A special aligning tool designed to fit the stems on adjustable cores of the IF coils (see points 5, 6, 7 and 8 in Fig. 10) is available and may be obtained from Stewart-Warner by requesting IF Alignment Tool #507479.
- 2. Turn receiver Channel Selector to television channel #12 and short antenna terminals together with a jumper wire.
- Connect a 3 volt battery to the receiver AGC system so that negative terminal of battery connects to the AGC line and positive terminal of bottery connects to receiver chassis. See Fig. 11 for convenient point of connection.
- 4. If the IF channel is badly misaligned and two ar more immediately adjoining IF stages are tuned to the same frequency, oscillation may occur. Such oscillation shows up as an excessive voltage across the video detector load, circuit reference number 42 and 43, and is indicated by the VTVM that is connected to this point during alignment. It should be noted that voltage due to IF oscillation is unaffe;ted by


strength of signal from the generator.

Where IF oscillation is encountered, it is generally possible to correct the condition by detuning the IF coils in different directions. If that does not have the desired effect, increase fixed bias on AGC line by using a 4½ volt battery instead of the 3 volt battery referred to in instruction #3. After stopping the oscillation in this manner it will then be possible to align all IF stages using the following procedure, however, the AGC bias battery must be changed back to 3 volts when using the oscilloscope to observe band pass characteristics. Once all stages have been aligned using the 4½ volt bias, the IF channel should be stable with reduced bias.

5. In order to eliminate the possibility of spurious oscillations, it is desirable to render the RF oscillator inoperative. This may be readily accomplished by insulating oscillator terminals of tuner. Remove tuner bottom shield and place a piece of transparent cellulose tape on the first two contacts (from front) of drum assembly. Use any inoperative channel and rotate drum to this insulated position.

STANDARD SIGNAL GENERATOR		SWEEP GE	NERATOR	VTVM	'SCOPE	MISCELLANEOUS	TRIMMER	TYPE OF ADJUST-		
CONNEC- TIONS	FREQUENCY	CONNEC- TIONS	FREQ.	CONNEC- TIONS	CONNEC- TIONS	INSTRUCTIONS	OR SLUG	MENT AND OUTPUT INDICATION		
Connect as shown in Fig. 7.	23.4 MC. OR 23.5 MC. See Note "P" Below	Not used.		Connect as shown in Fig. 9.	Not used.	Be sure that RF as- cillator has been rendered inopera- tive as outlined in instruction #5 at the head of this chart.	#5 Converter plate coil (See Fig. 10)	Adjust for maximum reading on VTVM.		
Same as above.	24.2 MC. OR 23.5 MC. See Note "P" Below	Not us ed .		Same as above.	Not used.	Same as above.	# 6 1st 1.F. (See Fig. 10)	Adjust for maximum reading on VTVM.		
Same as above.	26.2 MC. OR 25.9 MC. See Note "P"	Not used.		Same as abave.	Not us ed .	Same as above.	#7 2nd 1.F. (See Fig. 10)	Adjust for maximum reading on VTVM.		
Same as above.	25.4 MC. OR 25.9 MC. See Note "P"	Not us ed .		Same as above.	Not used.	Same as above.	#8 3rd 1.F. (See Fig. 10)	Adjust for maximum reading on VTVM.		
Connect as i hown in fig. 8.	26.6 OR 26 MC. See Note "P" Below	Connect as shown in Fig. 8.	25 MC. Sweeping ± 5 Mc.	Same as above.	Connect as shown in Fig. 9	on the oscillo- scope. 3. Be sure that a 3 volt battery is connected to AGC line as specified in instruction #3 at the head af	by the use of a should compare picture corrier m that incorporate at rear of chassi amplitude positio 20- 20- 50L 40- MAF 60- 80- 100- 5 Should this obser repeated, exercis of the marker g	s: characteristic can new be observ 'scope. Its general shape and conto with the curve shown in Fig. 6. T tarker (26.6 Mc. or 26 Mc. on Chas a letter 'P' in the series designati- s) should appear at the 50% (±109 in of the curve as shown in Fig. 6. CCH DIVISION = I MC. IND IND IND IND IND IND IND IND		
Same as above.	22.1 OR 21.5 MC. See Note "P" Below	Same as above.	Same as above.	Same as above.	Same as above.	Same as above.	chassis that incor nation at rear of of a 'scope and in Fig. 6. Increas in order to magn curve. This marks cated in Fig. 6. S erly positioned, c	r marker (22.1 Mc. or 21.5 Mc. o porate a letter "P" in the series desi chassis) can be observed by the u should be compared with that show se the vertical gain control or "sco- ify the sound portion of the respon or should appear at the position ind should the sound marker not be proj heck the setting of the picture carri ed in the previous step.		

NOTE "P": On chassis which have a letter "P" in the SERIES designation on rear of chassis, the converter Plate and 1st I.F. coils must be aligned to 23.5 Mc. and the 2nd I.F. and 3rd I.F. coils must be aligned to 25.9 Mc. The carrier markers on this series type chassis are: picture carrier 26 Mc., sound carrier 21.5 Mc.




Stewart-Warner Series 21C9300 and 21T9300 Receivers, continued

RF CHANNEL ALIGNMENT PROCEDURE

 CAUTION: The shell of the picture tube has a high voltage potential, approximately 14,000 volts, and contact should be avoided. As the adjustment screws are in relatively close proximity to this shell, some means of insulation from accidental contact should be provided.


 Connect a 3 volt battery to the receiver AGC system so that negative terminal of battery connects to AGC line and positive terminal of battery connects to receiver chassis. (See Fig. 11 for convenient point of connection.)

	RD SIGNAL ERATOR	SWEEP GE	SWEEP GENERATOR VTVM SCOPE MISCELLANE		MISCELLANEOUS	TRIMMER	TYPE OF ADJUST- MENT AND OUTPUT		
CONNEC- TIONS	FREQUENCY	CONNEC- TIONS	FREQ.	TIONS	TIONS	INSTRUCTIONS	OR SLUG	INDICATION	
			RF	AMPLIFIE	R AND N	NIXER ALIGNM	ENT		
Connect as shown in Fig. 12.	205.25 MC.	Cannect as shown in Fig. 12 and set controls for sweep width of 10 Mc. on 1 e l e v i - sion channel specified in the next col- umn.	CHANNEL #12	Not used.	Connect as shown in Fig. 13.	Set Channel Selec- tor to #12. IMPORTANT: Keep output of standard sig no 1 generator at a level that provides a readable marker but does not distort the curve that is be- ing observed an the scope.	Mixer Grid. (See Fig. 19) #10 RF Amp. Plate	Adjust these trimmers to obtain proper ly shaped RF band pass characteristic a shown in Fig. 16. Use Mixer Grid trim mer #9; and RF Amplifier Plate trimme #10 to obtain correct amplitude of char acteristic in vicinity of picture and soum carrier markers. Then adjust RF Amp Grid trimmer #11 to equalize overal amplitude. Repeat adjustment of trim mers to be sure correct respanse ha been obtained. IMPORTANT: When adjusting trimmer #9, 10 and 11 it will be noted that the band pass characteristic can be broad ened by sacrificing amplitude. It is un desirable ta averly broaden the curve a that would result in a loss of sensitivity	
Same as above.	The bandpass charac- teristic for sources- sive channels should now be abserved in divid- ually. For fre- quency setting of marker sig- nals see table in Fig. 15.	Same as above.	Set sweep gener- ator to chan- nel fre- quen- cies being observed.	Not used.	Same as above.	Set channel selectar ta chonnel being abserved.	channels shoul settings of tri sweep generat the other televe the sound carr characteristic of the RF response promise may be tions in chann	pass characteristic of the other televisian d now be checked without disturbing the immers ±7, 10 and 11. Adjust the RF or and marker generator for operation of ision channels, observing position of both ier and picture carrier markers. Band pass of these channels should conform close to se curve in Fig. 16. If necessary, a com- e obtained to compensate for large varia- el response by returning to channel #12 light changes in the settings of trimmers 1.	
	<u> </u>			OSCII	LATOR A	LIGNMENT			
circuits in Fig. 2. During control	RTANT: Befor are correctly 6. oscillator alig so that the too t position for tl	aligned for b gnment, it is i oth on the fiber	and pass o necessary to r fine tuning	characteristic il o set the Fine g cam points do	lustrated Tuning 4.	keep output af swi on VTVM to exce . Keep output of st	eep generator ed one-half vo andard signal	Il succeeding steps it is necessary to: at a level that does not allow reading It. generator at a level that provides a istort the curve that is being observed	
Connect as shawn in Fig. 12.	205.25 MC.	Connect as shown in Fig. 12 ond set controls for sweep width of 10 Mc. on t e l e v i - sion channel specified in the next col- umn.	CHANNEL #12	Connect as shown in Fig. 14.	Cannect as shown in Fig. 13.	Set Channel Selector to #12 Be sure that gener- ator's output does nat exceed voltage specified in instruc- tions #3 and 4 above.	oscillator slug Tuner Unit—se picture carrier in Fig. 17. NOTE: Before vance the verti magnify the so	etallic screwdriver to adjust channel #12 (accessible thru hole on front of RF re Fig. 18) shift response curve so that marker is located at the position indicated making the following adjustment, ad- ical gain control on the 'scope in order to ound portion af the response curve. on of sound carrier marker (see Fig. 17).	
Same as above.	The bandpass c h a r a c - teristic for each of the s u c c e s - sive channels should now be abserved i n d i v i d - ually. For fre- quency setting of marker sig- nals see table in Fig. 15.	Some as above.	Set sweep gener- ator to chan- nel fre- quen- cies being observed.	Same as above.	Same as above.	to channel being observed.	for operation a er generator t Channel Select. lator slug thru 18). This perm picture and so pasitian indicat for the corress the 50% ampli band pass cha NOTE: Make s remains proper	sweep generator and marker generator in the ather television channels; set mark- o sound carrier frequency. After setting ar to corresponding channel, adjust ascil- hole an front of RF Tuner Unit (see Fig- nits response curve to be shifted so that und carrier markers will appear at the ted in Fig. 17. The picture carrier marker sounding channel should then appear at tude position on the opposite side of the racteristic curve. ure that cam on fine tuning control shaft 1y positioned during this step (tooth on ng downward—see Fig. 18).	
	1 1						the end so the		



MOST-OFTEN-NEEDED 1954 TELEVISION SERVICING INFORMATION STROMBERG-CARLSON 622 SERIES 624 SERIES TELEVISION

The illustration on this page of chassis top and rear panel is exact for 622 Series and is similar in appearance to 624 Series. In following alignment information on page 158, which is applicable to both 622 and 624, reference may be made to this view. Tube voltage chart for 622 Series is on page 154, and the circuit diagram for 622 Series on page 155. The circuit diagram for 624 Series is printed separately on pages 156-157, since it is different in some important respects from the 622.



Stromberg-Carlson 622 Series Tube Voltage Chart


TUBE VOLTAGE CHART

1. Measurements are made at 117 Volts line using vacuum tube voltmeter. All voltages are D.C. and are


positive with respect to chassis ground except where noted. 2. Contrast and brightness controls set for normal picture. (Strong signal area).


			PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6	PIN 7	PIN 8	PIN
V-10	6CB6	1st VIDEO	—3.66	.09	Fil.	AC 6.3	134	144	Gnd.	-	
V-11	6CB6	2nd VIDEO	—3.46	.08	AC 6.3	AC 6.3	125	144	Gnd.		
V-12	6CB6	3rd VIDEO	0	1.28	AC 6.3	AC 6.3	110	128	Gnd.		
V-1 <u>3</u>	6U8	1st SYNC. CLIPP 1st VIDEO AMP	43.2	1.32	104	AC 6.3	AC 6.3	129	Gnd.	Gnd.	•
V-14	6W6	2nd VIDEO AMP	9.8	AC 6.3	274	146	9.26	528	Gnd.	25	
V-15		KINESCOPE SOCKET.	Gnd.	313	474	RF	522	Gnd.	468	465	
V-16	6U8	1st AUDIO	128	0	141	AC 6.3	AC 6.3	140	.78	56	—21 .2
V-17	6AU6	DRIVER		Gnd.	AC 6.3	AC 6.3	107	113	Gnd.		
V-18	678	RATIO DET		37.4	2.46	AC 6.3	AC 6.3	—3.7	Gnd.	—.76	64.4
V-19	6¥6	AUDIO OUTPUT	NC	Gnd.	234	257	.05	NC	AC 6.3	12	
V-20	6AU6	A.G.C	134	144	144	144	—37	316	144		
V-21	12AU7	PHASE INV 2nd SYNC. CLIPPER	41.8	Gnd.	15.6	AC 6.3	AC 6.3	116	13.4	20.6	Gnd.
/-22	6C4	VER. OSC	NC	NC	Gnd.	AC 6.3	128		0		
/-23	654	VER. OUTPUT	NC	23.2	NC	/ 0	AC 6.3	.11	NC	NC	458
/-24	6AL5	PHASE DET	0	0	Gnd.	AC 6.3	14.8	NC	—13.6		
-25	65N7	HOR. OSC	—14.6	156	11.6	1.64	264	11.6	AC 6.3	Gnd.	
/-26	6BQ6	HOR. AMP	161	Gnd.	NC	159			AC 6.3	10	
-27	6AX4	DAMPER	NC	NC	565	NC	316	563	AC 6.3	Gnd.	
-29	5U4	L.V. RECTIFIER	NC	335	NC	Plate	NC	Plate	NC	335	
-30	504	L.V. RECTIFIER	NC	335	NC	Plate	NC	Plate	NC	335	
27	Terminal	V.H.F. TUNER	137	152	AC 6.3	98	NC	0	0	0	T.B.17 0





.....





Stromberg-Carlson 622 and 624 Series Alignment Procedure

Apply A.G.C. bias of approximately—2 V to A.G.C. Line (across C-202). Maintain the output level of the sweep generator such that the second detector output is 2 volts peak to peak. Scope Cal. 1-V per inch. NOTE—USE A NON-METALLIC ALIGNING TOOL AND LIGHT PRESSURE ON ALL SLUGS.

Signal Generator Connection	Oscilloscope or VTVM Connection	Adjustments	
 Output of 40mc. Sweep Genera- tor to grid of 3rd I.F. Tube, pin of 6CB6 V-12 thru 100 MMF isolating capacitor. 	Input of scope to grid of Video Amplifier, pin 2 of 6U8 V-13 thru 47K ohm isolating resistor.	 Adjust top ond bottom of T-11 for marker positions as shown on curve Figure 1. 	4 5.75 96 % FIG. 1
 Output of 40mc. Sweep Genera- tor to grid of 2nd I.F. Tube, pin 1 of 6CB6 V-11 thru 100 MMF isolating capacitor. 	Same as Step #1.	 Adjust top and bottom of T-10 for marker positions as shown on curve Figure 2. 	
3. Output of 40mc. Sweep Generator to grid of 1st 1.F. Tube, pin 1 of 6CB6 V-10 thru 100 MMF isolating capacitor.	Same as Step #1.	 Adjust top of T-9 for marker position of 47.25mc. Adjust bottom of T-9 for marker positions at 41.25mc. Adjust bottom of T-6 for marker position at 39.75mc. Adjust bottom of T-7 and T-8 to produce curve as shown on Fig- ure 3. 	FIG. 2
B. Raise converter tube shield from ground and connect output of 40mc, sweep generator to the shield.	Same as Step #1.	 Adjust top of T-6 ond L-4 on tuner (L-14 on standard coil tuner) assembly to produce a curve as shown on Figure 4. 	4 532
Connect a 400 cycle modulated 4.5mc. signal to the junction of Video detector M-13 and C-130. Adjust generator output to a level to indicate 1.5 Volts on VTVM.	Connect 2-100 resistors in series from plate of ratio detector pin 2 of V-18, 6T8 to ground. Con- nect VTVM from junction of the 2-100K resistors to ground.	 Adjust L-21, T-15 and bottom slug of T-16 for maximum indi- cation. 	FIG. 4
. Same as Step #5.	Connect — VTVM ground lead to the junction of the 2-100K resistors (see 5 above). Connect VTVM D.C. lead to the junction of C-183 and R-182.	 Adjust the secondary (Top slug) of T-16 for zero volts between the positive ond negative ex- cursions. (Increase Generator out- put for good deflection). 	
IF THIS METHOD IS U	Alternate Tra SED, IT SHOULD BE PER	p Alignment FORMED BEFORE THE I.F. CURVE	ALIGNMENT
Signal Generator Connection	Oscilloscope or VTVM Connection	Adjustments	
. Connect a modulated (400 cycle) 39.75mc. signal to grid, pin 1 of the 1st video I.F. Tube—V-10.	Same as Step #1.	 Adjust bottom of T-6 for mini- mum response on scope. 	
Connect a modulated (400 syster)	Same as Step #1	1 Adjust bottom of T.9 for mini	


2.	Connect a modulated (400 cycle) 41.25mc. signal to the grid, pin 1 of 1st video I.F. Tube 6CB6— V-10.	Same as Step #1.	 Adjust bottom of T-9 for mini- mum response on scope. 	
58	Connect a modulated (400 cycle) 47.25mc. signal to grid, pin 1 of 1st video 1.F. Tube 6CB6 V-10.	Same as Step #1.	 Adjust top of T-9 for minimum response on scope. 	



SYLVANIA ELECTRIC PRODUCTS INC.

CHASSIS 1-514-1, -3, -4 1-520-1, -3, -4, -7, -8

MODELS ALL 105-14, 300 SERIES ALL 120-20, 320, 325, 326 SERIES



PICTURE TUBE INSTALLATION

Picture Tube Replacement

Alignment of the mask and picture tube should not be necessary after normal servicing of the chassis. However, if tube support members have been disturbed during picture tube replacement, observe the following procedure. See Picture Tube Installation illustrations.


- 1. Position tube with face tilted forward about 3 degrees with brackets in approximately normal position. Tighten the following just enough to permit further adjustment in cabinet.
 - (a) Tube holddown strap mounting nuts (21" chassis only).
 - (b) Holddown strap rod or rod nuts.
 - (c) Rear tube mounting rod nut.

 - (d) Yoke mounting wing nuts.(e) Rear tube mounting bracket screws if previously loosened.


HaloLight Tube Replacement


- Remove chassis from cabinet. 1
- Unfasten the nuts that hold the bezel assembly 2. to the cabinet and remove assembly.
- Lay bezel assembly face down on a surface that 3. will not scratch bezel.
- Remove clamps holding light shield and mask to 4 bezel.
- Remove HaloLight plug, and transformer and con-5. trol assembly.


- Remove retaining channels and lift HaloLight 6. shield from assembly.
- 7. Remove tape holding HaloLight tube mounting clips and leads to shield.
- 8. Remove vinyl tubing from ends of tube and carefully lift tube from shield.
- 9. Unsolder leads from tube.
- 10. To replace tube, follow the foregoing steps in reverse order. It is important that all tape removed from assembly be replaced to minimize dust collection on picture tube face.





M	IOST	Г-ОF	TEN	-NEEI	DED	19	54 1	relev	ISIO	N SEI	RVICIN	IG INFORMATION
				SYLVA	NIA C	has	sis I	1-514 a	nd 1-	520, co	ntinued	
		VI	DEO	IF, 4	.5M	C	TRA	AP AN	ND S	SOUN	d ali	GNMENT
BEFC	ay chassi: hassis adj	MPTING s on side ustments.	ALIGNMEN: with H.V.	READ CAR F. supply down fo less otherwise	r under-	Use priiron c driver: Receiv	roper no ores wit s may be er should	h hex holes used for core:	or slots. s adjusted b r approxima	ols for powder Metallic scre y brass screw ately 15 minut	s. Set Fringe	to IF Alignment, when indicated, raise shield or/Mixer tube so ground contact is broken. (AGC) switch to maximum counterclockwise 1-514-3, 1-514-4, 1-520-3, 1-520-4 and
TEP		GENER/	ATOR Freq.	SWEEP G	ENERATOR ion Fr		VTVN CONNEC		OSCOPE ECTION	ADJUST	OUTPUT READING	COMMENTS
	To raised on Osc./M							diode load R147-4.7K.		L54 (Top Core)	Min.	Set VHF tuner to free channel. Apply -3V. between C130 - 22 Mfd. and chassis. Use sufficient output for satisfactory reading.
2.	Loosely co	ouple mark Point "B"		D 1-520-7 ONL Looker Point VHF tuner.	"B" on 43	3. 25 MC 0 MC weep	IF Amp. thru de- tector circuit.			L54 (Bot. Core); T2 (VHF tuner)	Response curve shown in Fig. A.	Remove AGC voltage. Disconnect T55 pri- mary lead from pin 5 of V1 - 6CB6; con- nect 330 Ohm resistor in its place (from R128 - 1K to pin 5 of V1). Lower Osc. /Mix. tube shield to normal position. On chassis 1-514-1 and 1-520-1 and -7, set VHF tuner to any free high channel;
	CHASSIS Loosely co to pin 5, 6 in VHF tu	ouple mark 3J6 thru h	ker 42 1 8	520-3, 1-520-4 Pin 5, 6J6 th in VHF tuner.	ru hole 4	ONLY: 3.25 MC 0 MC weep		Pin 5 of 1st IF Amp. th tector circuit	iru de-	L54 (Bot. Core); L8 (VHF tuner); L53	Response curve shown in Fig. C.	on chassis $1-514-3$, $1-514-4$, $1-520-3$, $1-520-4$ and $1-520-8$, set VHF tuner between any two channels. L53 controls width of curve on $1-514-3$, $1-514-4$, $1-520-3$, $1-520-4$ and $1-520-8$ chassis.
3.	Repeat ste	ep 2 until	curve is f	lat with 42.1 M	C and 45.7	75 MC	markers	on corners. I	REMOVE 33	0 OHM RESIST	FOR AND REC	ONNECT T55 before proceeding with step 4
	To raised on Osc./M							liode load R147-4.7K.		L55 4th Video IF trap.	Min.	Set VHF tuner to free channel. Apply -3V. between C13022 Mfd. and chassis. Use sufficient output for satisfactory reading.
5.	Same as 4	4	47.25 MC			_	Same as	4		T56 (Top Core)	Min.	Same as 4
6.	Same as 4	1	41.25 MC		- -	_	Same as	4]	T55 (Top Core)	Min.	Same 28 4
7.	Same as 4		44.0 MC		- -		Same as	4		T58	Max.	Same as 4. Reduce signal generator output to keep VTVM reading between 1 and 2 volts.
8.	Same as 4	4	42.0 MC			_	Same as	4	_	T 57	Max.	Same as 7
9.	Same as 4	4	45. 2 MC				Same as	4		T56 (Bot. Core)	Max.	Same as 7
10.	Same as 4	1	43.2 MC				Same as	4 _		T55 (Bot. Core)	Max.	Same as 7
11.	Repeat st	eps 4 to 6	inclusive.	1								
12.	ker to rai	ouple man sed tube Osc./Mix	MC	To raised tube on Osc. /Mixe	r tube. 43	3.25 MC 0 MC weep		Across diod sistor R14 with 33K r series with lead.	7 - 4.7K esistor in	T58 T57 T56 (Bot. Core) T55 (Bot. Core)	Response Curve shown in Fig. B	Same as 4. Use low signal input and high scope gain. Retouch T58, T57, T56 and T55 adjustments slightly to obtain response curve shown.
		SCRIMINA		(NOT NECESSAR IS USED VIDEO IF D	ON SCOPE)	D LEAD	DPE L5 (TO 39.7 M(1-514	LIMC.		42.1A SOUND 41.25M VIDEO	70%	42.163 5MC. 25MC. 1-514-3, 1-514-4, 1-520-3, 1-520-4, 1-520-3, FIGURE C
	,							4.5M	<u>C TRA</u>	<u>P ALIGN</u>	MENT	
		STEP	SIGNAL GE Connecti			VM CO Probe	ONNECTI	ONS Ground Lead	ADJUST	OUTPUT READING	- 6-	COMMENTS
11	50		o Pin 2 of 12 ideo Amplific		RF Probe Cathode (F Picture Tu	Pin 11)		To chassis.	L61	Min.	Short Pin 1 of	f V4-6CB6 4th Video IF Amplifier to Chassis.













MC	ST-OF			NEEI A Chas			4 TE								IG INFO		ATI	<u>on</u>
PROCEDURES	 Allow receiver to warm up for approximately 15 minutes before proceeding with alignment. NOTE: During Video IF Alignment, when indicated, raise shield on Oscillator-Mixer tube so that ground contact is broken. 		COMMENTS	Set Tuner to free channel. Apply -12 V. between junction of R137 and C131 and chassis. Use sufficient output for satis- factory readings.	Remove AGC voltage. Disconnect T55 pri- mary from pin 5 of V3 6CB6; connect a 330 ohm resistor in its place. Lower OscMix- er tube shield. Set VHF tuner between any two channels. L54 controls width of curve.	CT T55 before proceeding with step 4.	Set Tuner to free channel. Apply -12 V. between junction of R137 and C131 and chassis. Use sufficient output for satisfactory readings.	Same as 4	Same as 4	Same as 4. Reduce Sig. Gen. output to keep VTVM reading between 1 and 2 Volts.	Same as 7	Same as 7	Same as 7		Same as 4. Use low signal input and high scope gain.		COMMENTS	Short Pin 1 of V6 6CB6 4th Video IF Amplifier to Chassis
NT PR	5. Allow red before p NOTE: Duri shield on Os broken.		OUTPUT READING	Min.	Response Curve shown in Fig. A	ND RECONNEC	Min.	Min.	Min.	Max.	Max.	Max.	Max.	1	Response Curve shown in Fig. B		сом	ı Video IF Amp
GNMEI	leads short. wedered iron trew drivers		ADJUST	L53 (Top Core)	L53 (Bot. Core), L8 (Tuner), L54	330 OHM RESISTOR AND RECONNECT	L55 4th Video IF trap.	T56 (Top Core)	T55 (Top Core)	T58	T57	T56 (Bot. Core)	T55 (Bot. Core)		T58 T57 T56 (Bot. Core) T55 (Bot. Core)			of V6 6CB6 4th
AND SOUND ALIGNMENT	When constructing detector circuit keep leads short. Use proper insulated alignment tools for powdered iron cores with hex holes or slots and metallic screw drivers for those cores adjusted by brass screws.	ALIGNMENT	OSCILLOSCOP E		Plate Pin 5 of V3 6CB6 through Detector Circuit. See "Comments"	REMOVE									Across Diode Load Res. R152 3. 3K with 33K resistor in series with hot scope lead.	ALIGNMENT	DNG	
SOL	ructing dete insulated al ex holes or ires adjuste			Load 3K	<u>р</u> р <u>а</u> й	rs on corner	Load 3K								Acr R15 resis	TRAP AI	IST READING	1 Min.
	When const Use proper cores with h for those co	VIDEO IF	VTVM CONNECTION	Across Diode Load Res. R152 3.3K		45. 75 MC markers on corners.	Across Diode Load Res. R152 3.3K	Same as 4	Same as 4	ame as 4	ame as 4	ame as 4	Same as 4			U W		isis L61
RAP	FULLY 3. 4. tments. stated.		ror Freq.		r 43. 25 MC 10 MC Sweep	and		Ø	<u></u>	33	ø.	- S	S		43. 25 MC 10 MC Sweep	4.5	TTONS Ground 1	To chassis
VIDEO IF, 4.5MC TRAP	ALIGNMENT INSTRUCTIONS - READ CAREFULLY ORE ATTEMPTING ALIGNMENT. Lay chassis on side for under chassis adjustments. Ground all test equipment unless otherwise stated.		SWEEP GENERATOR Connection		Through Hole in tuner cover to Pin 5 of 616	Repeat step 2 adjustments until curve is flat with 42.1 MC									To raised tube shield on OscMixer		VTVM CONNECTIONS RF Probe Gro	RF Probe connected to Cathode (Pin 11) of Picture Tube
Η	RUCTIONS ALIGNM de for u quipment		TOR Freq.	39.75 MC	45.75 MC MC MC MC	nts until c	41.25 MC	47.25 MC	41. 25 MC	44. ⁰ MC	42.0 MC	45.2 MC	43. 2 MC	clustve.	41.25 42.1 42.1 45.75 45.75 47.25 MC		TOR Freq.	4.5 MC
VIDEO	FORE FORE Lay Grour		SIGNAL GENERATOR Connection	To raised tube shield on Osc Mixer	Loosely couple marker to control grid(pin 5) of 616 Osc Mixer through hole in Tuner Cover.	Repeat step 2 adjustme	To raised tube shield on Osc Mixer	Same as 4	Same as 4	Same as 4	Same as 4	Same as 4	Same as 4	Repeat steps 4 to 6 inclusive.	Loosely couple mar- ker to raised tube shield on OscMixer		SIGNAL GENERA Connection	To Pin 2 of 12BY7 4 Video Amplulier
16	56 56		STEP	-i	~	3.	4	5.	ø	7.	æ	.6	10.	11.	12.		STEP	





Westinghouse


Models <u>H-765T17</u>, <u>H-766T17</u>, <u>H-810T17</u>, Chassis <u>V-2240-1</u>, <u>V-2240-2</u>, and

MODELS CONTAINING ALL-CHANNEL UHF TUNERS

When the letter "U" appears in the model number, it indicates that the receiver cantains an allchannel UHF tuner in addition to its VHF facilities. Far example, Model H-770TU21 is the same as Model H-770T21 except that an all-channel UHF tuner has been added to it.

The service material and alignment information presented on pages 169 to 171, applies to all models listed above. Separate circuit diagrams for Chassis V-2240-1 and -2 (pages 172-173), and for Chassis V-2243-1 (on pages 174-175), are printed since these diagrams differ in some respects. Refer to correct material.

The following additional Models <u>H-782K21</u>, <u>H-783K21</u>, <u>H-784K21</u>, <u>H-785K21</u>, <u>H-791K21</u>, <u>H-792K21</u>, using Chassis <u>V-2247-1</u>, and Models <u>H-788C21</u>, <u>H-789C21</u>, <u>H-790C21</u>, <u>H-794C21</u>, using Chassis <u>V-2249-1</u>, are similar to Chassis <u>V-2243-1</u>, and differ mainly in the Sound I.F. and Audio sections. Models <u>H-795T27</u>, <u>H-815T24</u>, and <u>H-817K24</u>, using Chassis <u>V-2250-1</u>, are also similar to V-2243-1, with the main differences in the Power and Sweep sections.



Westinghouse Electric, Television Chassis V-2240-1, V-2240-2, V-2243-1

Α

ALIGNMENT CHARTS

COMMON I-F SECTION

Rotate the channel selector to channel 13.

Connect the oscilloscope to the video test terminal, point "B" through the decoupling network shown in Fig. 2.

Connect a 9 volt bias battery to the AGC line, point "A"

Couple the n_{i-} ker generator output to the sweep generator output. In the steps that follow, use the marker to check the response curve at the frequencies indicated on Fig. 6.

Step	Alignment Signal	Remark s	Adjust —
1.	Remove the 6BZ7	R-F amplifier tube	
2.	44 mc. sweep to 3rd I-F grid	Connect detuning clips to 1st & 2nd I-F plates	Pri, of T302 for max, re- sponse and sec, of T302 for symmetrical curve shown in Fig. 6A
3.	47.25 mc. ampli- tude modulated to 1st 1-F grid	Use sufficient signal to produce sine wave response on oscillo- scope	L302 for min, response
4.	44 mc, sweep to 2nd I-F grid	Connect detuning clip to 1st I-F plate	Pri, of T301 for max. re- sponse and sec. of T301 for symmetrical curve shown in Fig. 6B
5.	44 mc. sweep to 1st I-F grid	Detune L103 before ad- justing T300	Pri. of T300 for max. re- sponse and sec. of T300 for 'symmetrical curve
6.	44 mc. sweep to 1st I-F grid		L103 for "suck-out" at 44 mc. (center of curve). See Fig. 6C
7.	Replace the 6BZ7	R-F amplifier tube	
8.	213 mc, sweep to antenna term- inals through network	Fine tuning set to mid- range	L300 for symmetrical curve and L301 for min. 41.25 mc. marker am- plitude. See Fig. 6D





FIG. 6 – RESPONSE CURVES AT VARIOUS STAGES OF ALIGNMENT

4.5 MC. TRAP

Connect the signal generator to pin #3 or #7 of the 6BK5 video amplifier (point "B") through a .001 mfd capacitor.



Westinghouse Electric, Television Chassis V-2240-1, V-2240-2, and V-2243-1 Alignment Information, continued. Sound Section.

The sound system can be aligned using either locally generated signals or a received TV signal. Since the latter method does not require signal generating equipment, it will be described first and will be followed by the procedure using locally generated signals.

To use an "air" TV signal for alignment:

1. Tune the receiver to a TV station and connect an attenuator between the receiver and the antenna so that the strength of the signal can be varied from weak to strong.

2. Set the quieting control (R202) located on the back of the chassis approximately to its mid-position.

3. Adjust the 4.5 mc. IF slug (L200) for maximum program sound. If peaks occur at two different positions of the slug, use the peak that occurs when the slug is farthest counterclockwise. Reduce the signal to its lowest usable level and recheck the adjustments.

4. Apply a strong signal to the receiver, and adjust the quadrature coil (L202) for maximum program sound. If peaks occur at two different positions that are widely separated, use the one that occurs with the slug farthest counterclockwise. If two peaks occur within a narrow range of adjustment, sufficient signal is not being applied to the receiver of the quieting control is not set at the desired position.

5. Apply a very weak signal that allows noise to be heard and adjust the quieting control (R202) for minimum noise. The position at which

To avoid scratching or chipping the cathode ray tube, the speaker and baffle should be removed before attempting to remove the chassis from the the noise is minimized depends on the strength of the signal; therefore, the weakest usable station in the area should be used for this adjustment. This control determines the AM rejection characteristics of the sound system, and its correct setting is normally about mid-position. Do not leave the quieting control set at its maximum counterclockwise position.

To use locally generated signals for alignment:

1. Connect an oscilloscope or an AC voltmeter across the volume control for use as an indicator.

2. Apply a 4.5 mc. FM signal (deviation approximately 7.5 kc.) to pin #3 or #7 of the 6BK5 video amplifier.

3. Using the lowest signal level that will produce an indication, adjust L200 for maximum output.

4. Using a *strong* signal, adjust L202 for maximum output.

5. Apply a 4.5 mc. AM signal (modulated approximately 30 percent) to pin #3 or #7 of the 6BK5 video amplifier.

6. Beginning with a very low signal level, increase the generator output, while rotating the quieting control back and forth, until the signal level is such that the AM output across the volume control dips to zero with a rise on each side as the quieting control is rotated. Set the quieting control for zero output at this signal level.

CHASSIS REMOVAL

cabinet. To release the speaker and baffle from the cabinet, remove the four No. 6 Phillips-head screws from the top of the cabinet.

CRITICAL LEAD DRESS

All leads located near the horizontal multivibrator trimmer capacitor, C430, must be dressed away from the capacitor and close to the chassis.

All resistors rated above one watt must be dressed away from each other and clear of other components and wires. Video peaking coils should be dressed away from the chassis and clear of adjacent parts.

All leads in the high voltage unit must be dressed away from the high voltage transformer to prevent arcing.


Keep all leads in the I-F and video circuits as short as possible.

REFLECTION ELIMINATION


Light reflection from the pilot lamp can appear on the lower right hand corner of the CRT unless preventive measures are taken. To eliminate the reflection, a piece of electrical tape $(1^m \times 6^m)$ is applied to the edge of the lower right corner of


the CRT face.


When replacing a CRT, the electrical tape must be applied to the new tube in the same manner as it was applied to the old tube.



MODEL H-765T17 H-766T17 H-810T17








Westinghouse Electric Corporation

Models H-736T17 and H-738T17 Chassis Assembly V-2227-1 Although this circuit differs in important respects from the sets covered in last year's volume, the alignment information given on page 184, Volume TV-7, 1953 Television Manual, applies exactly to this additional chassis, V-2227-1.





CHASSIS NO. V 2227-1


SECTION 4

SWEE

6BQ6GT PLATE CURRENT REDUCTION. To reduce the plate current of the 6BQ6GT horizontal output tube and thus prolong its life, R499 was increased to 39,000 ohms.








WESTERN AUTO SUPPLY COMPANY

Models 2D1331A, 2D1345A, 2D2334A (2D1336A is similar) continued from pp 178-179



A. Unmodulated R-F signal into Converter Grid by means of tube shield insuloted from bose. VTVM with filter in lead of 22 K ohms and 5000 mmf connected to pic. det. load resistor, (R-100) 4700 ohms, in series with peaking coil (L-6) from Pin 7 of 6AL5. Input signol level should be such that output is less thon 2 volts DC. Apply -4.5V battery bias on AGC line.

FREQUENCY

ADJUST

- 1. 25.2 MC Converter plote coil on top of tuner for maximum dc at picture detector.
- 2. 23.1 MC 1st picture I-F coil (T-1) for maximum dc at picture detector.
- 3. 25.9 MC 2nd picture I-F coil (T-2) for maximum dc ot picture detector.
- 24.1 MC 3rd picture I-F coil (T-3 below chassis) for maximum dc at picture detector.
- 5. 21.7 MC 3rd picture I-F trap (T-3 in con above chassis) for minimum dc ot picture detector.
- B. I-F Sweep Generator into converter grid by means of tube shield insulated from base.


Connect oscilloscope ocross R-100 (in place of VTVM). Apply -4.5V bias (DC) to AGC line (battery).

Tuner should be switched to dead channel so as not to couse interference.

Observe overall I-F response, which should be as shown above: A slight touch-up may be required. At no time should the trap coil be re-adjusted, nor should it be necessary to turn any of the picture I-F coils more than 1/2 turn of the slug. The following comments are suggestions only:


- 1. The height of the 26.2 MC marker is controlled by the 25.2 MC (Converter Plate Coil on tuner) and the 25.9 MC (2nd P.I.F.) coils.
- The uniformity of response (flatness across top ond position of 23.5 MC) morker is controlled for the most part by the 24.1 MC third picture I-F coil.
- 3. The 23.0 MC marker position is controlled by the first picture I-F (23.1 MC coil). However, it is not odvisable to change the setting of the coil, due to its effect on sound rejection.

ALIGNMENT PROCEDURE



Bottom Chassis Video and Audio I-F Adjustments VIDEO


With 4.5 MC unmodulated signal from a high impedance sawce, (10,000 ohms in series with the generator) into plate af the picture detector tube (Pin 7-6AL5) and VTVM on picture tube grid, tune 4.5 MC trap (L-7 Top) for minimum response. VTVM on 0-10 V AC scale. This adjustment can also be made while observing a picture from a station. Tune trap for least 4.5 MC beat in picture.



AUDIO I-F

- With signal generator set to 4.5 MC and dc VTVM connected to junction of R-62 and C-46, adjust sound take-off coil (L-13 Top) and sound I-F transformer slugs (T-6 Top & Bottom) for maximum.
- With VTVM connected to pin 7 of V-12 (6AL5) adjust the ratio detector primary (T-7 Bottom) for maximum.
- With VTVM connected to junction of R-66, R-69 and C-50, adjust ratio detector secondary (T-7 Top) for cross over (zero voltage) on lowest scale.

NOTE-- If no signal generator is available, the procedure above may be followed by tuning in a station and using the 4.5 MC beat between picture and sound carrier.



Zenith "L" Series, continued

INTRODUCTION

The 19L25, 19L26, 19L27, 19L28, 21L21 and 22L20 chassis described in this manual are basically alike. Alignment and adjustment procedures are identical. The slight differences which exist are as follows:

19L25: This chassis utilizes a 17 inch rectangular picture tube and is the basic chassis.

19L26: This chassis is the same as the **19L25** without the screen and tone register controls.

19L27: This is the 19L25 chassis with a 21 inch picture tube.

19L28: This is the 19L26 chassis with a 21" picture tube.

21L21: This chassis is the same as the basic 19L25 chassis except for the 21 inch picture tube and the addition of a 5U4G low voltage rectifier and a 1X2A tube in the high voltage circuit. The 1X2A is used in conjunction with the 1B3GT rectifier to boost the picture tube second anode voltage to 18.5 Kv. This chassis uses a 6CD6 in the horizontal output circuit. PM focusing and centering is utilized.

22L20: This chassis is similar to the 21L21 chassis but has a separate power supply and utilizes either the 24 or 27 inch picture tube. The 12AX7 used as the vertical oscillator in all other "L" chassis is used in the interlace circuit of this chassis. This circuit is designed to utilize the actual vertical pulse for triggering, rather than depending on the voltage build-up across an intergrating network. In this circuit the first of the six serration of the vertical pulse is differentiated, clipped by the 12AX7 (used as a diode) and applied to the 6SN7GT vertical oscillator. By using the actual pulse for triggering, the time relationship between alternate fields remains constant and positive interlacing results. This chassis utilizes the 6AV5GT vertical output and the 6AS4GT damper.

All models have provisions for reception of the new Ultra High Frequency stations by the simple addition of UHF strips as required.

THE FRINGE LOCK CIRCUIT

The fringe lock is a newly developed circuit, utilizing a 6BE6 heptode, which can be adjusted to assure sync stability over the wide range of noise and signal levels encountered in different areas. In this circuit the output of the crystal detector, approximately -3 volts peak to peak, is fed to grid #1 of the 6BE6. The same signal, after it has been inverted and amplified to approximately 40 volts peak to peak by the first video amplifier, is applied to grid #3 which in this circuit is the signal grid. The fringe lock control is used to pre-set the bias on grid #1 so that the normal 3 volt signal allows proper sync clipping action, i.e. the sync



pulses, which have been stripped from the composite video signal appearing at grid #3, will appear at the plate. If a noise pulse drives grid #1 beyond the 2 volt level, plate current cutoff occurs and the noise pulse cannot get through to falsely trigger the sweep oscillators. On rare occasions, a strong noise pulse may occur at the time of the sync pulse and the tube likewise will cut off, however, the flywheel action of the sweep oscillators will maintain sync during this brief period. The entire fringe lock system is based on the fact that the loss of an occasional sync pulse is to be preterred over having a noise pulse get through to falsely trigger the sweep oscillator.

FRINGE LOCK ADJUSTMENT

1. Turn the fringe lock control fully clockwise and then back it off approximately 1/4 turn. Adjust the vertical and horizontal hold controls and check operation of the receiver to see that it syncs normally when the turret is switched from channel to channel.

2. If the picture jitters or shows evidence of delay, tearing, split phase, etc., back down the fringe lock control further, a few degrees at a time, each time readjusting the hold controls and switching from channel to channel until normal sync action is obtained. It will be found that under normal signal conditions, the correct adjustment will be near the counterclockwise position of the control.

3. In fringe and noisy areas, the best adjustment will be found at or near the maximum clockwise position of the control, however, do not automatically turn the fringe lock fully clockwise in fringe areas as has been done on previous models. Always follow the procedure outlined.

CENTERING ADJUSTMENT

In the 19L series, the centering assembly is built into the yoke housing. This assembly is made up of two magnetic rings which can be rotated by means of tabs. Centering is accomplished by gradually rotating the tabs with respect to each other then rotating both tabs simultaneously until the picture is centered.

In the 21L and 22L series, PM focusing and centering is utilized. The top screwdriver adjustment on the centering assembly is used to move the picture up or down and the bottom adjustment for side to side movement. The center adjustment is for focusing.

In some 21L and 22L receivers, a single centering lever is used for both vertical and horizontal centering. The up down movement of this lever moves the picture horizontally while a left-right movement moves the picture vertically. A screwdriver adjustment is provided for focusing.

AFC ADJUSTMENT

The AFC adjustment can effectively be made by setting the horizontal hold control L26 to a position where it is virtually impossible to "throw" the receiver out of horizontal sync when switching from channel to channel.

BULLS EYE TUNER ADJUSTMENTS

To adjust the receiver for bulls-eye tuning, set the fine tuning control to its approximate center position as shown in Fig 2. Without further adjustment of the fine tuning control insert a 68-21 alignment wrench into the tuner (See Fig.11) and adjust each operating channel to resonance. It will be noted that tuning to one side of resonance results in a faded, washed-out picture with the spacing between the wedge lines fogged and tuning in the opposite direction causes the spaces between the lines to clear up. However, going beyond this point causes the picture to take on a "wormy" appearance from sound getting into the picture. Correct adjustment is obtained by tuning to the "wormy" picture and then backing the control off slightly until the picture clears up.




Fig. 11 Bulls-eye Tuning Adjustment.

REMOVING TURRET TUNER

1. Pull out the power and IF connector cables and disconnect the antenna transmission line.

2. Look through the U shaped opening in the top of the tuner and rotate the fine tuning control until the allen head set screw (or paint mark on some tuners) is straight up.

3. Loosen (do not remove) the hex head set screw in the turret dial cord pulley assembly.

4. Slide the pulley towards the front of the chassis until it clears the fine tuning shaft.

5. Remove the four hex nuts and gently pull the tuner assembly straight out of its case.

REMOVING CHANNEL STRIPS

1. To insure proper indexing, carefully note the channel to which the receiver is tuned so that the tuner drum can be rotated back to this channel before the unit is reassembled. Zenith "L" Series, continued

2. Rotate the turret drum until the strip to be removed is readily accessible.

3. Insert a small screwdriver in the slot (See Fig.13). Push in the direction of arrow until the channel strip clears the drum slot then lift straight out in direction of screwdriver shaft. Some strips have a round hole instead of a slot and a pointed tool is used in place of the screwdriver.

CAUTION: TO AVOID DAMAGE TO CHANNEL STRIPS, DO NOT USE PRYING ACTION IN REMOVING STRIPS.




Fig. 13 Removing Channel Strips.

REMOVING TURRET DRUM ASSEMBLY

1. Use long nose pliers and remove the two turret shaft tension springs from the front and rear of the tuner assembly. Unsolder and slide the bronze turret shaft grounding springs out of their slots at the front and rear of the tuner.

2. With a pair of long nose pliers, grasp the first turn of the spiral index spring and lift spring off its hook. This takes pressure off the detent arm and may cause the roller to fall out and become lost.

3. Slide the drum out of its slot. Reverse this procedure to re-assemble the tuner.

Some of the component parts in the tuner cannot be replaced without removing the fine tuning control and bracket assembly. This bracket can be removed as follows:

1. Unsolder the fine tuning capacitor lead.

2. Loosen the Allen head set screw on the fine tuning shaft collar and remove fine tuning shaft.

3. Remove the self tapping screw from the center top of the tuning capacitor mounting bracket, loosen the three remaining screws and remove the bracket.



Zenith "L" Series, continued

DOUBLE DELAYED GATED AGC

In order to obtain the best possible performance in fringe and weak signal areas, it is important that the application of AGC voltage to the 6BK7A RF tube be withheld until the signal level reaches approximately 500 microvolts at the antenna input. The noise figure of the tuner will be optimized only under this condition of no AGC voltage. To accomplish this, the cathode of the 6CB6 1st IF tube is approximately 8 volts positive by virtue of the drop through the cathode resistor of the 6CB6 3rd IF. This voltage plus the voltage which results from current flow through the tube makes the grid of the 6CB6 1st IF approximately 9.3 volts negative with respect to its cathode. It should be noted here that the bias voltage for the 3rd IF is obtained across the 100 ohm portion of the cathode resistor only. The voltage at the junction of the two resistors varies from 8 volts with no signal to 4 volts with strong signals. The 2nd IF tube is in series with the 1st IF tube and any changes in the plate current of the 1st IF tube will also change the 2nd IF tube thus the 2nd IF tube is also controlled indirectly by the AGC.

Under weak signal conditions, the output of the AGC tube at point "E" is approximately 8 volts positive. This positive voltage however, does not reach the grid of the 6BK7A because of the 2.2 megohm resistor. Actually the grid of this tube is slightly negative because of contact potential developed as a result of the high resistance in its grid circuit (2.2 megohms). The 8 volts positive voltage however, is applied to the grid of the 6CB6 1st IF but because the cathode is 9.3 volts positive the grid is actually 1.3 volts negative with respect to its cathode and AGC control of the IF results under weak signal conditions.

When the receiver is used with normal signals, the signal voltage applied to the grid of the AGC tube will increase and as a result the output of the AGC tube will become 4 to 5 volts negative. This negative voltage will be applied to the 6BK7A through the 2.2 megohm resistor thus both the RF and IF stages will then be controlled by the AGC.

With the application of a negative AGC voltage to the 6BK7A tube under normal signal conditions, the noise figure of the tuner will not be optimized as under weak signal conditions, however, this is not a consideration with normal signal levels.

AGC ADJUSTMENTS

IMPORTANT: THE AGC CONTROL CANNOT BE USED IN ANY WAY TO IMPROVE THE RECEIVER SENSITI-VITY. The sole function of this control is to set the level applied to the video amplifier (12BY7) tube so that the output of this tube is approximately 100 volts peak (100% modulated video signal) for application to the picture tube cathode.



The adjustment can also be made by connecting a calibrated oscilloscope through a 10K isolation resistor, to test point "D" (See Fig.16) and, while receiving the strongest TV signal adjust the AGC delay control for 2.5 volts (2.75V on 19L26 and 28 models) peak output.

Satisfactory adjustment can also be made by observing the picture and slowly turning the AGC delay control from its maximum clockwise position, counterclockwise until a point is reached where the picture distorts and buzz is heard in the sound. The control should then be turned slowly clockwise and set at a point comfortably below this level of intercarrier buzz, picture distortion and improper sync.

CAUTION: Misadjustment of the AGC delay control can result in a washed-out picture, distorted picture, buzz in sound OR COMPLETE LOSS OF PICTURE AND SOUND.




Fig. 15 IF-RF Alignment Fixtures

A suitable sweep generator in conjunction with an accurate marker must be used for alignment work. It is very important to have the sweep generator output cable properly terminated and to check whether or not its attenuator is reactive. If the attenuator is reactive or if the output cable is improperly terminated, correct alignment cannot be made since the degree of attenuation then may change the shape as well as the amplitude of the response curve. The position of the attenuator should only vary the amplitude and not the shape of the response curve.

VIDEO IF ALIGNMENT

1. Connect the negative lead of a 2 volt battery supply to terminal "E" (Fig. 36) and the positive lead to chassis. The bias supply should be made variable so that it can be varied from negative 3 volts to positive 3 volts. Keep the supply leads short.

2. Connect the calibrated oscilloscope through a 10,000 ohm isolation resistor between terminal "D" and chassis. The sweep generator input to the receiver should be adjusted for 3 volts peak to peak detector output. Do not exceed this output level during any of the adjustments.




Fig. 16 IF Alignment Guide.

3. Feed the output from the sweep generator through the special termination unit shown in Fig. 15 to point "C" (Pin 1 of 6CB6, 3rd IF). Adjust the generator until a pattern similar to Fig. 17 is obtained.

4. Set the Marker Generator to 45.75 Mc and alternately adjust the top and bottom slugs of the 4th IF transformer for maximum gain with the 41.25 Mc and 45.75 Mc markers positioned as shown in fig. 17




Fig. 17 4th IF Response.

If the correct response curve cannot be obtained in this step, check the position of the two slugs to see that they are entering their respective coils from the opposite ends of the coil form. The position of the slugs near the center of the coils may change the coefficient of coupling, making correct alignment difficult if not impossible. 5. Connect the sweep generator cable to terminal "A" (Mixer Grid). In this step it may be necessary to temporarily reduce the bias to zero or even to go to a slightly positive voltage in order to see the highly attenuated trap slots with the oscilloscope vertical gain near maximum.

6. Adjust the 47.25 Mc, 41.25 Mc and 39.75 Mc traps for minimum marker amplitude (See Fig.18. It can be seen that maximum oscilloscope gain has been used and as a result the top of the response curve has been "run off" the oscilloscope screen in order to see a "blow-up" of the trap slots.

7. Readjust the bias to -2 volts and set the oscilloscope vertical gain to the calibrated position. Adjust the sweep generator for a 3 volt peak to peak output from the video detector.




Fig. 18 Exploded View of Trap.

Zenith "L" Series, continued



Fig. 19 Overall IF Response.

8. With the test equipment set up as in Step 7, alternately adjust the 2nd IF, 3rd IF, 1st IF and the converter plate coil until an overall response curve similar to Fig19 is obtained. It will be found that the 2nd IF affects the low side (42.75 Mc) and the 3rd IF the high side of the response curve. If the proper response curve cannot be obtained by an alternate adjustment of the above trimmers, it may be necessary to retouch the 4th IF transformer.

SOUND ALIGNMENT

Proper alignment of the 4.5 Mc intercarrier sound channel can only be obtained if the signal to the receiver antenna terminals is reduced to a level below the limiting point of the 6BN6 Gated Beam Detector. This level can be easily identified by the "hiss" which then accompanies the sound.

Various methods may be used to reduce the signal level, however, it is recommended that a step atten-

uator similar to the S-17203 unit be used for most satisfactory results. To prevent leakage, certain precautions must be taken when connections are made. Use as short a lead as possible between the attenuator and receiver antenna terminals and approximately 6 feet of 300 ohm shielded line between the antenna transmission line and the attenuator. The shield from the transmission line should be connected to the attenuator and the attenuator itself grounded to the TV chassis under test.

After the connections have been made, proceed as follows:

1. Tune in a tone modulated TV signal and adjust the step attenuator until the signal is reduced to a level where "hiss" is heard with the sound.


2. Adjust the sound take-off coil L19 (top and bottom slugs), intercarrier coil L22, quadrature coil L23 and buzz control R39 for the cleanest sound and minimum buzz. It must be remembered that any of these adjustments may cause the "hiss" to disappear and further reduction of the signal will be necessary so that the "hiss" does not disappear during alignment.


If intercarrier buzz is in evidence, after all normal sound adjustments have been made, the cause may be attributed to one or more of the following:


- 1. Improper adjustment of the AGC delay control.
- 2. Defective 6AU6 sound limiter.


3. Extremely high signal levels which require attenuation in the antenna circuit.


4. Transmitter over modulation.











Signal Path Chart 19L Series Receivers.

This signal path chart can be used for quickly isolating the particular section of the receiver where trouble is suspected. As an example, if the set under test has video but no sound, the chart will indicate that the sound signal alone is handled by V8 and V9, and so the trouble must lie in one of these sections. The AGC tube (V10A) affacts both picture and sound. In using this chart reference should be made to the main circuit shown on pages 187 and 188-189.

190

Index

Under each manufacturer's name are listed that make chassis and models in numerical order, at left. The corresponding page number at right of each listing refers to the first page of each section dealing with such material.

Admiral Cor	₽ <u>-</u> ,_	Arvin (cont.	-	Emerson (con	it.)	Motorola (co			
19A2	15	TE364	19	120182D	45	21F2FY,-Y	69	TS-292AY	69
19B2	15	9210	19	120185B	37	21F3BD	69	TS-292B	69
19D2	15	9212	19	120190D	37	21F3BDY	69	TS-292C	69 60
19E2	15 15	9216	19	120191D	37	21F3BY,-D	69	TS-292CY	69 60
1951		9218	19	120192B	37	21F3DY,-Y	69	TS-292Y	69 60
19 L1	15 15	9219 9240	19 19	120192D	37	21F5B	72 69	VTS-292B	69 69
19P1 19 S1	15	9240	19	120195D	45	21K4AY,-BD	69	VTS-292BY	69
22F2	5	<u>Crosley Cor</u> p		120196B	45	21K4BDY	69	VTS-292C	69
22G2	5	F-17COBH	23	120197B	45	21K4BY,-C	69	VTS-292CY VTS-292Y	69
22M2	5	F-17COBU	23	120197D	45	21K4CB 21K4CBY	69	WTS-2921	69
22N2	5	F-17COMH	23			21K4CW	69	WTS-292B,-B	
22P2	5	F-17COMU	23	General-Elec		21K4CWY	69	WTS-292C,-C	
22R2	5	F-17TOBH	23	EE	47	21K4CY,-D	69	WTS-2920,-03	69
121UDX12	15	F-17TOBU	23	210225	47	21K4DY,-WD	69	TS-402	72
122DX12	5	F-17TOLBH	23	210333	47	21K4WDY	69	TS-402Y	72
122UDX12	5	F-17TOLBU	23	2117	47	21K4WY,-Y	69	VTS-402, -Y	72
221UDX16L	15	F-17TOLH	23	2178	47 47	21K5BD	69	TS-502	72
221UDX17L	15	F-17TOLU	23	21720		21K5BDY	69	TS-502Y	72
222DX15B	5	F-17TOMH	23	21721	47	21K5BY,-D	69	TTS-502,-Y	72
222DX16B	5	F-17TOMU	23	No.7.74 amo étam		21K5DY,-Y	69	VTS-502,-Y	72
222DX17B	5	F-21CDBH	23	Hallicrafter	53	21K6D,-DY	69	WTS-502,-Y	72
222DX27B	5	F-21CDBU	23	21K200B		21K6Y	69	TS-602	63
222UDX15	5	F-21CDLBH	23	21K201B	53			TS-602Y	63
222UDX16	5	F-21CDLBU	23	21K210M	53	21K7D,-DY	69 60	10-0001	00
222UDX17	5	F-21CDLH	23	21K211M	53	21K7Y	69 69	Muntz TV	
321UDX15L	15	F-21CDLU	23	21K220B	53	21K9, -Y	69 69	17B1	77
321UDX16L	15	F-21CDMH	23	21K221B	53	21K10	69 60	17B2	77
322DX16A	5	F-21CDMU	23	21K230M	53	21K10B,-BY	69 60	17B3	77
322UDX16	5	F-21COBH	23	21K231M	53	21K10Y	69 69	17B4	77
TU1811	15	F-21COBU	23	24K240B,-M	53	21K11, -B	69 69	17B5	77
TU1812	1 5	F-21COLBH	23	24K241B,-M	53	21K11BY,-Y	69 70	17B6	77
TU1822	15	F-21COLBU	23	27K250B,-M	53	21K12A,-AB	72	3742	77
TU2212	15	F-21COLH	23	27K251B,-M	53	21K12WA	72	317T2	77
C2215	15	F-21COLU	23	A1400D	53	21K13	72	321T1	77
CU2215	15	F-21COMH	23	B1400D	53	21K14, -B	72	321T2	77
T2215	15	F-21COMU	23	C1400D	53	21K15	72	2053-A	77
TU2215	15	F-21TOBH	23	D1400D	53	21K16, -W	72	2054-A	77
C2216	15	F-21TOBU	23	Uoffman		21K17	72 69	2055-A,-B	77
CU2216	15	F-21TOLBH	23	Hoffman 7722 42	59	21T4ACY	69 69	2056-A	77
H2216	15	F-21TOLBU	23	7B141		21T7, -B		2158-A	77
HU2216	15	F-21TOLH	23	7M140	59 59	21T7BY,-Y	69 72	2159-A	77
K2216	15	F-21TOLU	23	21B144,-U	59	21T8A,-AE	72	2162-A	77
KU2216	15	F-21TOMH	23	21B318,-U 21B719,-U	59	21T11, -B 21T11W	72	2457-A	77
T2216	15	F-21TOMU	23	21M143,-U	59		72	2461-A	77
TU2216	15	402, 402-1	23	21M317,-U	59	Y21C2,-B	72		
C2217	15	403, 403-1	23	21M317,-U	59	Y21F5, -B Y21K12A	72	Olympic Radi	io
CU2217	15	404, 404-1	23		59	Y21K12AB	72	17057	83
H2217	15	405, 405-1	23	21M718,-U 21P145,-U	59	Y21K12WA	72	17K55	83
HU2217	15	410, 410-1	23	21P720,-U	59		72	17K101	83
K2217	15	-	~	300-17	59	Y21K13,-B	72	17T56	83
KU2217	15	Du Mont Labs		300-21	59	Y21K14,-B Y21K15	72	TM-17	83
T2217	15	RA-306	31	500-21	05	Y21K16,-W	72	21065	83
TU2217	15	RA-307	31	Motorola, In		Y21K17	72	21068	83
T2218	15	Emerson Radi	0	17K17,-B	72	Y21T8A, -AE	72	21072	83
TU2218	15	732G	37	17T15A,-AE	72	Y21T11,-B	72	21073	83
TU2222	15	741F	45	17T16,-B	72	Y21T11W	72	21D60	83
TU2226	15	742E	37	Y17K17,-B	72	24K1, -B	63	21D64	83
C2236	15	757D	45	Y17T15A,-AE	72	24K2, -B	63	21K61	83
CU2236	15	760D, 760H	37	Y17T16,-B	72	24K3, -W	63	21K62	83
C2237	15	762D	37	21C1BD,	69	Y24K1,-B	63	21K63B	83
CU2237	ī5	767	37	21CIBDY	69	Y24K2,-B	63	21758	83
		771A, 771D	37	21C1BY,-D	69	Y24K3,-W	63	21769	83
Arvin Indus	tries	773A	37	2101DY,-Y	69	27K2, -B	63	21770	83
TE358-1	19	781A, 781B	45	2101D1,-1 2102,-B	72	27K2, -B	63	21174	83
TE359	19	784E, 784G	45	2162,-B 21F2F,-FB	69	Y27K2,-B	63	TN-21	83
TE363-1	19	785K	45	21F2FBY	69	Y27K3	63	TNA-21	83
						10,100		,	-


191

Packard-Bell	. 1	Philco, (co	nt.)	Raytheon		Stewart-Warn		Westinghous	e ++
2040	85	R -191 U	98	21T8	127	21T-9300R	143	H-784KU21	169
2041	85	R-192U	98	24T2	127	21T-9300RB	143	H-785K21	169
2042	85	D-194	98	UM-2133A	127	21T-9300S	143	H-785KU21	169
2043	85	R-194	98	UM-2134A	127	21T-9300T	143	H-786K21	169
				UM-2135A		240-9360	143		
044	85	R-194U	102		127			H-786KU21	169
2141	85	D-201	105	UM-2136A	127	240-9370	143	H-787K21	169
142	85	R-201	105	UM-2139A	127	270-9310	143	H-787KU21	169
143, 2144	85	D-202	105	UM-2141A	127	270-9350	143	H-788C21	169
•		R-202	105	UM-2142A	127			H-788CU21	169
hilco Corp.		D-204	105	UM-2144A	127	Stromberg-		H-789C21	169
8B3000	96	R-204	105	UM-2145A	127	Carlson		H-789CU21	169
8BU3000	96	N=204	103		127	621A	153		
8B3001	96	RCA Victor		UC-2403A		622	153	H-790C21	169
			115	UC-2404A	127			H-790CU21	169
8BU3001	96	178349	115	UC-2405A	127	624, -RP	153	H-791K21	169
	102	17S350,-U	115	UC-2406A	127	625 , - RP	153	H-791KU21	169
	102	17 8 351,-U	115					H-792K21	169
8B3100	96	1783520	115	Sentinel Ra	othe	Sylvania El	ect.	H-792KU21	169
8BU3100	96	178360,-U	115	500	135	1-514-1	159		
	102	178361,-U	115			1-514-3	159	H-794C21	169
				510	135			H-794CU21	169
	102	17T301,-U	115	511	135	1-514-4	159	H-795T27	169
	109	17T302,-U	115	512	135	1-518-1	164	H-795TU27	169
8BU3104	109	17T310,-U	115	513	135	1-518-2	164	H-810T17	169
8B3408	102	21D305,-U	121	515	135	1-518-3	164		
	102	21D317,-U	121			1-520-1	159	H-810TU17	169
2B4000	96		121	532	135			H-815T24	169
		21D326,-U		542	135	& -3,-4,-7		H-815TU24	169
2BU4000	96	21D327,-U	121	552, 554	135	105-14	159	H-817K24	169
	102	21D328 ,- U	121	562, 564	135	120-20	159	H-817KU24	169
2804002	102	21D329,-U	121	,		175-18	164	V-2240-1	169
2B4004	102	21D330,-U	121	Sponton		300	159		
	102	21D358,-U	121	Sparton		320	159	V-2240-2	169
	109			21S173A	139			V-2243-1	169
		21D368,-U	121	218214	139	325	159	V-2247-1	169
	109	21D376,-U	121	240174	139	326	159	V-2249-1	169
2B 41 00	96	21D377,-U	121	240213	139	372	164	V-2250-1	169
2BU4100	96	21D378,-U	121	240214	139	373	164		
2B4102	102	21D379,-U	121			375	164	Zand the Dad	1
	102	21D380,-U	121	11322A	139	376	164	Zenith Radi	
	102			11324A	139			L Series	181
		21S354,-U	111	15312A	139	377	164	19L25	181
	102	2 18 362,-U	111	15314A	139			19L26	181
	109	21T3O3,-U	115	20312	139	True tone,		19L27	181
2BU4108	109 }	21T313,-U	115	20313	139	Western Aut	•	19128	181
2B4109HM	102	21T314,-U	115	21322, -A	139	2D1330A	- 178	21121	181
2BU4109HM	102	21T315,-U	115						
	109	21T316,-U	115	21324	139	2D1331A	178	22120	181
				31322	139	2D1336A	178	L1812E,-R	188
	109	21T322,-U	115	32324	139	2D1345A	178	L1820E,-R	188
	102	21T323,-U	115	33322	139	2D1352A see	143	L1846E,-R	188
2B4301	96 I	21T324,-U	115	34324	139	2D1353A see		L2229E,-R	188
2B4302	102	21T356Ú	111			2D2334A		1.9935F	
	102	21T363,-U	īīī	35342	139	SUSUSAR.	178	L2235E,-R	188
2B4303	96	21T364,-U	iii	35343	139			L2236E,-R	188
		010265 7		36342	139	Westinghous	e	L2258E,-R	188
2BU4303	96	21T365,-U	111	36343	139	H-765T17	169	L2259E,-R	188
	102	21T372,-U	111	50312	139	H-765TU17	169	L2260R	188
	102	21T373,-U	111	50314	139	H-766T17	169	L2261E,-H	188
2B 43 06	102	21T374,-U	iii	58112		H-766TU17	169	L2262C,-R	
	102	21T375,-U	iii		139				188
	102			58114	139	H-770T21	169	L2266R	188
		KCS-78	115			H-770TU21	169	L2267E,-H	188
	102	KC S- 78B	115	Stewart-War		H-771T21	169	L2270	188
	109	KCS-78F	115	21C-9300E	143	H-771TU21	169	L2281,-E	188
2804308	109	KCS - 78H	115	21C-9300F	143	H-772K21	169	L2281R	188
2B4400W	102	KCS-78J	115	21C-9300G	143	H-772KU21	169	L2285R	188
	102	KCS-81	121	21C-9300K					
	102	KCS-81B			143	H-773K21	169	L2287R	188
			121	21C-9300KB	143	H-773KU21	169	L2291E	188
	102	KCS-81D	121	21C-9300L	143	H-774K21	169	L2571R	188
	109	KCS-81E	121	21C-9300LB	143	H-774KU21	169	L2572R	188
	109	KC S- 81F	121	21C-9300M	143	H-775K21	169	L2573E	188
2B4406	109	KCS-81J	121	21C-9300MB	143			L2574R	188
	102	KCS-82				H-775KU21	169		
	102		115	21C-9300P	143	H-776T21	169	L2575E	188
		KCS-82B	115	21T-9300A	143	H-776TU21	169	L2592R	188
-181	87	KC S - 83	111	21T-9300AA	143	H-782K21	169	L2593H	188
-181	87	KCS-83B	111	21T-9300B	143	H-782KU21	169	L2876E,-R	188
-1810	87	KCS-83C	111	21T-9300D	143	H-783K21	169	L2878R	188
-191	98	KCS-83D	iii	21T-9300H		-			
	~~			211-9300H	143 143	H-783KU21	169	L2879E	188
-191	- 98 [KCS-83E	111			H-784K21	169	L2894HU	188

.

192

1



Another Supreme Publications Service Manual

~~~~~

Supreme Publications are Available at All Leading Parts Jobbers